

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	
Mondial						1980	2.0L F/I		Panel Filter	Air Filter	33-2001	1979	1.5L L4 2 BBL.		All	Air Filter	E-2710	
1983		All Qty.2		Air Filter	33-2019*	1980	2.5L DSL		Panel Filter	Air Filter	33-2001	1979	1.5L L4 F/I		All	Air Filter	E-2350	
1982		All Qty.2		Air Filter	33-2019*	1979	2.0L DSL		Panel Filter	Air Filter	33-2001	X1/9						
1981		8 Qty.2		Air Filter	33-2019*	1979	2.0L F/I		Panel Filter	Air Filter	33-2001	1982	1.5L L4 F/I		All	Air Filter	E-2350	
1980		8 Qty.2		Air Filter	33-2019*	1979	2.5L DSL		Panel Filter	Air Filter	33-2001	1981	1.5L L4 F/I		All	Air Filter	E-2350	
Testarossa						1972	1.6L		All	Air Filter	E-2670	1980	1.5L L4 2 BBL.		All	Air Filter	E-2350	
1984	5.0L V12	All		Air Filter	33-2799	850						1979	1.3L L4 2 BBL.		All	Air Filter	E-2710	
FIAT						1973			All	Air Filter	E-2540	1979	1.5L L4 2 BBL.		All	Air Filter	E-2350	
124						1973	.8L		850BN,Coupe	Air Filter	E-2540	1978	1.3L L4 2 BBL.		All	Air Filter	E-2710	
				Panel Filter	Air Filter	33-2001	1972		All	Air Filter	E-2540	1977	1.3L L4 2 BBL.		All	Air Filter	E-2710	
				Round Filter	Air Filter	E-2670	1972	.8L		850BN,Coupe	Air Filter	E-2540	1976	1.3L L4 2 BBL.		All	Air Filter	E-2710
1978	1.8L L4			All	Air Filter	E-2670	1971		All	Air Filter	E-2540	1975	1.3L L4 2 BBL.		All	Air Filter	E-2710	
1977	1.8L L4			All	Air Filter	E-2670	1971	.8L		850BN,Coupe	Air Filter	E-2540	1974	1.3L L4 2 BBL.		All	Air Filter	E-2710
1976	1.8L L4			All	Air Filter	E-2670	1970		All	Air Filter	E-2540	1973	1.3L		All	Air Filter	E-2710	
1975	1.8L L4			All	Air Filter	E-2670	1970	.8L		850BN,Coupe	Air Filter	E-2540	FORD					
1974	1.8L L4			All	Air Filter	E-2670	1969		All	Air Filter	E-2540	Aerostar						
1973	1.8L L4			All	Air Filter	E-2670	1969	.8L		850BN,Coupe	Air Filter	E-2540	1997	3.0L V6 F/I		All	Air Filter	33-2024
1972	1.8L L4			All	Air Filter	E-2670	1968		All	Air Filter	E-2540	1997	4.0L V6 F/I	(X)		Oil Filter	HP-3001	
1971	1.8L L4			All	Air Filter	E-2670	1968	.8L		850BN,Coupe	Air Filter	E-2540	1997	4.0L V6 F/I		All	Air Filter	33-2024
1970	1.8L L4			All	Air Filter	E-2670	1967		All	Air Filter	E-2540	1996	4.0L V6 F/I	(U)		Oil Filter	HP-2009	
1969	1.8L L4			All	Air Filter	E-2670	1967	.8L		850BN,Coupe	Air Filter	E-2540	1996	3.0L V6 F/I		All	Air Filter	33-2024
1968	1.8L L4			All	Air Filter	E-2670	1966		All	Air Filter	E-2540	1996	3.0L V6 F/I		All	Air Filter	33-2024	
1967	1.5L L4			All	Air Filter	E-2550	1966	.8L		850BN,Coupe	Air Filter	E-2540	1996	4.0L V6 F/I	(X)		Oil Filter	HP-3001
125						850BN						1996	4.0L V6 F/I		All	Air Filter	33-2024	
				BN,125S	Air Filter	E-2670	1974		All	Air Filter	E-2540	1995	3.0L V6 F/I	(U)		Oil Filter	HP-2009	
125BN						1100						1995	3.0L V6 F/I		All	Air Filter	33-2024	
1970				All	Air Filter	E-2670	1969	1.1L		All	Air Filter	E-2550	1995	4.0L V6 F/I	(X)		Oil Filter	HP-3001
1969				All	Air Filter	E-2670	1968	1.1L		All	Air Filter	E-2550	1995	4.0L V6 F/I		All	Air Filter	33-2024
128						1100B						1994	3.0L V6 F/I	(U)		Oil Filter	HP-2009	
1978		exc. Coupe/		Rallye	Air Filter	E-2570	1969		All	Air Filter	E-2550	1994	3.0L V6 F/I		All	Air Filter	33-2024	
1977		exc. Coupe/		Rallye	Air Filter	E-2570	1968		All	Air Filter	E-2550	1994	4.0L V6 F/I	(X)		Oil Filter	HP-3001	
1976		exc. Coupe/		Rallye	Air Filter	E-2570	1100D		eng.#	Air Filter	E-2550	1994	4.0L V6 F/I		All	Air Filter	33-2024	
1975		exc. Coupe/		Rallye	Air Filter	E-2570			1200698-up			1993	3.0L V6 F/I	(U)		Oil Filter	HP-2009	
1975	1.3L L4			All	Air Filter	E-2710	1100E				1993	3.0L V6 F/I		All	Air Filter	33-2024		
1974		exc. Coupe/		Rallye	Air Filter	E-2570	1969		All	Air Filter	E-2550	1993	4.0L V6 F/I	(X)		Oil Filter	HP-3001	
1974	1.3L L4			All	Air Filter	E-2710	1968		All	Air Filter	E-2550	1993	4.0L V6 F/I		All	Air Filter	33-2024	
1973		exc. Coupe/		Rallye	Air Filter	E-2570	1100ELR				1992	3.0L V6 F/I	(U)		Oil Filter	HP-2009		
1973	1.3L L4			All	Air Filter	E-2710	1969		All	Air Filter	E-2550	1992	4.0L V6 F/I	(X)		Oil Filter	HP-3001	
130						1300 Spyder						1992	4.0L V6 F/I		All	Air Filter	33-2024	
1976	3.0L V6 Coupe (OE4371573)			Air Filter	E-2710	1968	1.3L L4		All	Air Filter	E-2670	1992	3.0L V6 F/I		All	Air Filter	33-2024	
1975	3.0L V6 Coupe (OE4371573)			Air Filter	E-2710	1500				1992	4.0L V6 F/I	(X)		Oil Filter	HP-3001			
1974	3.0L V6 Coupe (OE4371573)			Air Filter	E-2710	1969	1.5L		Cabriolet All	Air Filter	E-2550	1992	4.0L V6 F/I		All	Air Filter	33-2024	
1973	3.0L V6 Coupe (OE4371573)			Air Filter	E-2710	1968	1.5L		Spyder All	Air Filter	E-2670	1992	4.0L V6 F/I	(U)		Oil Filter	HP-2009	
1972	3.0L V6 Coupe (OE4371573)			Air Filter	E-2710	1500 Cabriolet				1991	3.0L V6 F/I		All	Air Filter	33-2024			
1971	3.0L V6 Coupe (OE4371573)			Air Filter	E-2710	1969	1.5L L4		All	Air Filter	E-2670	1991	4.0L V6 F/I	(X)		Oil Filter	HP-3001	
1970	3.0L V6 Coupe (OE4371573)			Air Filter	E-2710	1968	1.5L L4		All	Air Filter	E-2670	1991	4.0L V6 F/I		All	Air Filter	33-2024	
1969	3.0L V6 Coupe (OE4371573)			Air Filter	E-2710	1500 Spyder				1990	3.0L V6 F/I	(U)		Oil Filter	HP-2009			
131						1969	1.5L L4		All	Air Filter	E-2670	1990	4.0L V6 F/I	(X)		Oil Filter	HP-3001	
1978	1.3L	Super & TC		Air Filter	E-2670	1500C				1990	4.0L V6 F/I		All	Air Filter	33-2024			
1978	1.8L L4			All	Air Filter	E-2670	1969	1.5L L4		All	Air Filter	E-2670	1990	4.0L V6 F/I		All	Air Filter	33-2024
1977	1.3L	Super & TC		Air Filter	E-2670	1500L				1989	3.0L V6 F/I	(U)		Oil Filter	HP-2009			
1977	1.8L L4			All	Air Filter	E-2670	1968	1.5L L4		All	Air Filter	E-2670	1989	3.0L V6 F/I		All	Air Filter	33-2024
1976	1.8L L4			All	Air Filter	E-2670	1600				1988	2.3L L4 F/I	(A)		Oil Filter	HP-3001		
1975	1.8L L4			All	Air Filter	E-2670	1968	1.5L L4		All	Air Filter	E-2670	1988	3.0L V6 F/I		All	Air Filter	33-2024
132						1967	1.6L		Coupe	Air Filter	E-2550	1987	2.3L L4 F/I	(A)		Oil Filter	HP-3001	
1982	2.0L DSL			Panel Filter	Air Filter	33-2001	1600s				1987	3.0L V6 F/I	(U)		Oil Filter	HP-2009		
1982	2.0L F/I			Panel Filter	Air Filter	33-2001	1967	1.6L L4		Coupe	Air Filter	E-2550	1987	3.0L V6 F/I		All	Air Filter	33-2024
1982	2.5L DSL			Panel Filter	Air Filter	33-2001	1800				1986	2.3L L4 F/I	(A)		Oil Filter	HP-3001		
1981	2.0L DSL			Panel Filter	Air Filter	33-2001	1967	1.8L L4		All	Air Filter	E-2720	1986	2.8L V6 2 BBL.	(S)		Oil Filter	HP-3001
1981	2.0L F/I			Panel Filter	Air Filter	33-2001	2100				1986	2.8L V6 2 BBL.		All	Air Filter	E-1280		
1981	2.5L DSL			Panel Filter	Air Filter	33-2001	1967	2.1L L4		All	Air Filter	E-2720	1986	3.0L V6 F/I	(U)		Oil Filter	HP-2009
1980	2.0L DSL			Panel Filter	Air Filter	33-2001	Spyder				1986	3.0L V6 F/I		All	Air Filter	33-2024		
							1982	2.0L L4 F/I		All	Air Filter	33-2001	1985	2.3L L4 F/I		All	Air Filter	33-2002
							1981	2.0L L4 F/I		All	Air Filter	33-2001	1985	2.8L V6 2 BBL.		All	Air Filter	E-1280
							1980	2.0L L4 F/I		II	Air Filter	33-2001	Aspire					
							Strada				1997	1.3L L4 F/I	(H)		Oil Filter	HP-1008		
							1981	1.5L L4 F/I		All	Air Filter	E-2350	1996	1.3L L4 F/I	(H)		Oil Filter	HP-1004
							1980	1.5L L4 2 BBL.		All	Air Filter	E-2710	1995	1.3L L4 F/I		All	Oil Filter	HP-1004
							1980	1.5L L4 F/I		All	Air Filter	E-2350	Bronco					

Automotive Applications

(Bronco cont.)

FORD

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #					
1996	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1990	5.8L	V8	F/I	All	FIPK	57-2503	1980	300	L6	1	BBL.	All	Air Filter	E-1040	
1996	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1989	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1980	302	V8	2	BBL.	(F)	Oil Filter	HP-3001	
1996	5.0L	V8	F/I	w/mass air	Air Filter	33-2023	1989	4.9L	L6	F/I	All	Air Filter	33-2023	1980	302	V8	2	BBL.	All	Air Filter	E-1290	
1996	5.0L	V8	F/I	w/mass air	FIPK	57-2510-1	1989	4.9L	L6	F/I	All	FIPK	57-2503	1980	351	V8	2	BBL.	(G)	Oil Filter	HP-3001	
1996	5.0L	V8	F/I	w/o mass air	Air Filter	33-2023	1989	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1980	351	V8	2	BBL.	All	Air Filter	E-1290	
1996	5.0L	V8	F/I	w/o mass air	Aircharger®	63-1014	1989	5.0L	V8	F/I	All	Air Filter	33-2023	1980	400	V8	2	BBL.	(Z)	Oil Filter	HP-3001	
1996	5.8L	V8	F/I	(H)	Oil Filter	HP-2010	1989	5.0L	V8	F/I	All	FIPK	57-2503	1980	400	V8	2	BBL.	All	Air Filter	E-1290	
1996	5.8L	V8	F/I	(H)	Oil Filter	HP-2010	1989	5.8L	V8	F/I	(H)	Oil Filter	HP-3001	1979	300	L6	1	BBL.	All	Air Filter	E-1040	
1996	5.8L	V8	F/I	w/mass air	Air Filter	33-2023	1989	5.8L	V8	F/I	All	Air Filter	33-2023	1979	302	V8	2	BBL.	All	Air Filter	E-1290	
1996	5.8L	V8	F/I	w/mass air	FIPK	57-2510-1	1989	5.8L	V8	F/I	All	FIPK	57-2503	1979	351	V8	2	BBL.	(H)	Oil Filter	HP-3001	
1996	5.8L	V8	F/I	w/o mass air	Air Filter	33-2023	1988	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1979	351	V8	2	BBL.	All	Air Filter	E-1290	
1996	5.8L	V8	F/I	w/o mass air	Aircharger®	63-1014	1988	4.9L	L6	F/I	All	Air Filter	33-2023	1979	400	V8	2	BBL.	(S)	Oil Filter	HP-3001	
1995	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1988	4.9L	L6	F/I	All	FIPK	57-2503	1979	400	V8	2	BBL.	All	Air Filter	E-1290	
1995	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1988	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1979	460	V8	4	BBL.	All	Air Filter	E-1570	
1995	5.0L	V8	F/I	w/mass air	Air Filter	33-2023	1988	5.0L	V8	F/I	All	Air Filter	33-2023	1978	300	L6	1	BBL.	All	Air Filter	E-1040	
1995	5.0L	V8	F/I	w/mass air	FIPK	57-2510-1	1988	5.0L	V8	F/I	All	FIPK	57-2503	1978	302	V8	2	BBL.	All	Air Filter	E-1290	
1995	5.0L	V8	F/I	w/o mass air	Air Filter	33-2023	1988	5.0L	V8	F/I	(H)	Oil Filter	HP-3001	1978	351	V8	2	BBL.	(H)	Oil Filter	HP-3001	
1995	5.0L	V8	F/I	w/o mass air	FIPK	57-2503	1988	5.8L	V8	F/I	All	Air Filter	33-2023	1978	351	V8	2	BBL.	All	Air Filter	E-1290	
1995	5.8L	V8	F/I	(H)	Oil Filter	HP-2010	1988	5.8L	V8	F/I	All	FIPK	57-2503	1978	400	V8	2	BBL.	(S)	Oil Filter	HP-3001	
1995	5.8L	V8	F/I	(H)	Oil Filter	HP-2010	1987	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1978	400	V8	2	BBL.	All	Air Filter	E-1290	
1995	5.8L	V8	F/I	w/mass air	Air Filter	33-2023	1987	4.9L	L6	F/I	All	Air Filter	33-2023	1978	460	V8	4	BBL.	All	Air Filter	E-1570	
1995	5.8L	V8	F/I	w/mass air	FIPK	57-2510-1	1987	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1977	302	V8	2	BBL.	(G)	Oil Filter	HP-3001	
1995	5.8L	V8	F/I	w/o mass air	Air Filter	33-2023	1987	5.0L	V8	F/I	All	Air Filter	33-2023	1977	302	V8	2	BBL.	All	Air Filter	E-1040	
1995	5.8L	V8	F/I	w/o mass air	FIPK	57-2503	1987	5.8L	V8	F/I	(H)	Oil Filter	HP-3001	1976	200	L6	1	BBL.	All	Air Filter	E-1200	
1994	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1987	5.8L	V8	F/I	All	Air Filter	E-1570	1976	200	L6	1	BBL.	All	Oil Filter	HP-3001	
1994	4.9L	L6	F/I	All	Air Filter	33-2023	1986	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1976	302	V8	2	BBL.	(G)	Oil Filter	HP-3001	
1994	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1986	4.9L	L6	F/I	All	Air Filter	E-1350	1976	302	V8	2	BBL.	All	Air Filter	E-1040	
1994	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1986	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1975	200	L6	1	BBL.	All	Air Filter	E-1200	
1994	5.0L	V8	F/I	w/mass air	Air Filter	33-2023	1986	5.0L	V8	F/I	All	Air Filter	33-2012	1975	200	L6	1	BBL.	All	Oil Filter	HP-3001	
1994	5.0L	V8	F/I	w/mass air	FIPK	57-2510-1	1986	5.8L	V8	2	BBL.	All	Air Filter	E-1290	1975	302	V8	2	BBL.	(G)	Oil Filter	HP-3001
1994	5.0L	V8	F/I	w/o mass air	Air Filter	33-2023	1986	5.8L	V8	4	BBL.	(H)	Oil Filter	HP-3001	1975	302	V8	2	BBL.	All	Air Filter	E-1040
1994	5.0L	V8	F/I	w/o mass air	FIPK	57-2503	1986	5.8L	V8	4	BBL.	All	Air Filter	E-1570	1974	200	L6	1	BBL.	All	Air Filter	E-1200
1994	5.8L	V8	F/I	(H)	Oil Filter	HP-2010	1985	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1974	200	L6	1	BBL.	All	Oil Filter	HP-3001	
1994	5.8L	V8	F/I	(H)	Oil Filter	HP-2010	1985	4.9L	L6	F/I	All	Air Filter	E-1350	1974	302	V8	2	BBL.	All	Air Filter	E-1040	
1994	5.8L	V8	F/I	w/mass air	Air Filter	33-2023	1985	5.0L	V8	2	BBL.	All	Air Filter	E-1290	1974	302	V8	2	BBL.	exc. cart.	Oil Filter	HP-3001
1994	5.8L	V8	F/I	w/o mass air	Air Filter	33-2023	1985	5.0L	V8	F/I	(N)	Oil Filter	HP-3001						type			
1994	5.8L	V8	F/I	w/o mass air	FIPK	57-2503	1985	5.0L	V8	F/I	All	Air Filter	33-2012	1973	200	L6	1	BBL.	All	Air Filter	E-1200	
1993	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1985	5.8L	V8	2	BBL.	(G)	Oil Filter	HP-3001	1973	200	L6	1	BBL.	All	Oil Filter	HP-3001
1993	5.0L	V8	F/I	All	Air Filter	33-2023	1985	5.8L	V8	2	BBL.	All	Air Filter	E-1290	1973	302	V8	2	BBL.	All	Air Filter	E-1040
1993	5.0L	V8	F/I	All	FIPK	57-2503	1985	5.8L	V8	4	BBL.	(H)	Oil Filter	HP-3001	1973	302	V8	2	BBL.	exc. cart.		
1993	5.8L	V8	F/I	(H)	Oil Filter	HP-3001	1985	5.8L	V8	4	BBL.	All	Air Filter	E-1570					type	Oil Filter	HP-3001	
1993	5.8L	V8	F/I	All	Air Filter	33-2023	1984	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1972	170	L6	1	BBL.	All	Air Filter	E-1200	
1993	5.8L	V8	F/I	All	FIPK	57-2503	1984	4.9L	L6	F/I	All	Air Filter	E-1350	1972	170	L6	1	BBL.	All	Oil Filter	HP-3001	
1992	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1984	5.0L	V8	2	BBL.	(F)	Oil Filter	HP-3001	1972	200	L6	1	BBL.	All	Air Filter	E-1200
1992	4.9L	L6	F/I	All	Air Filter	33-2023	1984	5.0L	V8	2	BBL.	All	Air Filter	E-1290	1972	302	V8	2	BBL.	All	Air Filter	E-1040
1992	4.9L	L6	F/I	All	FIPK	57-2503	1984	5.8L	V8	2	BBL.	(G)	Oil Filter	HP-3001	1972	302	V8	2	BBL.	exc. cart.		
1992	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1984	5.8L	V8	2	BBL.	All	Air Filter	E-1290					type	Oil Filter	HP-3001	
1992	5.0L	V8	F/I	All	Air Filter	33-2023	1984	5.8L	V8	4	BBL.	(H)	Oil Filter	HP-3001	1971	170	L6	1	BBL.	All	Air Filter	E-1200
1992	5.0L	V8	F/I	All	FIPK	57-2503	1984	5.8L	V8	4	BBL.	All	Air Filter	E-1570	1971	170	L6	1	BBL.	All	Oil Filter	HP-3001
1992	5.8L	V8	F/I	(H)	Oil Filter	HP-3001	1983	4.9L	L6	1	BBL.	(Y)	Oil Filter	HP-3001	1971	200	L6	1	BBL.	All	Air Filter	E-1200
1992	5.8L	V8	F/I	All	Air Filter	33-2023	1983	4.9L	L6	1	BBL.	All	Air Filter	E-1350	1971	302	V8	2	BBL.	All	Air Filter	E-1040
1992	5.8L	V8	F/I	All	FIPK	57-2503	1983	5.0L	V8	2	BBL.	(F)	Oil Filter	HP-3001	1971	302	V8	2	BBL.	exc. cart.		
1991	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1983	5.0L	V8	2	BBL.	All	Air Filter	E-1290					type	Oil Filter	HP-3001	
1991	4.9L	L6	F/I	All	Air Filter	33-2023	1983	5.8L	V8	2	BBL.	(G)	Oil Filter	HP-3001	1970	170	L6	1	BBL.	All	Air Filter	E-1200
1991	4.9L	L6	F/I	All	FIPK	57-2503	1983	5.8L	V8	2	BBL.	All	Air Filter	E-1290	1970	170	L6	1	BBL.	All	Oil Filter	HP-3001
1991	5.0L	V8	F/I	(H)	Oil Filter	HP-3001	1982	4.9L	L6	1	BBL.	(E)	Oil Filter	HP-3001	1970	200	L6	1	BBL.	All	Air Filter	E-1200
1991	5.0L	V8	F/I	All	Air Filter	33-2023	1982	4.9L	L6	1	BBL.	All	Air Filter	E-1350	1970	302	V8	2	BBL.	All	Air Filter	E-1040
1991	5.0L	V8	F/I	All	FIPK	57-2503	1982	5.0L	V8	2	BBL.	(F)	Oil Filter	HP-3001	1970	302	V8	2	BBL.	exc. cart.		
1991	5.8L	V8	F/I	(N)	Oil Filter	HP-3001	1982	5.0L	V8	2	BBL.	All	Air Filter	E-1290					type	Oil Filter	HP-3001	
1991	5.8L	V8	F/I	All	Air Filter	33-2023	1982	5.8L	V8	2	BBL.	(G)	Oil Filter	HP-3001	1969	170	L6	1	BBL.	All	Air Filter	E-1200
1991	5.8L	V8	F/I	All	FIPK	57-2503	1982	5.8L	V8	2	BBL.	All	Air Filter	E-1290	1969	170	L6	1	BBL.	All	Oil Filter	HP-3001
1990	4.9L	L6	F/I	(Y)	Oil Filter	HP-3001	1981	4.9L	L6	1	BBL.	(E)	Oil Filter	HP-3001	1969	200	L6	1	BBL.	All	Air Filter	E-1200
1990	4.9L	L6	F/I	All	Air Filter	33-2023	1981	4.9L	L6	1	BBL.	All	Air Filter	E-1040	1969	289	V8	2	BBL.	All	Air Filter	E-1040
1990	4.9L	L6	F/I	All	FIPK	57-2503	1981	5.0L	V8	2	BBL.	(F)	Oil Filter	HP-3001	1969	289	V8	2	BBL.	exc. cart.		
1990	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1981	5.0L	V8	2	BBL.	All	Air Filter	E-1290					type	Oil Filter	HP-3001	
1990	5.0L	V8	F/I	All	Air Filter	33-2023	1981	5.8L	V8	2	BBL.	(G)	Oil Filter	HP-3001	1969	302	V8	2	BBL.	All	Air Filter	E-1040
1990	5.0L	V8	F/I	All	FIPK	57-2503	1981	5.8L	V8	2	BBL.	All	Air Filter	E-1290	1969	302	V8	2	BBL.	exc. cart. type	Oil Filter	HP-3001
1990	5.8L	V8	F/I	(H)	Oil Filter	HP-3001	1981	6.6L	V8	2	BBL.	All	Air Filter	E-1290	1968	170	L6	1	BBL.	All	Air Filter	E-1200
1990	5.8L	V8	F/I	All	Air Filter	33-2023	1980	300	L6	1	BBL.	(E)	Oil Filter	HP-3001								

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	
1968	170 L6	1 BBL.	All	Oil Filter	HP-3001	1995	2.5L V6	F/I	All	Air Filter	33-2115-1	2000	4.6L V8	F/I	All	Air Filter	33-2101	
1968	200 L6	1 BBL.	All	Air Filter	E-1200	1995	2.5L V6	F/I	All	Oil Filter	HP-2010	1999	4.6L V8	F/I	(9,W)	Oil Filter	HP-2010	
1968	289 V8	2 BBL.	All	Air Filter	E-1040	Country Squire						1999	4.6L V8	F/I	All	Air Filter	33-2101	
1968	289 V8	2 BBL.	exc. cart. type	Oil Filter	HP-3001	1990	5.0L V8	F/I	(F)	Oil Filter	HP-3001	1998	4.6L V8	F/I	(9,W) inc.			
1968	302 V8	2 BBL.	All	Air Filter	E-1040	1990	5.0L V8	F/I	All	Air Filter	33-2012				natural gas	Oil Filter	HP-2010	
1968	302 V8	2 BBL.	exc. cart. type	Oil Filter	HP-3001	1990	5.8L V8	2 BBL.	All	Air Filter	E-1290	1998	4.6L V8	F/I	All	Air Filter	33-2101	
1967	289 V8	2 BBL.	All	Air Filter	E-1040	1989	5.0L V8	F/I	(F)	Oil Filter	HP-3001	1997	4.6L V8	F/I	(9,W) inc.			
1967	289 V8	2 BBL.	All	Oil Filter	HP-3001	1989	5.0L V8	F/I	Wagon	Air Filter	33-2012				natural gas	Oil Filter	HP-2010	
1966	289 V8	2 BBL.	All	Air Filter	E-1040	1989	5.8L V8	2 BBL.	Wagon	Air Filter	E-1290	1997	4.6L V8	F/I	All	Air Filter	33-2101	
1966	289 V8	2 BBL.	All	Oil Filter	HP-3001	1988	5.0L V8	F/I	(F)	Oil Filter	HP-3001	1996	4.6L V8	F/I	(9,W) inc.			
1965	289 V8	2 BBL.	All	Air Filter	E-1040	1988	5.0L V8	F/I	Wagon	Air Filter	33-2012				natural gas	Oil Filter	HP-2010	
Bronco II						1988	5.8L V8	2 BBL.	Wagon	Air Filter	E-1290	1996	4.6L V8	F/I	All	Air Filter	33-2101	
1990	2.9L V6	F/I	(T)	Oil Filter	HP-3001	1987	5.0L V8	F/I	(F)	Oil Filter	HP-3001	1995	4.6L V8	F/I	(W)	Oil Filter	HP-2010	
1990	2.9L V6	F/I	All	Air Filter	33-2024	1987	5.0L V8	F/I	All	Air Filter	33-2012	1995	4.6L V8	F/I	All	Air Filter	33-2101	
1989	2.9L V6	F/I	(T)	Oil Filter	HP-3001	1987	5.8L V8	2 BBL.	All	Air Filter	E-1290	1994	4.6L V8	F/I	(W)	Oil Filter	HP-2010	
1989	2.9L V6	F/I	All	Air Filter	33-2024	1986	5.0L V8	F/I	(F)	Oil Filter	HP-3001	1994	4.6L V8	F/I	All	Air Filter	33-2101	
1988	2.9L V6	F/I	(T)	Oil Filter	HP-3001	1986	5.0L V8	F/I	All	Air Filter	33-2012	1993	4.6L V8	F/I	(W)	Oil Filter	HP-2010	
1988	2.9L V6	F/I	All	Air Filter	33-2024	1986	5.8L V8	2 BBL.	All	Air Filter	E-1290	1993	4.6L V8	F/I	All	Air Filter	33-2101	
1987	2.9L V6	F/I	(T)	Oil Filter	HP-3001	1985	5.0L V8	F/I	(F)	Oil Filter	HP-3001	1992	4.6L V8	F/I	(W)	Oil Filter	HP-2010	
1986	2.3L L4	DSL	(E)	Oil Filter	HP-3001	1985	5.0L V8	F/I	All	Air Filter	E-1290	1992	4.6L V8	F/I	All	Air Filter	33-2101	
1986	2.9L V6	F/I	(T)	Oil Filter	HP-3001	1985	5.8L V8	2 BBL.	(G)	Oil Filter	HP-3001	1991	5.0L V8	F/I	(F)	Oil Filter	HP-3001	
1985	2.3L L4	DSL	(E)	Oil Filter	HP-3001	1985	5.8L V8	2 BBL.	All	Air Filter	E-1290	1991	5.0L V8	F/I	All	Air Filter	33-2195	
1985	2.8L V6	2 BBL.	(S)	Oil Filter	HP-3001	1985	5.8L V8	2 BBL.	w/oil cooler	Oil Filter	HP-2004	1991	5.8L V8	2 BBL.	(G)	Oil Filter	HP-2004	
1985	2.8L V6	2 BBL.	All	Air Filter	E-1280	1984	5.0L V8	F/I	(F)	Oil Filter	HP-3001	1991	5.8L V8	2 BBL.	All	Air Filter	E-1290	
1984	2.2L L4	DSL	All	Air Filter	E-0990	1984	5.0L V8	F/I	All	Air Filter	E-1290	1990	5.0L V8	F/I	(F)	Oil Filter	HP-3001	
1984	2.3L L4	DSL	All	Air Filter	E-1088	1984	5.8L V8	2 BBL.	(G) Police	Oil Filter	HP-3001	1990	5.0L V8	F/I	All	Air Filter	33-2195	
1984	2.8L V6	2 BBL.	(S)	Oil Filter	HP-3001	1984	5.8L V8	2 BBL.	All	Air Filter	E-1290	1990	5.8L V8	2 BBL.	(G)	Oil Filter	HP-2004	
1984	2.8L V6	2 BBL.	All	Air Filter	E-1280	1983	5.0L V8	F/I	(F)	Oil Filter	HP-3001	1990	5.8L V8	2 BBL.	All	Air Filter	E-1290	
1983	2.2L L4	DSL	All	Air Filter	E-0990	1983	5.0L V8	F/I	All	Air Filter	E-1290	1989	5.0L V8	F/I	(F)	Oil Filter	HP-3001	
1983	2.3L L4	DSL	All	Air Filter	E-1088	1983	5.8L V8	2 BBL.	(G)	Oil Filter	HP-3001	1989	5.0L V8	F/I	All	Air Filter	33-2195	
1983	2.8L V6	2 BBL.	All	Air Filter	E-1280	1983	5.8L V8	2 BBL.	All	Air Filter	E-1290	1989	5.8L V8	2 BBL.	(G) Police	Oil Filter	HP-2004	
1982	2.3L L4	DSL	All	Air Filter	E-1088	1976	351 V8	2 BBL.	M	Air Filter	E-1300	1989	5.8L V8	2 BBL.	All	Air Filter	E-1290	
Brougham						1976	400 V8	2 BBL.	All	Air Filter	E-1300	1988	5.0L V8	F/I	(F)	Oil Filter	HP-3001	
1974	351 V8	2 BBL.	All	Air Filter	E-1300	1976	460 V8	4 BBL.	exc. Police	Air Filter	E-1580	1988	5.0L V8	F/I	All	Air Filter	33-2195	
1974	400 V8	2 BBL.	All	Air Filter	E-1580	1976	460 V8	4 BBL.	Police only	Air Filter	E-1570	1988	5.8L V8	2 BBL.	(G) H.P.	Oil Filter	HP-3001	
1974	460 V8	4 BBL.	exc. Police	Air Filter	E-1580	1975	351 V8	2 BBL.	M	Air Filter	E-1300	1988	5.8L V8	2 BBL.	All	Air Filter	E-1290	
1974	460 V8	4 BBL.	Police only	Air Filter	E-1570	1975	400 V8	2 BBL.	All	Air Filter	E-1580	1987	5.0L V8	F/I	(F)	Oil Filter	HP-3001	
1973	250 L6	1 BBL.	All	Air Filter	E-1350	1975	460 V8	4 BBL.	exc. Police	Air Filter	E-1580	1987	5.0L V8	F/I	All	Air Filter	33-2195	
1973	302 V8	2 BBL.	All	Air Filter	E-1300	1975	460 V8	4 BBL.	Police only	Air Filter	E-1570	1987	5.8L V8	2 BBL.	(G) H.P.	Oil Filter	HP-3001	
1973	351 V8	2 BBL.	(C,W)			1974	351 V8	2 BBL.	All	Air Filter	E-1300	1987	5.8L V8	2 BBL.	All	Air Filter	E-1290	
			exc. Police	Air Filter	E-1300	1974	400 V8	2 BBL.	All	Air Filter	E-1580	1986	5.0L V8	F/I	(F)	Oil Filter	HP-3001	
1973	351 V8	2 BBL.	(C,W)			1974	460 V8	4 BBL.	exc. Police	Air Filter	E-1580	1986	5.0L V8	F/I	All	Air Filter	33-2195	
			exc. Police	Air Filter	E-1570	1974	460 V8	4 BBL.	Police only	Air Filter	E-1570	1986	5.8L V8	2 BBL.	(G) H.P., Police	Oil Filter	HP-3001	
1973	400 V8	4 BBL.	exc. Police	Air Filter	E-1580	Courier						1986	5.8L V8	2 BBL.	All	Air Filter	E-1290	
1973	400 V8	4 BBL.	Police only	Air Filter	E-1570	1980	2.0L L4	2 BBL.	All	Air Filter	E-2790	1986	5.8L V8	2 BBL.	w/oil cooler	Oil Filter	HP-2004	
1973	429 V8	4 BBL.	exc. Police	Air Filter	E-1580	1980	2.3L L4	2 BBL.	(B)	Oil Filter	HP-2004	1985	5.0L V8	F/I	(F)	Oil Filter	HP-3001	
1973	429 V8	4 BBL.	Police only	Air Filter	E-1570	1980	2.3L L4	2 BBL.	All	Air Filter	E-2790	1985	5.0L V8	F/I	All	Air Filter	E-1290	
1973	460 V8	4 BBL.	exc. Police	Air Filter	E-1580	1979	2.0L L4	2 BBL.	All	Air Filter	E-2790	1985	5.8L V8	2 BBL.	(G)	Oil Filter	HP-3001	
1973	460 V8	4 BBL.	Police only	Air Filter	E-1570	1979	2.3L L4	2 BBL.	(B)	Oil Filter	HP-3001	1985	5.8L V8	2 BBL.	All	Air Filter	E-1290	
Contour						1979	2.3L L4	2 BBL.	All	Air Filter	E-2790	1985	5.8L V8	2 BBL.	All	Air Filter	E-1290	
2000	2.0L L4	F/I	All	Air Filter	33-2132	1978	1.8L L4	2 BBL.	All	Air Filter	E-2790	1985	5.8L V8	2 BBL.	w/oil cooler	Oil Filter	HP-2004	
2000	2.5L V6	F/I	(G,L)	Oil Filter	HP-2010	1978	2.3L L4	2 BBL.	(B)	Oil Filter	HP-3001	1984	5.0L V8	F/I	(G) Police	Oil Filter	HP-3001	
2000	2.5L V6	F/I	exc. SVT	Air Filter	33-2115-1	1978	2.3L L4	2 BBL.	All	Air Filter	E-2790	1984	5.0L V8	F/I	All	Air Filter	E-1290	
2000	2.5L V6	F/I	SVT	Air Filter	E-0998	1977	1.8L L4	2 BBL.	All	Air Filter	E-2790	1984	5.8L V8	2 BBL.	All	Air Filter	E-1290	
1999	2.0L L4	F/I	All	Air Filter	33-2132	1977	2.3L L4	2 BBL.	(B)	Oil Filter	HP-3001	1983	5.0L V8	F/I	(F)	Oil Filter	HP-3001	
1999	2.5L V6	F/I	(G,L)	Oil Filter	HP-2010	1977	2.3L L4	2 BBL.	All	Air Filter	E-2790	1983	5.0L V8	F/I	All	Air Filter	E-1290	
1999	2.5L V6	F/I	exc. SVT	Air Filter	33-2115-1	1976	1.8L L4	2 BBL.	All	Air Filter	E-2890	1983	5.8L V8	2 BBL.	(G) Police	Oil Filter	HP-3001	
1999	2.5L V6	F/I	SVT	Air Filter	E-0998	1975	1.8L L4	2 BBL.	All	Air Filter	E-2890	1983	5.8L V8	2 BBL.	All	Air Filter	E-1290	
1998	2.0L L4	F/I	All	Air Filter	33-2132	1974	1.8L L4	2 BBL.	All	Air Filter	E-2890	Custom 500						
1998	2.5L V6	F/I	(G,L)	Oil Filter	HP-2010	1973	1.8L L4	2 BBL.	All	Air Filter	E-2890	1974	351 V8	2 BBL.	(C)	Air Filter	E-1300	
1998	2.5L V6	F/I	exc. SVT	Air Filter	33-2115-1	1972	1.8L L4	2 BBL.	All	Air Filter	E-2890	1974	351 V8	2 BBL.	(W)	Air Filter	E-1300	
1998	2.5L V6	F/I	SVT	Air Filter	E-0998	Crown Victoria						1974	400 V8	2 BBL.	(S)	Oil Filter	HP-3001	
1997	2.0L L4	F/I	All	Air Filter	33-2132	2003	4.6L V8	F/I	(9), CNG	Oil Filter	HP-2010	1974	400 V8	2 BBL.	All	Air Filter	E-1580	
1997	2.5L V6	F/I	(L)	Oil Filter	HP-2010	2003	4.6L V8	F/I	(W)	Oil Filter	HP-2010	1974	460 V8	4 BBL.	exc. Police	Air Filter	E-1580	
1997	2.5L V6	F/I	All	Air Filter	33-2115-1	2002	4.6L V8	F/I	(9), (W)	Oil Filter	HP-2010	1974	460 V8	4 BBL.	Police	Air Filter	E-1570	
1996	2.0L L4	F/I	All	Air Filter	33-2132	2002	4.6L V8	F/I	All	Air Filter	33-2101	1973	351 V8	2 BBL.	exc. Police	Air Filter	E-1300	
1996	2.5L V6	F/I	(L)	Oil Filter	HP-2010	2001	4.6L V8	F/I	(9,W)	Oil Filter	HP-2010	1973	351 V8	2 BBL.	Police	Air Filter	E-1570	
1996	2.5L V6	F/I	All	Air Filter	33-2115-1	2001	4.6L V8	F/I	All	Air Filter	33-2101	1973	400 V8	4 BBL.	(S)	Oil Filter	HP-3001	
1995	2.0L L4	F/I	All	Air Filter	33-2132	2000	4.6L V8	F/I	(9,W)	Oil Filter	HP-2010	1973	400 V8	4 BBL.	exc. Police	Air Filter	E-1580	

Automotive Applications

(Custom 500 cont.)

FORD

YRS.	ENG.	DISP.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.	DISP.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.	DISP.	INTAKE	COMMENTS	PRODUCT	PART #	
1973	429	V8	4 BBL.	exc.Police	Air Filter	E-1580	1993	1.8L	L4	F/I	GT	FIPK	57-2500	EXP							
1973	429	V8	4 BBL.	Police	Air Filter	E-1570	1993	1.9L	L4	EFI	(J)	Oil Filter	HP-2009	1988	1.9L	L4	CFI	(9,J)	Oil Filter	HP-2009	
1973	460	V8	4 BBL.	exc.Police	Air Filter	E-1580	1993	1.9L	L4	EFI	All	Air Filter	33-2126	1987	1.9L	L4	EFI	(9,J)	Oil Filter	HP-2009	
1973	460	V8	4 BBL.	Police	Air Filter	E-1570	1992	1.8L	L4	F/I	All	Air Filter	33-2034	1987	1.9L	L4	EFI	All	Air Filter	33-2002	
1972	240	L6	1 BBL.	All	Air Filter	E-1200	1992	1.8L	L4	F/I	All	Oil Filter	HP-1008	1986	1.9L	L4	CFI	All	Air Filter	E-1958	
1972	302	V8	2 BBL.	All	Air Filter	E-1300	1992	1.8L	L4	F/I	GT	FIPK	57-2500	1986	1.9L	L4	EFI	All	Air Filter	33-2002	
1972	351	V8	2 BBL.	(W)	Air Filter	E-1300	1992	1.9L	L4	EFI	(J)	Oil Filter	HP-2009	1985	1.6L	L4	2 BBL.	Non Turbo	Air Filter	E-1958	
1972	351	V8	4 BBL.	exc.351 W	Air Filter	E-1570	1992	1.9L	L4	EFI	All	Air Filter	33-2126	1985	1.6L	L4	F/I	(8) Turbo	Oil Filter	HP-2004	
1972	400	V8	2 BBL.	All	Air Filter	E-1570	1991	1.8L	L4	F/I	All	Air Filter	33-2034	1985	1.6L	L4	F/I	Turbo	Air Filter	33-2002	
1972	429	V8	4 BBL.	All	Air Filter	E-1570	1991	1.8L	L4	F/I	All	Oil Filter	HP-1008	1984	1.6L	L4	2 BBL.	(4)	Oil Filter	HP-2009	
1971	240	L6	1 BBL.	All	Air Filter	E-1200	1991	1.8L	L4	F/I	GT	FIPK	57-2500	1984	1.6L	L4	2 BBL.	Non Turbo	Air Filter	E-1958	
1971	302	V8	2 BBL.	All	Air Filter	E-1570	1991	1.9L	L4	EFI	(J)	Oil Filter	HP-2009	1984	1.6L	L4	F/I	(8) Turbo	Oil Filter	HP-2004	
1971	351	V8	2 BBL.	All	Air Filter	E-1570	1991	1.9L	L4	EFI	All	Air Filter	33-2126	1984	1.6L	L4	F/I	Turbo	Air Filter	33-2002	
1971	390	V8	2 BBL.	All	Air Filter	E-1570	1990	1.9L	L4	EFI	(J)	Oil Filter	HP-2009	1983	1.6L	L4	2 BBL.	(2,4)	Oil Filter	HP-2009	
1971	400	V8	2 BBL.	All	Air Filter	E-1570	1990	1.9L	L4	EFI	All	Air Filter	33-2087	1983	1.6L	L4	2 BBL.	All	Air Filter	E-1958	
1971	429	V8	4 BBL.	All	Air Filter	E-1570	1989	1.9L	L4	EFI	(J)	Oil Filter	HP-2009	1982	1.6L	L4	2 BBL.	(2,4)	Oil Filter	HP-2009	
1970	240	L6	1 BBL.	All	Air Filter	E-1200	1989	1.9L	L4	EFI	All	Air Filter	33-2087	1982	1.6L	L4	2 BBL.	All	Air Filter	E-1958	
1970	302	V8	2 BBL.	All	Air Filter	E-1570	1988	1.9L	L4	EFI	(9,J)	Oil Filter	HP-2009	1981	1.6L	L4	2 BBL.	All	Air Filter	E-1958	
1970	351	V8	2 BBL.	All	Air Filter	E-1570	1988	1.9L	L4	EFI	All	Air Filter	33-2087	Expedition							
1970	390	V8	2 BBL.	All	Air Filter	E-1570	1987	1.9L	L4	EFI	(J)	Oil Filter	HP-2009	2003	4.6L	V8	F/I	All	Air Filter	E-0945	
1970	429	V8	4 BBL.	All	Air Filter	E-1570	1987	1.9L	L4	EFI	All	Air Filter	33-2087	2003	4.6L	V8	F/I	(W)	Oil Filter	HP-2010	
							1986	1.9L	L4	CFI	All	Air Filter	E-1958	2003	5.4L	V8	F/I	All	Air Filter	E-0945	
							1986	1.9L	L4	EFI	All	Air Filter	33-2087	2003	5.4L	V8	F/I	(L)	Oil Filter	HP-2010	
							1985	1.6L	L4	2 BBL.	(2,4)	Oil Filter	HP-2009	2002	4.6L	V8	F/I	(W)	Oil Filter	HP-2010	
							1985	1.6L	L4	2 BBL.	All	Air Filter	E-1958	2002	4.6L	V8	F/I	All	Air Filter	E-0945	
							1984	1.6L	L4	2 BBL.	(2,4)	Oil Filter	HP-2009	2002	4.6L	V8	F/I	All	FIPK	57-2514-4	
							1984	1.6L	L4	2 BBL.	All	Air Filter	E-1958	2002	5.4L	V8	F/I	(L)	Oil Filter	HP-2010	
							1984	1.6L	L4	F/I	(5)	Oil Filter	HP-2009	2002	5.4L	V8	F/I	All	Air Filter	E-0945	
							1984	1.6L	L4	F/I	All	Air Filter	33-2002	2002	5.4L	V8	F/I	All	FIPK	57-2514-4	
							1983	1.6L	L4	2 BBL.	(2,4)	Oil Filter	HP-2009	2001	4.6L	V8	F/I	(W)	Oil Filter	HP-2010	
							1983	1.6L	L4	2 BBL.	All	Air Filter	E-1958	2001	4.6L	V8	F/I	All	Air Filter	E-0945	
							1983	1.6L	L4	F/I	(5)	Oil Filter	HP-2009	2001	4.6L	V8	F/I	All	FIPK	57-2514-4	
							1983	1.6L	L4	F/I	All	Air Filter	33-2002	2001	5.4L	V8	F/I	(L)	Oil Filter	HP-2010	
							1982	1.6L	L4	2 BBL.	(2,4)	Oil Filter	HP-2009	2001	5.4L	V8	F/I	All	Air Filter	E-0945	
							1982	1.6L	L4	2 BBL.	All	Air Filter	E-1958	2001	5.4L	V8	F/I	All	FIPK	57-2514-4	
							1981	1.6L	L4	2 BBL.	(2)	Oil Filter	HP-2009	2000	4.6L	V8	F/I	(W)	Oil Filter	HP-2010	
							1981	1.6L	L4	2 BBL.	All	Air Filter	E-1958	2000	4.6L	V8	F/I	All	Air Filter	E-0945	
														2000	4.6L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	(L)	Oil Filter	HP-2010	
														2000	5.4L	V8	F/I	All	Air Filter	E-0945	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-2514-4	
														2000	5.4L	V8	F/I	All	FIPK	57-25	

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #
2001	4.0L V6	F/I	(X)	Oil Filter	HP-3001	1970	250 L6	1 BBL.	All	Air Filter	E-1350	1970	302 V8	2 BBL.	All	Oil Filter	HP-3001
2001	4.0L V6	F/I	All	Air Filter	33-2106-1	1970	250 L6	1 BBL.	All	Oil Filter	HP-3001	1969	170 L6	1 BBL.	All	Air Filter	E-1200
2001	4.0L V6	F/I	All	FIPK	57-2529-1	1970	302 V8	2 BBL.	All	Air Filter	E-1570	1969	170 L6	1 BBL.	All	Oil Filter	HP-3001
2001	5.0L V8	F/I	(P)	Oil Filter	HP-2010	1970	302 V8	2 BBL.	All	Oil Filter	HP-3001	1969	200 L6	1 BBL.	All	Air Filter	E-1030
2001	5.0L V8	F/I	All	Air Filter	33-2106-1	1970	351 V8	4 BBL.	All	Oil Filter	HP-3001	1969	200 L6	1 BBL.	All	Oil Filter	HP-3001
2000	4.0L V6	F/I	(E,X)	Oil Filter	HP-3001	1970	351 V8	4 BBL.	All	Oil Filter	HP-3001	1969	302 V8	2 BBL.	All	Air Filter	E-1570
2000	4.0L V6	F/I	All	Air Filter	33-2106-1	1970	351 V8	4 BBL. w/Ram air	All	Air Filter	E-1580	1969	302 V8	2 BBL.	All	Oil Filter	HP-3001
2000	4.0L V6	F/I	OHV	FIPK	57-2527	1970	351 V8	4 BBL. w/o Ram air	All	Air Filter	E-1570	1968	170 L6	1 BBL.	All	Air Filter	E-1030
2000	4.0L V6	F/I	SOHC	FIPK	57-2528	1970	390 V8	4 BBL.	SCJ	Air Filter	E-1560	1968	170 L6	1 BBL.	All	Oil Filter	HP-3001
2000	5.0L V8	F/I	(P)	Oil Filter	HP-2010	1970	429 V8	4 BBL. CJ w/ Ramair	All	Air Filter	E-1580	1968	289 V8	2 BBL.	All	Air Filter	E-1570
2000	5.0L V8	F/I	All	Air Filter	33-2106-1	1970	429 V8	4 BBL. CJ w/ Ramair	All	Air Filter	E-1580	1968	289 V8	2 BBL.	All	Oil Filter	HP-3001
1999	4.0L V6	F/I	(E,X)	Oil Filter	HP-3001	1970	429 V8	4 BBL.	SCJ	Air Filter	E-1560	1968	289 V8	4 BBL.	All	Air Filter	E-1560
1999	4.0L V6	F/I	All	Air Filter	33-2106-1	1969	250 L6	1 BBL.	All	Air Filter	E-1030	1968	302 V8	2 BBL.	All	Air Filter	E-1570
1999	4.0L V6	F/I	OHV	FIPK	57-2527	1969	250 L6	1 BBL.	All	Oil Filter	HP-3001	1968	302 V8	4 BBL.	All	Air Filter	E-1570
1999	4.0L V6	F/I	SOHC	FIPK	57-2528	1969	302 V8	2 BBL.	All	Air Filter	E-1570	1968	302 V8	4 BBL.	All	Oil Filter	HP-3001
1999	5.0L V8	F/I	(P)	Oil Filter	HP-2010	1969	302 V8	2 BBL.	All	Oil Filter	HP-3001	1968	302 V8	4 BBL.	All	Oil Filter	HP-3001
1999	5.0L V8	F/I	All	Air Filter	33-2106-1	1969	351 V8	4 BBL.	All	Air Filter	E-1570	1993	1.3L L4	F/I	(H)	Oil Filter	HP-1004
1998	4.0L V6	F/I	(X,E)	Oil Filter	HP-3001	1969	351 V8	4 BBL.	All	Oil Filter	HP-3001	1992	1.3L L4	F/I	(H)	Oil Filter	HP-1004
1998	4.0L V6	F/I	Flat	Air Filter	33-2106-1	1969	390 V8	4 BBL.	All	Air Filter	E-1560	1991	1.3L L4	F/I	(H)	Oil Filter	HP-1004
1998	4.0L V6	F/I	OHV	FIPK	57-2527	1969	390 V8	4 BBL.	All	Oil Filter	HP-3001	1990	1.3L L4	2 BBL.	(H,K)	Oil Filter	HP-1004
1998	4.0L V6	F/I	Round	Air Filter	E-0996	1969	428 V8	4 BBL.	All	Oil Filter	HP-3001	1980	160 L4	1 BBL.	All	Air Filter	E-1280
1998	4.0L V6	F/I	SOHC	FIPK	57-2528	1969	428 V8	4 BBL. Cobra Jet	All	Air Filter	E-1560	1979	160 L4	1 BBL.	All	Air Filter	E-1280
1998	5.0L V8	F/I	(P)	Oil Filter	HP-2010	1968	200 L6	1 BBL.	All	Air Filter	E-1030	1980	160 L4	1 BBL.	All	Air Filter	E-1280
1998	5.0L V8	F/I	Flat	Air Filter	33-2106-1	1968	200 L6	1 BBL.	All	Oil Filter	HP-3001	1979	160 L4	1 BBL.	All	Air Filter	E-1280
1998	5.0L V8	F/I	Round	Air Filter	E-0996	1968	289 V8	2 BBL.	All	Air Filter	E-1570	2003	2.0L L4	F/I	inc SVT, DOHC	Air Filter	33-2819
1997	4.0L V6	F/I	(X) OHV, (E)	Oil Filter	HP-3001	1968	289 V8	2 BBL.	All	Oil Filter	HP-3001	2003	2.0L L4	F/I	(P) SOHC	Oil Filter	HP-2009
1997	4.0L V6	F/I	SOHC	Oil Filter	HP-3001	1968	302 V8	2 BBL.	All	Air Filter	E-1570	2002	2.0L L4	F/I	(P)	Oil Filter	HP-2009
1997	4.0L V6	F/I	Flat	Air Filter	33-2106-1	1968	302 V8	2 BBL.	All	Oil Filter	HP-3001	2002	2.0L L4	F/I	All	Air Filter	33-2819
1997	4.0L V6	F/I	OHV	Aircharger®	63-1044	1968	390 V8	4 BBL.	All	Air Filter	E-1570	2002	2.0L L4	F/I	All	Air Filter	33-2819
1997	4.0L V6	F/I	OHV	FIPK	57-2513-1	1968	390 V8	4 BBL.	All	Oil Filter	HP-3001	2002	2.0L L4	F/I	DOHC	FIPK	57-2526-2
1997	4.0L V6	F/I	OHV, w/ FA-1658 Panel Filter	FIPK	57-2527	1968	427 V8	4 BBL.	All	Air Filter	E-1560	2001	1.8L L4	DSL	All	Air Filter	33-2819
1997	4.0L V6	F/I	Round	Air Filter	E-0996	1967	427 V8	2x4BBL.	All	Air Filter	E-1960	2001	2.0L L4	F/I	(P)	Oil Filter	HP-2009
1997	4.0L V6	F/I	SOHC	FIPK	57-2528	1983	2.3L L4	1 BBL.	(A)	Oil Filter	HP-3001	2001	2.0L L4	F/I	All	Air Filter	33-2819
1997	5.0L V8	F/I	(P)	Oil Filter	HP-2010	1983	2.3L L4	1 BBL.	All	Air Filter	E-1200	2001	2.0L L4	F/I	DOHC	FIPK	57-2526-2
1997	5.0L V8	F/I	Flat	Air Filter	33-2106-1	1983	2.3L L4	1 BBL.	All	Air Filter	E-1200	2000	2.0L L4	F/I	(P)	Oil Filter	HP-2009
1997	5.0L V8	F/I	Round	Air Filter	E-0996	1983	3.3L L6	1 BBL.	(X)	Oil Filter	HP-3001	2000	2.0L L4	F/I	All	Air Filter	33-2819
1997	5.0L V8	F/I	Round	FIPK	57-2513-1	1983	3.3L L6	1 BBL.	All	Air Filter	E-1350	2000	2.0L L4	F/I	DOHC	FIPK	57-2526-2
1996	4.0L V6	F/I	(X)	Oil Filter	HP-3001	1982	2.3L L4	2 BBL.	(A)	Oil Filter	HP-3001	1998	1.8L L4	F/I	Zetec	Air Filter	33-2819
1996	4.0L V6	F/I	All	Air Filter	E-0995	1982	2.3L L4	2 BBL.	All	Air Filter	E-1200	1998	2.0L L4	F/I	Zetec	Air Filter	33-2819
1996	4.0L V6	F/I	All	FIPK	57-2513-1	1982	3.3L L6	1 BBL.	(B)	Oil Filter	HP-3001	1964	427 V8	2x4BBL.	All	Air Filter	E-1960
1996	4.0L V6	F/I	OHV	Aircharger®	63-1044	1982	3.3L L6	1 BBL.	All	Air Filter	E-1350	1964	427 V8	3x2BBL.	All	Air Filter	E-1960
1996	5.0L V8	F/I	(P)	Oil Filter	HP-2010	1982	4.2L V8	2 BBL.	(D)	Oil Filter	HP-3001	1963	406 V8	3x2BBL.	All	Air Filter	E-1960
1996	5.0L V8	F/I	All	Air Filter	E-0996	1982	4.2L V8	2 BBL.	All	Air Filter	E-1180	1963	427 V8	3x2BBL.	All	Air Filter	E-1960
1996	5.0L V8	F/I	All	FIPK	57-2513-1	1981	2.3L L4	2 BBL.	All	Air Filter	E-1200	1962	406 V8	3x2BBL.	All	Air Filter	E-1960
1995	4.0L V6	F/I	(X)	Oil Filter	HP-3001	1981	3.3L L6	1 BBL.	All	Air Filter	E-1350	1961	3"	tall, replaces E-1960	All	Air Filter	E-1963
1995	4.0L V6	F/I	All	Air Filter	E-0995	1981	4.2L V8	2 BBL.	All	Air Filter	E-1180	1961	390 V8	3x2BBL.	All	Air Filter	E-1960
1995	4.0L V6	F/I	All	FIPK	57-2513-1	1980	140 L4	2 BBL.	All	Air Filter	E-1200	1961	390 V8	3x2BBL.	All	Air Filter	E-1960
1995	4.0L V6	F/I	OHV	Aircharger®	63-1044	1980	255 V8	2 BBL.	(D)	Oil Filter	HP-3001	1974	351 V8	2 BBL.	All	Air Filter	E-1300
1994	4.0L V6	F/I	(X)	Oil Filter	HP-3001	1980	255 V8	2 BBL.	All	Air Filter	E-1180	1974	400 V8	2 BBL.	All	Air Filter	E-1580
1994	4.0L V6	F/I	All	Air Filter	33-2024	1979	200 L6	2 BBL.	(T)	Oil Filter	HP-3001	1974	460 V8	4 BBL. exc. Police	All	Air Filter	E-1580
1993	4.0L V6	F/I	(X)	Oil Filter	HP-3001	1979	200 L6	2 BBL.	(T)	Oil Filter	HP-3001	1974	460 V8	4 BBL. Police only	All	Air Filter	E-1570
1993	4.0L V6	F/I	All	Air Filter	33-2024	1979	200 L6	2 BBL. w/ manual	All	Air Filter	E-1200	1973	351 V8	2 BBL. exc. Police	All	Air Filter	E-1300
1992	4.0L V6	F/I	(X)	Oil Filter	HP-3001	1979	200 L6	2 BBL. w/ auto.	All	Air Filter	E-1350	1973	351 V8	2 BBL. Police only	All	Air Filter	E-1570
1992	4.0L V6	F/I	All	Air Filter	33-2024	1979	230 L4	2 BBL.	All	Air Filter	E-1200	1973	351 V8	2 BBL. Police only	All	Air Filter	E-1570
1991	4.0L V6	F/I	(X)	Oil Filter	HP-3001	1979	230 L4	2 BBL.	All	Air Filter	E-1200	1973	400 V8	2 BBL.	All	Air Filter	E-1580
1991	4.0L V6	F/I	All	Air Filter	33-2024	1979	255 V8	2 BBL.	All	Air Filter	E-1180	1973	429 V8	4 BBL.	All	Air Filter	E-1580
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	200 L6	1 BBL.	(T)	Oil Filter	HP-3001	1973	429 V8	4 BBL.	All	Air Filter	E-1580
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	200 L6	1 BBL.	(T)	Oil Filter	HP-3001	1973	460 V8	4 BBL. exc. Police	All	Air Filter	E-1580
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	200 L6	1 BBL. w/ auto.	All	Air Filter	E-1350	1973	460 V8	4 BBL. Police only	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	200 L6	1 BBL. w/ manual	All	Air Filter	E-1200	1972	240 L6	1 BBL.	All	Air Filter	E-1200
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	230 L4	2 BBL.	All	Air Filter	E-1200	1972	302 V8	2 BBL.	All	Air Filter	E-1300
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	(F)	Oil Filter	HP-3001	1972	351 V8	2 BBL.	(W)	Air Filter	E-1300
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1972	351 V8	2 BBL. exc. 351 (W)	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1972	400 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1972	429 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1972	429 V8	4 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	240 L6	1 BBL.	All	Air Filter	E-1200
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	302 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	351 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	351 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	351 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	351 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	351 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	351 V8	2 BBL.	All	Air Filter	E-1570
1991	4.0L V6	F/I	All	Air Filter	33-2024	1978	302 V8	2 BBL.	All	Air Filter	E-1180	1971	351 V8	2 BBL			

Automotive Applications

(Galaxie 500 cont.)

FORD

YRS.	ENG.DISPL	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL	INTAKE	COMMENTS	PRODUCT	PART #
1971	390 V8	2 BBL.	All	Air Filter	E-1570	1975	250 L6	1 BBL.	All	Air Filter	E-1200	1976	330 V8		LTS600-800	Air Filter	E-1440
1971	400 V8	2 BBL.	All	Air Filter	E-1570	1975	302 V8	2 BBL.	(F)	Oil Filter	HP-3001	1976	330 V8		B500-750,	Air Filter	E-1440
1971	429 V8	4 BBL.	All	Air Filter	E-1570	1975	302 V8	2 BBL.	(W)	Air Filter	E-1300	1976	330 V8		C600-800	Air Filter	E-1440
1970	240 L6	1 BBL.	XL	Air Filter	E-1200	1975	351 V8	2 BBL.	(W)	Air Filter	E-1300	1976	330 V8		CT600-800	Air Filter	E-1440
1970	302 V8	2 BBL.	XL	Air Filter	E-1570	Heavy Duty Truck											
1970	390 V8	2 BBL.	All	Air Filter	E-1570	1980	370 V8		All	Air Filter	E-1430	1976	330 V8		F500-900	Air Filter	E-1440
1970	429 V8	4 BBL.	XL	Air Filter	E-1570	1979	330 V8		B500-750,	Air Filter	E-1440	1976	330 V8		LNT,LT,	Air Filter	E-1440
1969	240 L6	1 BBL.	w/ auto.	Air Filter	E-1030				C600-800			1976	389 V8		XD	Air Filter	E-1440
1969	240 L6	1 BBL.	w/manual	Air Filter	E-1200	1979	330 V8		CT600-800	Air Filter	E-1440	1976	389 V8		XD F600-750	Air Filter	E-1440
1969	302 V8	2 BBL.	All	Air Filter	E-1570	1979	330 V8		F500-900	Air Filter	E-1440	1976	389 V8		XD B600-750	Air Filter	E-1440
1969	428 V8	4 BBL.	All	Air Filter	E-1570	1979	330 V8		LNT,LT,	Air Filter	E-1440	1976	389 V8		XD C600-800	Air Filter	E-1440
1969	429 V8	4 BBL.	All	Air Filter	E-1570				LTS600-800			1976	389 V8		XD LNT,LT,	Air Filter	E-1440
1968	240 L6	1 BBL.	w/ auto.	Air Filter	E-1030	1979	370 V8		All	Air Filter	E-1430	1976	391 V8		LTS600-800	Air Filter	E-1440
1968	240 L6	1 BBL.	w/manual	Air Filter	E-1200	1979	475 V8		B600-750,	Air Filter	E-1440	1976	391 V8		HD B600-750,	Air Filter	E-1440
1968	302 V8	2 BBL.	All	Air Filter	E-1570				C600-800			1976	391 V8		C600-800	Air Filter	E-1440
1968	390 V8	4 BBL.	All	Air Filter	E-1570	1979	475 V8		CT600-800	Air Filter	E-1440	1976	391 V8		HD CT600-800	Air Filter	E-1440
1968	427 V8	4 BBL.	All	Air Filter	E-1560	1979	475 V8		F600-750	Air Filter	E-1440	1976	391 V8		HD F600-750	Air Filter	E-1440
1967	427 V8	2x4BBL.	All	Air Filter	E-1960	1979	475 V8		F880	Air Filter	E-1440	1976	391 V8		HD LNT,LT,	Air Filter	E-1440
1965	427 V8	2x4BBL.	All	Air Filter	E-1960	1979	475 V8		LNT,LT,	Air Filter	E-1440	1976	475 V8		LTS600-800	Air Filter	E-1440
Granada									LTS600-800			1976	475 V8		B600-750,	Air Filter	E-1440
1982	2.3L L4	2 BBL.	(A)	Oil Filter	HP-3001	1978	330 V8		B500-750,	Air Filter	E-1440	1976	475 V8		C600-800	Air Filter	E-1440
1982	2.3L L4	2 BBL.	All	Air Filter	E-1200				C600-800			1976	475 V8		CT600-800	Air Filter	E-1440
1982	3.3L L6	1 BBL.	(B)	Oil Filter	HP-3001	1978	330 V8		CT600-800	Air Filter	E-1440	1976	475 V8		F600-750	Air Filter	E-1440
1982	3.3L L6	1 BBL.	All	Air Filter	E-1350	1978	330 V8		F500-900	Air Filter	E-1440	1976	475 V8		F880	Air Filter	E-1440
1982	3.8L V6	2 BBL.	(3)	Oil Filter	HP-3001	1978	330 V8		LNT,LT,	Air Filter	E-1440	1976	475 V8		LNT,LT,	Air Filter	E-1440
1982	3.8L V6	2 BBL.	All	Air Filter	E-1325				LTS600-800			1976	475 V8		LTS600-800	Air Filter	E-1440
1982	4.2L V8	2 BBL.	All	Air Filter	E-1290	1978	389 V8		XD	Air Filter	E-1440	1975	475 V8		F880	Air Filter	E-1440
1981	2.3L L4	2 BBL.	(A)	Oil Filter	HP-3001	1978	389 V8		XD F600-750	Air Filter	E-1440	1974	475 V8		F880	Air Filter	E-1440
1981	2.3L L4	2 BBL.	All	Air Filter	E-1200	1978	389 V8		XD B600-750	Air Filter	E-1440	LTD					
1981	3.3L L6	1 BBL.	(B)	Oil Filter	HP-3001	1978	389 V8		XD C600-800	Air Filter	E-1440	1986	2.3L L4	1 BBL.	(A)	Oil Filter	HP-3001
1981	3.3L L6	1 BBL.	All	Air Filter	E-1350	1978	389 V8		XD LNT,LT,	Air Filter	E-1440	1986	2.3L L4	1 BBL.	All	Air Filter	E-1200
1981	4.2L V8	2 BBL.	(D)	Oil Filter	HP-3001	1978	389 V8		LTS600-800	Air Filter	E-1440	1986	3.8L V6	F/I	(3)	Oil Filter	HP-3001
1981	4.2L V8	2 BBL.	All	Air Filter	E-1180	1978	391 V8		HD B600-750,	Air Filter	E-1440	1986	3.8L V6	F/I	All	Air Filter	E-1325
1980	250 L6	1 BBL.	(C)	Oil Filter	HP-3001				C600-800	Air Filter	E-1440	1985	2.3L L4	1 BBL.	(A)	Oil Filter	HP-3001
1980	250 L6	1 BBL.	All	Air Filter	E-1200	1978	391 V8		HD CT600-800	Air Filter	E-1440	1985	2.3L L4	1 BBL.	All	Air Filter	E-1200
1980	255 V8	2 BBL.	(D)	Oil Filter	HP-3001	1978	391 V8		HD F600-750	Air Filter	E-1440	1985	3.8L V6	F/I	(3)	Oil Filter	HP-3001
1980	255 V8	2 BBL.	All	Air Filter	E-1290	1978	391 V8		HD LNT,LT,	Air Filter	E-1440	1985	3.8L V6	F/I	All	Air Filter	E-1325
1980	302 V8	2 BBL.	(F)	Oil Filter	HP-3001				LTS600-800	Air Filter	E-1440	1985	5.0L V8	F/I	(M) H.P.	Oil Filter	HP-3001
1980	302 V8	2 BBL.	All	Air Filter	E-1290	1978	475 V8		B600-750,	Air Filter	E-1440	1985	5.0L V8	F/I	All	Air Filter	E-1570
1979	200 L6	1 BBL.	All	Air Filter	E-1200				C600-800	Air Filter	E-1440	1984	2.3L L4	1 BBL.	(A)	Oil Filter	HP-3001
1979	250 L6	1 BBL.	(L)	Oil Filter	HP-3001	1978	475 V8		CT600-800	Air Filter	E-1440	1984	2.3L L4	1 BBL.	All	Air Filter	E-1200
1979	250 L6	1 BBL.	All	Air Filter	E-1200	1978	475 V8		F600-750	Air Filter	E-1440	1984	3.8L V6	2 BBL.	(C)	Oil Filter	HP-3001
1979	302 V8	2 BBL.	(F)	Oil Filter	HP-3001	1978	475 V8		F880	Air Filter	E-1440	1984	3.8L V6	2 BBL.	All	Air Filter	E-1325
1979	302 V8	2 BBL.	All	Air Filter	E-1290	1978	475 V8		LNT,LT,	Air Filter	E-1440	1984	3.8L V6	F/I	(3)	Oil Filter	HP-3001
1978	250 L6	1 BBL.	(L)	Oil Filter	HP-3001				LTS600-800	Air Filter	E-1440	1984	3.8L V6	F/I	All	Air Filter	E-1325
1978	250 L6	1 BBL.	All	Air Filter	E-1200	1977	330 V8		B500-750,	Air Filter	E-1440	1983	2.3L L4	1 BBL.	All	Air Filter	E-1200
1978	302 V8	2 BBL.	(F)	Oil Filter	HP-3001				C600-800	Air Filter	E-1440	1983	3.3L L6	1 BBL.	(X)	Oil Filter	HP-3001
1978	302 V8	2 BBL.	All	Air Filter	E-1290	1977	330 V8		CT600-800	Air Filter	E-1440	1983	3.3L L6	1 BBL.	All	Air Filter	E-1350
1977	200 L6	1 BBL.	(T)	Oil Filter	HP-3001	1977	330 V8		F500-900	Air Filter	E-1440	1983	3.8L V6	2 BBL.	(3)	Oil Filter	HP-3001
1977	200 L6	1 BBL.	All	Air Filter	E-1200	1977	330 V8		LNT,LT,LTS	Air Filter	E-1440	1983	3.8L V6	2 BBL.	All	Air Filter	E-1325
1977	250 L6	1 BBL.	(L)	Oil Filter	HP-3001				600-800	Air Filter	E-1440	1982	4.2L V8	2 BBL.	(D)	Oil Filter	HP-3001
1977	250 L6	1 BBL.	All	Air Filter	E-1200	1977	389 V8		XD	Air Filter	E-1440	1982	4.2L V8	2 BBL.	All	Air Filter	E-1290
1977	302 V8	2 BBL.	(F)	Oil Filter	HP-3001	1977	389 V8		XD F600-750	Air Filter	E-1440	1982	5.0L V8	2 BBL.	(F)	Oil Filter	HP-3001
1977	302 V8	2 BBL.	All	Air Filter	E-1180	1977	389 V8		XD B600-750	Air Filter	E-1440	1982	5.0L V8	2 BBL.	All	Air Filter	E-1290
1977	351 V8	2 BBL.	(H)	Oil Filter	HP-3001	1977	389 V8		XD C600-800	Air Filter	E-1440	1982	5.8L V8	2 BBL.	(G)	Oil Filter	HP-3001
1977	351 V8	2 BBL.	(W)	Air Filter	E-1290	1977	389 V8		XD LNT,LT,	Air Filter	E-1440	1982	5.8L V8	2 BBL.	All	Air Filter	E-1290
1976	200 L6	1 BBL.	(T)	Oil Filter	HP-3001				LTS600-800	Air Filter	E-1440	1981	4.2L V8	2 BBL.	(D)	Oil Filter	HP-3001
1976	200 L6	1 BBL.	All	Air Filter	E-1200	1977	391 V8		HD B600-750,	Air Filter	E-1440	1981	4.2L V8	2 BBL.	All	Air Filter	E-1290
1976	250 L6	1 BBL.	(L)	Oil Filter	HP-3001				C600-800	Air Filter	E-1440	1981	5.0L V8	2 BBL.	(F)	Oil Filter	HP-3001
1976	250 L6	1 BBL.	All	Air Filter	E-1200	1977	391 V8		HD CT600-800	Air Filter	E-1440	1981	5.0L V8	2 BBL.	All	Air Filter	E-1290
1976	302 V8	2 BBL.	(F)	Oil Filter	HP-3001	1977	391 V8		HD F600-750	Air Filter	E-1440	1981	5.8L V8	2 BBL.	(G)	Oil Filter	HP-3001
1976	302 V8	2 BBL.	(F)	Oil Filter	HP-3001	1977	391 V8		HD LNT,LT,	Air Filter	E-1440	1981	5.8L V8	2 BBL.	All	Air Filter	E-1290
1976	302 V8	2 BBL.	Early Prod.	Air Filter	E-1300	1977	391 V8		LTS600-800	Air Filter	E-1440	1980	302 V8	2 BBL.	(F)	Oil Filter	HP-3001
1976	302 V8	2 BBL.	Late Prod.	Air Filter	E-1180	1977	475 V8		B600-750,	Air Filter	E-1440	1980	302 V8	2 BBL.	All	Air Filter	E-1290
1976	351 V8	2 BBL.	(H)	Oil Filter	HP-3001				C600-800	Air Filter	E-1440	1980	351 V8	2 BBL.	(G)	Oil Filter	HP-3001
1976	351 V8	2 BBL.	(W)	Air Filter	E-1300	1977	475 V8		CT600-800	Air Filter	E-1440	1980	351 V8	2 BBL.	All		

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #
1979	302 V8 2 BBL.		All	Air Filter	E-1180	1971	351 V8 2 BBL.		All	Air Filter	E-1570	1994	5.9L V8 F/I	Class C	Air Filter	33-2023	
1979	302 V8 2 BBL.		All	Air Filter	E-1290	1971	390 V8 2 BBL.		All	Air Filter	E-1570	1994	7.5L V8 F/I	Class C	Air Filter	33-2023	
1979	302 V8 2 BBL.		All	Air Filter	E-1290	1971	400 V8 2 BBL.		All	Air Filter	E-1570	1993	4.9L L6 F/I	Class C	Air Filter	33-2023	
1979	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	1971	429 V8 2 BBL.		All	Air Filter	E-1570	1993	5.0L V8 F/I	Class C	Air Filter	33-2023	
1979	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	1971	429 V8 4 BBL.		All	Air Filter	E-1570	1993	5.9L V8 F/I	Class C	Air Filter	33-2023	
1979	351 V8 2 BBL.		All	Air Filter	E-1290	1970	240 L6 1 BBL.		All	Air Filter	E-1200	1993	7.3L V8 DSL	Class C	Air Filter	E-1461	
1979	351 V8 2 BBL.		All	Air Filter	E-1290	1970	302 V8 2 BBL.		All	Air Filter	E-1570	1993	7.5L V8 F/I	Class C	Air Filter	33-2023	
1978	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	1970	429 V8 2 BBL.		All	Air Filter	E-1570	1992	4.9L L6 F/I	Class C	Air Filter	33-2023	
1978	302 V8 2 BBL.		All	Air Filter	E-1290	1970	429 V8 4 BBL.		All	Air Filter	E-1570	1992	5.0L V8 F/I	Class C	Air Filter	33-2023	
1978	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	Maverick						1992	5.9L V8 F/I	Class C	Air Filter	33-2023	
1978	351 V8 2 BBL.		All	Air Filter	E-1290	1977	200 L6 1 BBL.	(T)		Oil Filter	HP-3001	1992	7.3L V8 DSL	Class C	Air Filter	E-1461	
1978	400 V8 2 BBL.	(S)		Oil Filter	HP-3001	1977	200 L6 1 BBL.		All	Air Filter	E-1200	1992	7.5L V8 F/I	Class C	Air Filter	33-2023	
1978	400 V8 2 BBL.		All	Air Filter	E-1290	1977	250 L6 1 BBL.	(L)		Oil Filter	HP-3001	1991	4.9L L6 F/I	Class C	Air Filter	33-2023	
1978	460 V8 4 BBL.	(A)		Oil Filter	HP-3001	1977	250 L6 1 BBL.		All	Air Filter	E-1200	1991	5.0L V8 F/I	Class C	Air Filter	33-2023	
1978	460 V8 4 BBL.	(C)		Oil Filter	HP-3001	1977	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	1991	5.9L V8 F/I	Class C	Air Filter	33-2023	
1978	460 V8 4 BBL.	All exc.Police	Air Filter	E-1580	1977	302 V8 2 BBL.		All	Air Filter	E-1180	1991	7.3L V8 DSL	Class C	Air Filter	E-1460		
1978	460 V8 4 BBL.	All Police only	Air Filter	E-1570	1976	200 L6 1 BBL.	(T)		Oil Filter	HP-3001	1991	7.5L V8 F/I	Class C	Air Filter	33-2023		
1977	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	1976	200 L6 1 BBL.		All	Air Filter	E-1200	1990	4.9L L6 F/I	Class C	Air Filter	33-2023	
1977	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	1976	250 L6 1 BBL.	(L)		Oil Filter	HP-3001	1990	5.0L V8 F/I	Class C	Air Filter	33-2023	
1977	302 V8 2 BBL.		All	Air Filter	E-1180	1976	250 L6 1 BBL.		All	Air Filter	E-1200	1990	5.9L V8 F/I	Class C	Air Filter	33-2023	
1977	302 V8 2 BBL.		All	Air Filter	E-1180	1976	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	1990	7.3L V8 DSL	Class C	Air Filter	E-1460	
1977	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	1976	302 V8 2 BBL.		All	Air Filter	E-1300	1990	7.5L V8 F/I	Class C	Air Filter	33-2023	
1977	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	1975	200 L6 1 BBL.	(T)		Oil Filter	HP-3001	1989	4.9L L6 F/I	Class C	Air Filter	33-2023	
1977	351 V8 2 BBL.		All	Air Filter	E-1290	1975	200 L6 1 BBL.		All	Air Filter	E-1200	1989	5.0L V8 F/I	Class C	Air Filter	33-2023	
1977	351 V8 2 BBL.	M		Air Filter	E-1290	1975	250 L6 1 BBL.	(L)		Oil Filter	HP-3001	1989	5.9L V8 F/I	Class C	Air Filter	33-2023	
1977	400 V8 2 BBL.	(S)		Oil Filter	HP-3001	1975	250 L6 1 BBL.		All	Air Filter	E-1200	1989	7.3L V8 DSL	Class C	Air Filter	E-1460	
1977	400 V8 2 BBL.		All	Air Filter	E-1290	1975	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	1989	7.5L V8 F/I	Class C	Air Filter	33-2023	
1977	400 V8 4 BBL.	(R)		Oil Filter	HP-3001	1975	302 V8 2 BBL.		All	Air Filter	E-1300	1988	4.9L L6 F/I	Class C	Air Filter	33-2023	
1977	400 V8 4 BBL.		All	Air Filter	E-1290	1974	200 L6 1 BBL.	(T)		Oil Filter	HP-3001	1988	5.0L V8 F/I	Class C	Air Filter	33-2023	
1977	460 V8 4 BBL.	(A)		Oil Filter	HP-3001	1974	200 L6 1 BBL.		All	Air Filter	E-1200	1988	5.9L V8 F/I	Class C	Air Filter	33-2023	
1977	460 V8 4 BBL.	(C)		Oil Filter	HP-3001	1974	250 L6 1 BBL.	(L)		Oil Filter	HP-3001	1988	7.3L V8 DSL	Class C	Air Filter	E-1460	
1977	460 V8 4 BBL.	exc.Police	Air Filter	E-1580	1974	250 L6 1 BBL.		All	Air Filter	E-1350	1988	7.5L V8 F/I	Class C	Air Filter	33-2023		
1977	460 V8 4 BBL.	Police only	Air Filter	E-1570	1974	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	1987	4.9L L6 F/I	Class C	Air Filter	33-2023		
1976	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	1974	302 V8 2 BBL.		All	Air Filter	E-1300	1987	5.0L V8 F/I	Class C	Air Filter	33-2023	
1976	351 V8 2 BBL.	M		Air Filter	E-1300	1973	200 L6 1 BBL.	(T)		Oil Filter	HP-3001	1987	5.9L V8 4 BBL.	Class C	Air Filter	E-1570	
1976	400 V8 2 BBL.	(S)		Oil Filter	HP-3001	1973	200 L6 1 BBL.		All	Air Filter	E-1200	1987	5.9L V8 F/I	Class C	Air Filter	33-2023	
1976	400 V8 2 BBL.		All	Air Filter	E-1300	1973	250 L6 1 BBL.	(L)		Oil Filter	HP-3001	1987	6.9L V8 DSL	Class C	Air Filter	E-1460	
1976	460 V8 4 BBL.	(A)		Oil Filter	HP-3001	1973	250 L6 1 BBL.		All	Air Filter	E-1350	1987	7.5L V8 F/I	Class C	Air Filter	33-2023	
1976	460 V8 4 BBL.	(C)		Oil Filter	HP-3001	1973	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	1986	4.9L L6 1 BBL.	Class C	Air Filter	E-1040	
1976	460 V8 4 BBL.	exc.Police	Air Filter	E-1580	1973	302 V8 2 BBL.		All	Air Filter	E-1300	1986	5.0L V8 2 BBL.	Class C	Air Filter	33-2012		
1976	460 V8 4 BBL.	Police only	Air Filter	E-1570	1972	170 L6 1 BBL.		All	Air Filter	E-1200	1986	5.9L V8 2 BBL.	Class C	Air Filter	E-1290		
1975	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	1972	170 L6 1 BBL.		All	Oil Filter	HP-3001	1986	5.9L V8 4 BBL.	Class C	Air Filter	E-1570	
1975	351 V8 2 BBL.	M		Air Filter	E-1300	1972	200 L6 1 BBL.		All	Air Filter	E-1200	1986	6.9L V8 DSL	Class C	Air Filter	E-1460	
1975	400 V8 2 BBL.	(S)		Oil Filter	HP-3001	1972	200 L6 1 BBL.		All	Oil Filter	HP-3001	1985	4.9L L6 1 BBL.	Class C	Air Filter	E-1040	
1975	400 V8 2 BBL.		All	Air Filter	E-1580	1972	250 L6 1 BBL.		All	Air Filter	E-1350	1985	5.0L V8 2 BBL.	Class C	Air Filter	E-1290	
1975	460 V8 4 BBL.	exc.Police	Air Filter	E-1580	1972	250 L6 1 BBL.		All	Oil Filter	HP-3001	1985	5.9L V8 2 BBL.	Class C	Air Filter	E-1290		
1975	460 V8 4 BBL.	Police only	Air Filter	E-1570	1972	302 V8 2 BBL.		All	Air Filter	E-1300	1985	5.9L V8 4 BBL.	Class C	Air Filter	E-1570		
1973	250 L6 1 BBL.		All	Air Filter	E-1350	1972	302 V8 2 BBL.		All	Oil Filter	HP-3001	1985	6.9L V8 DSL	Class C	Air Filter	E-1460	
1973	302 V8 2 BBL.		All	Air Filter	E-1300	1971	170 L6 1 BBL.		All	Air Filter	E-1200	1984	4.9L L6 1 BBL.	Class C	Air Filter	E-1040	
1973	351 V8 2 BBL.	(C) exc.Police	Air Filter	E-1300	1971	170 L6 1 BBL.		All	Oil Filter	HP-3001	1984	5.0L V8 2 BBL.	Class C	Air Filter	E-1290		
1973	351 V8 2 BBL.	(W) exc.Police	Air Filter	E-1300	1971	200 L6 1 BBL.		All	Air Filter	E-1200	1984	5.9L V8 2 BBL.	Class C	Air Filter	E-1290		
1973	351 V8 2 BBL.	(W) Police only	Air Filter	E-1570	1971	200 L6 1 BBL.		All	Oil Filter	HP-3001	1984	5.9L V8 4 BBL.	Class C	Air Filter	E-1570		
1973	351 V8 4 BBL.	(C) Police only	Air Filter	E-1570	1971	250 L6 1 BBL.		All	Air Filter	E-1350	1984	6.9L V8 DSL	Class C	Air Filter	E-1460		
1973	400 V8 2 BBL.	exc.Police	Air Filter	E-1580	1971	250 L6 1 BBL.		All	Oil Filter	HP-3001	1983	4.9L L6 1 BBL.	Class C	Air Filter	E-1040		
1973	400 V8 4 BBL.	Police only	Air Filter	E-1570	1971	302 V8 2 BBL.		All	Air Filter	E-1570	1983	5.0L V8 2 BBL.	Class C	Air Filter	E-1290		
1973	429 V8 4 BBL.	exc.Police	Air Filter	E-1580	1971	302 V8 2 BBL.		All	Oil Filter	HP-3001	1983	5.9L V8 2 BBL.	Class C	Air Filter	E-1290		
1973	429 V8 4 BBL.	Police only	Air Filter	E-1570	1970	170 L6 1 BBL.		All	Air Filter	E-1200	1983	5.9L V8 4 BBL.	Class C	Air Filter	E-1570		
1973	460 V8 4 BBL.	exc.Police	Air Filter	E-1580	1970	170 L6 1 BBL.		All	Oil Filter	HP-3001	1983	6.6L V8 2 BBL.	Class C	Air Filter	E-1290		
1973	460 V8 4 BBL.	Police only	Air Filter	E-1570	1970	200 L6 1 BBL.		All	Air Filter	E-1200	1983	6.9L V8 DSL	Class C	Air Filter	E-1460		
1972	240 L6 1 BBL.		All	Air Filter	E-1200	1970	200 L6 1 BBL.		All	Oil Filter	HP-3001	1982	4.9L L6 1 BBL.	Class C	Air Filter	E-1040	
1972	302 V8 2 BBL.		All	Air Filter	E-1300	1970	250 L6 1 BBL.		All	Air Filter	E-1350	1982	5.9L V8 2 BBL.	Class C	Air Filter	E-1290	
1972	351 V8 2 BBL.	(W)		Air Filter	E-1300	1969	170 L6 1 BBL.		All	Air Filter	E-1200	1982	5.9L V8 4 BBL.	Class C	Air Filter	E-1570	
1972	351 V8 2 BBL.	exc. W		Air Filter	E-1570	Motor Home						1982	6.6L V8 2 BBL.	Class C	Air Filter	E-1290	
1972	390 V10 2 BBL.		All	Air Filter	E-1570	1995	4.9L L6 F/I	Class C		Air Filter	33-2023	1981	4.9L L6 1 BBL.	Class C	Air Filter	E-1040	
1972	400 V8 2 BBL.		All	Air Filter	E-1570	1995	5.0L V8 F/I	Class C		Air Filter	33-2023	1981	5.0L V8 2 BBL.	Class C	Air Filter	E-1290	
1972	429 V8 2 BBL.		All	Air Filter	E-1570	1995	5.9L V8 F/I	Class C		Air Filter	33-2023	1981	5.9L V8 2 BBL.	Class C	Air Filter	E-1290	
1972	429 V8 4 BBL.		All	Air Filter	E-1570	1995	7.5L V8 F/I	Class C		Air Filter	33-2023						
1971	240 L6 1 BBL.		All	Air Filter	E-1200	1994	4.9L L6 F/I	Class C		Air Filter	33-2023						
1971	302 V8 2 BBL.		All	Air Filter	E-1570	1994	5.0L V8 F/I	Class C		Air Filter	33-2023						

Automotive Applications

(Motor Home cont.)

FORD

YRS.	ENG.DISPL. INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL. INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL. INTAKE	COMMENTS	PRODUCT	PART #
1981	6.6L V8 2 BBL.	Class C	Air Filter	E-1290	2001	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1991	5.0L V8 F/I	(E)	Oil Filter	HP-3001
1980	4.9L L6 1 BBL.	Class C	Air Filter	E-1040	2001	3.8L V6 F/I	All	Air Filter	E-0940	1991	5.0L V8 F/I	All	Air Filter	33-2015
1980	5.0L V8 2 BBL.	Class C	Air Filter	E-1290	2001	3.8L V6 F/I	All	Aircharger®	63-1031	1991	5.0L V8 F/I	All	FIPK	57-2502
1980	5.9L V8 2 BBL.	Class C	Air Filter	E-1290	2001	4.6L V8 F/I	(V,X)	Oil Filter	HP-2010	1990	2.3L L4 F/I	(A)	Oil Filter	HP-3001
1980	6.6L V8 2 BBL.	Class C	Air Filter	E-1290	2001	4.6L V8 F/I	All	Air Filter	E-0945	1990	2.3L L4 F/I	All	Air Filter	33-2044
1980	7.7L V8 4 BBL.	Class C	Air Filter	E-1570	2001	4.6L V8 F/I	Cobra DOHC	FIPK	57-2523-2	1990	5.0L V8 F/I	(E)	Oil Filter	HP-3001
1979	300 L6 1 BBL.	Class C	Air Filter	E-1040	2001	4.6L V8 F/I	GT, Cobra	Aircharger®	63-1008	1990	5.0L V8 F/I	All	Air Filter	33-2015
1979	302 V8 2 BBL.	Class C	Air Filter	E-1290	2001	4.6L V8 F/I	GT, exc. Bullet	FIPK	57-2519-3	1990	5.0L V8 F/I	All	FIPK	57-2502
1979	360 V8 2 BBL.	Class C	Air Filter	E-1290	2000	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1989	2.3L L4 F/I	(A)	Oil Filter	HP-3001
1979	400 V8 4 BBL.	Class C	Air Filter	E-1290	2000	3.8L V6 F/I	All	Air Filter	E-0940	1989	2.3L L4 F/I	All	Air Filter	33-2044
1979	400 V8 4 BBL.	Class C	Air Filter	E-1290	2000	3.8L V6 F/I	All	Aircharger®	63-1031	1989	5.0L V8 F/I	(E)	Oil Filter	HP-3001
1979	460 V8 4 BBL.	Class C	Air Filter	E-1570	2000	4.6L V8 F/I	(V,X)	Oil Filter	HP-2010	1989	5.0L V8 F/I	All	Air Filter	33-2015
1978	300 L6 1 BBL.	Class C	Air Filter	E-1040	2000	4.6L V8 F/I	All	Air Filter	E-0945	1989	5.0L V8 F/I	All	FIPK	57-2502
1978	302 V8 2 BBL.	Class C	Air Filter	E-1290	2000	4.6L V8 F/I	GT	Aircharger®	63-1008	1988	2.3L L4 F/I	(A)	Oil Filter	HP-3001
1978	351 V8 2 BBL.	Class C	Air Filter	E-1290	2000	4.6L V8 F/I	GT	FIPK	57-2519-3	1988	2.3L L4 F/I	All	Air Filter	33-2044
1978	460 V8 4 BBL.	Class C	Air Filter	E-1570	1999	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1988	5.0L V8 F/I	(E)	Oil Filter	HP-3001
1977	300 L6 1 BBL.	Class C	Air Filter	E-1040	1999	3.8L V6 F/I	All	Air Filter	E-0940	1988	5.0L V8 F/I	(E)	Oil Filter	HP-3001
1977	302 V8 2 BBL.	Class C	Air Filter	E-1290	1999	3.8L V6 F/I	All	Aircharger®	63-1031	1988	5.0L V8 F/I	w/mass air	Air Filter	33-2015
1977	360 V8 2 BBL.	Class C	Air Filter	E-1290	1999	4.6L V8 F/I	(V,X)	Oil Filter	HP-2010	1988	5.0L V8 F/I	w/mass air	FIPK	57-2502
1977	460 V8 4 BBL.	Class C	Air Filter	E-1580	1999	4.6L V8 F/I	All	Air Filter	E-0945	1988	5.0L V8 F/I	w/o mass air	Air Filter	33-2015
1976	300 L6 1 BBL.	Class C	Air Filter	E-1040	1999	4.6L V8 F/I	Cobra DOHC	FIPK	57-2523-2	1988	5.0L V8 F/I	w/o mass air	FIPK	57-2501
1976	302 V8 2 BBL.	Class C	Air Filter	E-1300	1999	4.6L V8 F/I	GT	FIPK	57-2519-3	1987	2.3L L4 F/I	(A)	Oil Filter	HP-3001
1976	360 V8 2 BBL.	Class C	Air Filter	E-1290	1999	4.6L V8 F/I	GT, Cobra	Aircharger®	63-1008	1987	2.3L L4 F/I	All	Air Filter	33-2044
1976	460 V8 4 BBL.	Class C	Air Filter	E-1570	1998	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1987	5.0L V8 F/I	(E) H.P.	Oil Filter	HP-3001
1975	300 L6 1 BBL.	Class C	Air Filter	E-1040	1998	3.8L V6 F/I	All	Air Filter	E-0940	1987	5.0L V8 F/I	All	Air Filter	33-2015
1975	302 V8 2 BBL.	Class C	Air Filter	E-1300	1998	4.6L V8 F/I	(V,X)	Oil Filter	HP-2010	1987	5.0L V8 F/I	All	FIPK	57-2501
1975	351 V8 2 BBL.	Class C	Air Filter	E-1290	1998	4.6L V8 F/I	All	Air Filter	E-0945	1986	2.3L L4 1 BBL.	(A)	Oil Filter	HP-3001
1975	460 V8 4 BBL.	Class C	Air Filter	E-1570	1998	4.6L V8 F/I	Cobra DOHC	FIPK	57-2523-2	1986	2.3L L4 1 BBL.	All	Air Filter	E-1200
1974	240 L6 1 BBL.	Class C	Air Filter	E-1200	1998	4.6L V8 F/I	GT	FIPK	57-2519-3	1986	2.3L L4 F/I	(T) Turbo	Oil Filter	HP-2004
1974	300 L6 1 BBL.	Class C	Air Filter	E-1040	1998	4.6L V8 F/I	GT, Cobra	Aircharger®	63-1008	1986	2.3L L4 F/I	Turbo	Air Filter	E-1931
1974	302 V8 2 BBL.	Class C	Air Filter	E-1300	1997	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1986	3.8L V6 F/I	(3)	Oil Filter	HP-3001
1973	240 L6 1 BBL.	Class C	Air Filter	E-1200	1997	3.8L V6 F/I	All	Air Filter	E-0940	1986	3.8L V6 F/I	All	Air Filter	E-1325
1973	300 L6 1 BBL.	Class C	Air Filter	E-1040	1997	4.6L V8 F/I	(V,X)	Oil Filter	HP-2010	1986	5.0L V8 F/I	(M) H.P.	Oil Filter	HP-3001
1973	302 V8 2 BBL.	Class C	Air Filter	E-1300	1997	4.6L V8 F/I	All	Air Filter	E-0945	1986	5.0L V8 F/I	All	Air Filter	33-2015
1972	240 L6 1 BBL.	Class C	Air Filter	E-1040	1997	4.6L V8 F/I	Cobra DOHC	FIPK	57-2523-2	1986	5.0L V8 F/I	All	FIPK	57-2501
1972	302 V8 2 BBL.	Class C	Air Filter	E-1040	1997	4.6L V8 F/I	GT	FIPK	57-2519-3	1985	2.3L L4 1 BBL.	(A)	Oil Filter	HP-3001
1971	240 L6 1 BBL.	Class C	Air Filter	E-1040	1997	4.6L V8 F/I	GT, Cobra	Aircharger®	63-1008	1985	2.3L L4 1 BBL.	All	Air Filter	E-1200
1971	302 V8 2 BBL.	Class C	Air Filter	E-1040	1996	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1985	2.3L L4 F/I	(T) Turbo	Oil Filter	HP-2004
1970	170 L6 1 BBL.	Class C	Air Filter	E-1040	1996	3.8L V6 F/I	All	Air Filter	E-0940	1985	2.3L L4 F/I	Turbo	Air Filter	E-1931
1970	240 L6 1 BBL.	Class C	Air Filter	E-1040	1996	4.6L V8 F/I	(V,X)	Oil Filter	HP-2010	1985	3.8L V6 F/I	(3)	Oil Filter	HP-3001
1970	302 V8 2 BBL.	Class C	Air Filter	E-1040	1996	4.6L V8 F/I	All	Air Filter	E-0945	1985	3.8L V6 F/I	All	Air Filter	E-1325
1970	302 V8 4 BBL.	Class C	Air Filter	E-1040	1996	4.6L V8 F/I	Cobra DOHC	FIPK	57-2523-2	1985	5.0L V8 4 BBL.	(M) H.P.	Oil Filter	HP-3001
1969	240 L6 1 BBL.	Class C	Air Filter	E-1040	1996	4.6L V8 F/I	GT	FIPK	57-2519-3	1985	5.0L V8 4 BBL.	All	Air Filter	E-1535
1969	300 L6 1 BBL.	Class C	Air Filter	E-1040	1996	4.6L V8 F/I	GT, Cobra	Aircharger®	63-1008	1984	2.3L L4 1 BBL.	(A)	Oil Filter	HP-3001
1969	302 V8 2 BBL.	Class C	Air Filter	E-1040	1995	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1984	2.3L L4 1 BBL.	All	Air Filter	E-1200
1968	240 L6 1 BBL.	Class C	Air Filter	E-1040	1995	3.8L V6 F/I	All	Air Filter	E-0940	1984	2.3L L4 F/I	(T,W) Turbo	Oil Filter	HP-2004
1968	300 L6 1 BBL.	Class C	Air Filter	E-1040	1995	5.0L V8 F/I	(D)	Oil Filter	HP-2004	1984	2.3L L4 F/I	Turbo	Air Filter	E-1931
1968	302 V8 2 BBL.	Class C	Air Filter	E-1040	1995	5.0L V8 F/I	(T)	Oil Filter	HP-3001	1984	3.8L V6 F/I	(3)	Oil Filter	HP-3001
1967	240 L6 1 BBL.	Class C	Air Filter	E-1080	1995	5.0L V8 F/I	All	Air Filter	E-0940	1984	3.8L V6 F/I	All	Air Filter	E-1325
1966	240 L6 1 BBL.	Class C	Air Filter	E-1080	1995	5.0L V8 F/I	All	FIPK	57-2511	1984	5.0L V8 4 BBL.	(M)	Oil Filter	HP-2004
1965	200 L6 2 BBL.	Class C	Air Filter	E-1080	1995	5.8L V8 F/I	Cobra R	Air Filter	E-0945	1984	5.0L V8 4 BBL.	All	Air Filter	E-1535
1964	200 L6 2 BBL.	Class C	Air Filter	E-1080	1994	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1983	2.3L L4 1 BBL.	All	Air Filter	E-1200
1963	200 L6 2 BBL.	Class C	Air Filter	E-1080	1994	3.8L V6 F/I	All	Air Filter	E-0940	1983	2.3L L4 F/I	(W) Turbo	Oil Filter	HP-2004
Mustang					1994	5.0L V8 F/I	(D)	Oil Filter	HP-2004	1983	2.3L L4 F/I	Turbo	Air Filter	E-1931
2003	3.8L V6 F/I	All	Air Filter	E-0940	1994	5.0L V8 F/I	(T)	Oil Filter	HP-3001	1983	3.8L V6 2 BBL.	(3)	Oil Filter	HP-3001
2003	4.6L V8 F/I	SOHC, inc Cobra DOHC	Air Filter	E-0945	1994	5.0L V8 F/I	All	Air Filter	E-0940	1983	3.8L V6 2 BBL.	All	Air Filter	E-1325
2003	4.6L V8 F/I	(W), DOHC Mach 1	Oil Filter	HP-2010	1994	5.0L V8 F/I	All	FIPK	57-2511	1983	5.0L V8 4 BBL.	(F)	Oil Filter	HP-3001
2003	4.6L V8 F/I	(X),SOHC,GT	Oil Filter	HP-2010	1993	2.3L L4 F/I	(M)	Oil Filter	HP-3001	1983	5.0L V8 4 BBL.	All	Air Filter	E-1535
2003	4.6L V8 F/I	(Y), Cobra (S.C.)	Oil Filter	HP-2010	1993	2.3L L4 F/I	All	Air Filter	33-2044	1982	2.3L L4 2 BBL.	(A)	Oil Filter	HP-3001
2003	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1993	5.0L V8 F/I	(D,E)	Oil Filter	HP-3001	1982	2.3L L4 2 BBL.	All	Air Filter	E-1200
2002	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1993	5.0L V8 F/I	All	Air Filter	33-2015	1982	3.3L L6 1 BBL.	(B)	Oil Filter	HP-3001
2002	3.8L V6 F/I	All	Air Filter	E-0940	1993	5.0L V8 F/I	All	FIPK	57-2502	1982	3.3L L6 1 BBL.	All	Air Filter	E-1350
2002	4.6L V8 F/I	(V), (W)	Oil Filter	HP-2010	1992	2.3L L4 F/I	(M)	Oil Filter	HP-3001	1982	4.2L V8 2 BBL.	(D)	Oil Filter	HP-3001
2002	4.6L V8 F/I	All	Air Filter	E-0945	1992	2.3L L4 F/I	All	Air Filter	33-2044	1982	4.2L V8 2 BBL.	All	Air Filter	E-1180
2002	4.6L V8 F/I	GT	Aircharger®	63-1008	1992	5.0L V8 F/I	(E)	Oil Filter	HP-3001	1982	5.0L V8 2 BBL.	(F)	Oil Filter	HP-3001
2002	4.6L V8 F/I	GT	FIPK	57-2519-3	1992	5.0L V8 F/I	All	Air Filter	33-2015	1982	5.0L V8 2 BBL.	All	Air Filter	E-1290
2002	4.6L V8 F/I	GT	FIPK	57-2519-3	1992	5.0L V8 F/I	All	FIPK	57-2502	1981	2.3L L4 2 BBL.	(A)	Oil Filter	HP-3001
2002	4.6L V8 F/I	GT	FIPK	57-2519-3	1991	2.3L L4 F/I	(M)	Oil Filter	HP-3001	1981	2.3L L4 2 BBL.	All	Air Filter	E-1200
2002	4.6L V8 F/I	GT	FIPK	57-2519-3	1991	2.3L L4 F/I	All	Air Filter	33-2044	1981	3.3L V8 1 BBL.	(B)	Oil Filter	HP-3001

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #			
1981	3.3L	V8	1 BBL.	All	Air Filter	E-1350	1970	351	V8	2 BBL.	All	Oil Filter	HP-3001	2002	7.3L	V8	DSL	All	Air Filter	33-2248
1981	4.2L	V8	2 BBL.	(D)	Oil Filter	HP-3001	1970	351	V8	4 BBL.	All	Oil Filter	HP-3001	2002	7.3L	V8	DSL	Turbo	Aircharger®	63-1024
1981	4.2L	V8	2 BBL.	All	Air Filter	E-1180	1970	351	V8	4 BBL.	All	Oil Filter	HP-3001	2001	4.2L	V6	F/I (2),	F Series	Oil Filter	HP-2009
1980	140	L4	2 BBL.	All	Air Filter	E-1200	1970	351	V8	4 BBL. w/Ram air	Air Filter	E-1580	2001	4.2L	V6	F/I	All	Air Filter	E-0945	
1980	199	L6	1 BBL.	All	Air Filter	E-1350	1970	351	V8	4 BBL. w/o Ram air	Air Filter	E-1570	2001	4.6L	V8	F/I (6W),	F Series	Oil Filter	HP-2010	
1980	255	V8	2 BBL.	(D)	Oil Filter	HP-3001	1970	428	V8	4 BBL. All, CJ	Oil Filter	HP-3001	2001	4.6L	V8	F/I	All	Air Filter	E-0945	
1980	255	V8	2 BBL.	All	Air Filter	E-1180	1970	428	V8	4 BBL.	CJ	Air Filter	E-1560	2001	4.6L	V8	F/I	F Series	FIPK	57-2514-4
1979	230	L4	2 BBL.	All	Air Filter	E-1200	1970	429	V8	4 BBL. All, CJ	Oil Filter	HP-3001	2001	5.4L	V8	F/I (3,L,M,Z),	Oil Filter	HP-2010		
1979	280	V6	2 BBL.	All	Air Filter	E-1280	1970	429	V8	4 BBL.	CJ	Air Filter	E-1560	2001	5.4L	V8	F/I exc. Lightning	Air Filter	E-0945	
1979	302	V8	2 BBL.	(F)	Oil Filter	HP-3001	1969	200	L6	1 BBL.	All	Air Filter	E-1030	2001	5.4L	V8	F/I (S/C)	Exc. Super	FIPK	57-2514-4
1979	302	V8	2 BBL.	All	Air Filter	E-1180	1969	200	L6	1 BBL.	All	Oil Filter	HP-3001	2001	5.4L	V8	F/I	F Series	FIPK	57-2525-2
1978	230	L4	2 BBL.	All	Air Filter	E-1200	1969	250	L6	1 BBL.	All	Air Filter	E-1350	2001	5.4L	V8	F/I	Super Duty		
1978	280	V6	2 BBL.	All	Air Filter	E-1280	1969	250	L6	1 BBL.	All	Oil Filter	HP-3001	2001	5.4L	V8	F/I	Lightning	Air Filter	33-2140-1
1978	302	V8	2 BBL.	(F)	Oil Filter	HP-3001	1969	302	V8	2 BBL.	All	Air Filter	E-1570	2001	6.8L	V10	F/I (S),	Super Duty	Oil Filter	HP-2010
1978	302	V8	2 BBL.	All	Air Filter	E-1180	1969	302	V8	2 BBL.	All	Oil Filter	HP-3001	2001	6.8L	V10	F/I	All	Air Filter	E-0945
1977	230	L4	2 BBL.	All	Air Filter	E-1200	1969	351	V8	2 BBL.	All	Air Filter	E-1570	2001	6.8L	V10	F/I	F Series	FIPK	57-2524-2
1977	280	V6	2 BBL.	All	Air Filter	E-1280	1969	351	V8	2 BBL.	All	Oil Filter	HP-3001	2001	7.3L	V8	DSL (F),	Super Duty	Oil Filter	HP-6001
1977	302	V8	2 BBL.	(F)	Oil Filter	HP-3001	1969	390	V8	4 BBL.	All	Air Filter	E-1570	2001	7.3L	V8	DSL	All	Air Filter	33-2248
1977	302	V8	2 BBL.	All	Air Filter	E-1180	1969	390	V8	4 BBL.	All	Oil Filter	HP-3001	2001	7.3L	V8	DSL	Turbo	Aircharger®	63-1024
1976	230	L4	2 BBL.	All	Air Filter	E-1200	1969	428	V8	4 BBL. Cobra Jet	Air Filter	E-1560	2000	4.2L	V6	F/I (2)	Oil Filter	HP-2009		
1976	280	V6	2 BBL.	All	Air Filter	E-1350	1968	200	L6	1 BBL.	All	Air Filter	E-1030	2000	4.2L	V6	F/I	F Series	Air Filter	E-0945
1976	302	V8	2 BBL.	(F)	Oil Filter	HP-3001	1968	200	L6	1 BBL.	All	Oil Filter	HP-3001	2000	4.6L	V8	F/I (6W)	Oil Filter	HP-2010	
1976	302	V8	2 BBL.	All	Air Filter	E-1550	1968	289	V8	2 BBL.	All	Oil Filter	HP-3001	2000	4.6L	V8	F/I	All	Air Filter	E-0945
1975	230	L4	2 BBL.	All	Air Filter	E-1200	1968	289	V8	2 BBL. Hi-Perf.	Air Filter	E-1560	2000	4.6L	V8	F/I	All	FIPK	57-2514-4	
1975	280	V6	2 BBL.	All	Air Filter	E-1350	1968	302	V8	4 BBL.	All	Air Filter	E-1570	2000	5.4L	V8	F/I (3,L,M,Z)	Oil Filter	HP-2010	
1975	302	V8	2 BBL.	(F) exc. cart. type	Oil Filter	HP-3001	1968	302	V8	4 BBL. exc. GT	Oil Filter	HP-3001	2000	5.4L	V8	F/I exc. Lightning	Air Filter	E-0945		
1975	302	V8	2 BBL.	All	Air Filter	E-1550	Pickup Full Size						2000	5.4L	V8	F/I exc. Super	FIPK	57-2514-4		
1974	230	L4	2 BBL.	All	Air Filter	E-1200	2003	4.2L	V6	F/I	All	Air Filter	E-0945	2000	5.4L	V8	F/I	Super Duty		
1974	280	V6	2 BBL.	All	Air Filter	E-1350	2003	4.2L	V6	F/I	F Series, (2)	Oil Filter	HP-2009	2000	6.8L	V10	F/I (S)	Oil Filter	HP-2010	
1973	250	L6	1 BBL.	(L)	Oil Filter	HP-3001	2003	4.6L	V8	F/I	All	Air Filter	E-0945	2000	6.8L	V10	F/I	All	Air Filter	E-0945
1973	250	L6	1 BBL.	All	Air Filter	E-1350	2003	4.6L	V8	F/I	F Series, (6W)	Oil Filter	HP-2010	2000	6.8L	V10	F/I	F Series	FIPK	57-2524-2
1973	351	V8	4 BBL.	(C)			2003	5.4L	V8	F/I	Lightning	Air Filter	33-2140-1	2000	7.3L	V8	DSL (F),	Super Duty	Oil Filter	HP-6001
							2003	5.4L	V8	F/I exc. Lightning	Air Filter	E-0945	2000	7.3L	V8	DSL	All	Air Filter	33-2138	
							2003	5.4L	V8	F/I Lightning, (3)	Oil Filter	HP-2010	2000	7.3L	V8	DSL	Turbo	Aircharger®	63-1024	
							2003	5.4L	V8	F/I	F Series	Oil Filter	HP-2010	1999	4.2L	V6	F/I (2)	Oil Filter	HP-2009	
							2003	5.4L	V8	F/I F Series, (M)	Oil Filter	HP-2010	1999	4.2L	V6	F/I	All	Air Filter	E-0945	
							2003	5.4L	V8	F/I	CNG			1999	4.6L	V8	F/I	All	Air Filter	E-0945
							2003	5.4L	V8	F/I	F Series, (Z)	Oil Filter	HP-2010	1999	4.6L	V8	F/I	All	FIPK	57-2514-4
							2003	5.4L	V8	F/I	Bi-Fuel			1999	5.4L	V8	F/I (L)	Oil Filter	HP-2010	
							2003	5.4L	V8	F/I	F Series	Oil Filter	HP-2010	1999	5.4L	V8	F/I exc. Lightning	Air Filter	E-0945	
							2003	5.4L	V8	F/I	Super Duty, (L)			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2003	6.8L	V10	F/I	All	Air Filter	E-0945	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2003	6.8L	V10	F/I	F Series,	Oil Filter	HP-2010	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2003	6.8L	V10	F/I	Super Duty, (S)			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2003	7.3L	V8	DSL	All	Air Filter	33-2248	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2003	7.3L	V8	DSL (F),	Super Duty	Oil Filter	HP-6001	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2003	7.3L	V8	DSL	Turbo			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	4.2L	V6	F/I	All	Air Filter	E-0945	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	4.2L	V6	F/I	F Series, (2)	Oil Filter	HP-2009	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	4.6L	V8	F/I	All	Air Filter	E-0945	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	4.6L	V8	F/I	exc. Super	FIPK	57-2514-4	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	4.6L	V8	F/I	Duty & Lightning			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	4.6L	V8	F/I	F Series, (W)	Oil Filter	HP-2010	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	exc.	Air Filter	E-0945	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	Lightning (S/C)			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	Duty & Lightning			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	F Series, (3),	Oil Filter	HP-2010	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	(L), (M), (Z)			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	F Series	FIPK	57-2525-2	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	Super Duty			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	Lightning	Air Filter	33-2140-1	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	5.4L	V8	F/I	(S/C)			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	6.8L	V10	F/I	All	Air Filter	E-0945	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	6.8L	V10	F/I	F Series,	Oil Filter	HP-2010	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	6.8L	V10	F/I	Super Duty, (S)			1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	6.8L	V10	F/I	F Series	FIPK	57-2524-2	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	7.3L	V8	DSL	(F)	Oil Filter	HP-6001	1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	7.3L	V8	DSL				1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	7.3L	V8	DSL				1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	7.3L	V8	DSL				1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	7.3L	V8	DSL				1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4
							2002	7.3L	V8	DSL				1999	5.4L	V8	F/I	exc. Super	FIPK	57-2514-4

Automotive Applications

(Pickup Full Size cont.)

FORD

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #
1998	4.6L	V8 F/I	All	FIPK	57-2514-4	1994	4.9L	L6 F/I	w/o mass air	FIPK	57-2503	1990	5.0L	V8 F/I	(N)	Oil Filter	HP-3001
1998	5.4L	V8 F/I	(L)	Oil Filter	HP-2010	1994	5.0L	V8 F/I	(N)	Oil Filter	HP-3001	1990	5.0L	V8 F/I	All	Air Filter	33-2023
1998	5.4L	V8 F/I	All	Air Filter	E-0945	1994	5.0L	V8 F/I	All	Air Filter	33-2023	1990	5.0L	V8 F/I	All	FIPK	57-2503
1998	5.4L	V8 F/I	All	FIPK	57-2514-4	1994	5.0L	V8 F/I	w/ mass air	FIPK	57-2510-1	1990	5.8L	V8 F/I	(H)	Oil Filter	HP-3001
1998	5.8L	V8 F/I	All	Air Filter	33-2023	1994	5.0L	V8 F/I	w/o mass air	FIPK	57-2503	1990	5.8L	V8 F/I	All	Air Filter	33-2023
1998	7.3L	V8 DSL	(F) Turbo	Oil Filter	HP-6001	1994	5.8L	V8 F/I	(H,R)	Oil Filter	HP-2010	1990	5.8L	V8 F/I	All	FIPK	57-2503
1998	7.3L	V8 DSL	Turbo	Air Filter	E-1946	1994	5.8L	V8 F/I	All	Air Filter	33-2023	1990	7.3L	V8 DSL	(M)	Oil Filter	HP-4002
1998	7.5L	V8 F/I	All	Air Filter	33-2023	1994	5.8L	V8 F/I	Lightning	FIPK	57-2517	1990	7.3L	V8 DSL	All	Air Filter	E-1460
1997	4.2L	V6 F/I	(2)	Oil Filter	HP-2009	1994	5.8L	V8 F/I	w/o mass air, exc. L	FIPK	57-2503	1990	7.5L	V8 F/I	(G)	Oil Filter	HP-3001
1997	4.2L	V6 F/I	All	Air Filter	E-0945	1994	7.3L	V8 DSL	(K,M) Turbo	Oil Filter	HP-4002	1990	7.5L	V8 F/I	All	Air Filter	33-2023
1997	4.6L	V8 F/I	(6,W)	Oil Filter	HP-2010	1994	7.3L	V8 DSL	DI Turbo	Air Filter	E-1946	1990	7.5L	V8 F/I	All	FIPK	57-2503
1997	4.6L	V8 F/I	All	Air Filter	E-0945	1994	7.3L	V8 DSL	S/D only			1989	4.9L	L6 F/I	All	Air Filter	33-2023
1997	4.6L	V8 F/I	All	FIPK	57-2514-4	1994	7.3L	V8 DSL	Non Turbo	Air Filter	E-1460	1989	4.9L	L6 F/I	All	FIPK	57-2503
1997	5.4L	V8 F/I	(L)	Oil Filter	HP-2010	1994	7.3L	V8 DSL	IDI Turbo	Air Filter	33-2088	1989	5.0L	V8 F/I	(N)	Oil Filter	HP-3001
1997	5.4L	V8 F/I	All	Air Filter	E-0945	1994	7.3L	V8 DSL	S/D only			1989	5.0L	V8 F/I	All	Air Filter	33-2023
1997	5.4L	V8 F/I	All	FIPK	57-2514-4	1994	7.3L	V8 DSL	DI Turbo Diesel	Aircharger®	63-1038	1989	5.0L	V8 F/I	All	FIPK	57-2503
1997	5.8L	V8 F/I	(H)	Oil Filter	HP-2010	1994	7.3L	V8 DSL	(G) exc.	Oil Filter	HP-3001	1989	5.8L	V8 F/I	(H)	Oil Filter	HP-3001
1997	5.8L	V8 F/I	All	Air Filter	33-2023	1994	7.5L	V8 F/I	off-road apps			1989	5.8L	V8 F/I	All	Air Filter	33-2023
1997	5.8L	V8 F/I	w/mass air	FIPK	57-2510-1	1994	7.5L	V8 F/I	All	Air Filter	33-2023	1989	5.8L	V8 F/I	All	FIPK	57-2503
1997	5.8L	V8 F/I	w/o mass air	Aircharger®	63-1014	1994	7.5L	V8 F/I	All	FIPK	57-2503	1989	7.3L	V8 DSL	(M)	Oil Filter	HP-4002
1997	7.3L	V8 DSL	(F) Turbo	Oil Filter	HP-6001	1994	7.5L	V8 F/I	All	FIPK	57-2503	1989	7.3L	V8 DSL	All	Air Filter	E-1460
1997	7.3L	V8 DSL	Turbo	Air Filter	E-1946	1993	4.9L	L6 F/I	(Y)	Oil Filter	HP-3001	1989	7.5L	V8 F/I	(G) exc.	Oil Filter	HP-3001
1997	7.3L	V8 DSL	Turbo Diesel	Aircharger®	63-1038	1993	4.9L	L6 F/I	All	Air Filter	33-2023	1989	7.5L	V8 F/I	All	Air Filter	33-2023
1997	7.5L	V8 F/I	(G) exc.	Oil Filter	HP-3001	1993	4.9L	L6 F/I	All	FIPK	57-2503	1989	7.5L	V8 F/I	All	FIPK	57-2503
			off-road apps			1993	5.0L	V8 F/I	(N)	Oil Filter	HP-3001	1988	7.5L	V8 F/I	All	FIPK	57-2503
1997	7.5L	V8 F/I	All	Air Filter	33-2023	1993	5.0L	V8 F/I	All	Air Filter	33-2023	1988	4.9L	L6 F/I	(Y) 2 & 4WD	Oil Filter	HP-3001
1997	7.5L	V8 F/I	w/mass air	FIPK	57-2516	1993	5.0L	V8 F/I	All	FIPK	57-2503	1988	4.9L	L6 F/I	All	Air Filter	33-2023
1997	7.5L	V8 F/I	w/o mass air	Aircharger®	63-1014	1993	5.8L	V8 F/I	(H)	Oil Filter	HP-3001	1988	4.9L	L6 F/I	All	FIPK	57-2503
1996	4.9L	L6 F/I	All	Air Filter	33-2023	1993	5.8L	V8 F/I	All	Air Filter	33-2023	1988	5.0L	V8 F/I	(N)	Oil Filter	HP-3001
1996	4.9L	L6 F/I	w/mass air	FIPK	57-2510-1	1993	5.8L	V8 F/I	exc. Lightning	FIPK	57-2503	1988	5.0L	V8 F/I	All	Air Filter	33-2023
1996	4.9L	L6 F/I	w/o mass air	Aircharger®	63-1014	1993	5.8L	V8 F/I	Lightning	FIPK	57-2517	1988	5.0L	V8 F/I	All	FIPK	57-2503
1996	5.0L	V8 F/I	(N)	Oil Filter	HP-3001	1993	7.3L	V8 DSL	(C)	Oil Filter	HP-4002	1988	5.8L	V8 F/I	(H)	Oil Filter	HP-3001
1996	5.0L	V8 F/I	All	Air Filter	33-2023	1993	7.3L	V8 DSL	(M)	Oil Filter	HP-4002	1988	5.8L	V8 F/I	All	Air Filter	33-2023
1996	5.0L	V8 F/I	w/mass air	FIPK	57-2510-1	1993	7.3L	V8 DSL	All	Air Filter	E-1460	1988	5.8L	V8 F/I	All	FIPK	57-2503
1996	5.0L	V8 F/I	w/o mass air	Aircharger®	63-1014	1993	7.3L	V8 DSL	Turbo	Air Filter	33-2088	1988	7.3L	V8 DSL	(M)	Oil Filter	HP-4002
1996	5.8L	V8 F/I	(H)	Oil Filter	HP-2010	1993	7.5L	V8 F/I	(G)	Oil Filter	HP-3001	1988	7.3L	V8 DSL	All	Air Filter	E-1460
1996	5.8L	V8 F/I	All	Air Filter	33-2023	1993	7.5L	V8 F/I	All	Air Filter	33-2023	1988	7.5L	V8 F/I	(G) exc.	Oil Filter	HP-3001
1996	5.8L	V8 F/I	w/mass air	FIPK	57-2510-1	1993	7.5L	V8 F/I	All	FIPK	57-2503	1988	7.5L	V8 F/I	off-road apps		
1996	5.8L	V8 F/I	w/o mass air	Aircharger®	63-1014	1992	4.9L	L6 F/I	(Y)	Oil Filter	HP-3001	1988	7.5L	V8 F/I	All	Air Filter	33-2023
1996	7.3L	V8 DSL	(F) Turbo	Oil Filter	HP-6001	1992	4.9L	L6 F/I	All	Air Filter	33-2023	1988	7.5L	V8 F/I	All	FIPK	57-2503
1996	7.3L	V8 DSL	Turbo	Air Filter	E-1946	1992	4.9L	L6 F/I	All	FIPK	57-2503	1987	4.9L	L6 F/I	(Y) 2 & 4WD	Oil Filter	HP-3001
1996	7.3L	V8 DSL	Turbo Diesel	Aircharger®	63-1038	1992	5.0L	V8 F/I	(N)	Oil Filter	HP-3001	1987	4.9L	L6 F/I	All	Air Filter	33-2023
1996	7.5L	V8 F/I	(G) exc.	Oil Filter	HP-3001	1992	5.0L	V8 F/I	All	Air Filter	33-2023	1987	5.0L	V8 F/I	(N)	Oil Filter	HP-3001
			off-road apps			1992	5.0L	V8 F/I	All	FIPK	57-2503	1987	5.0L	V8 F/I	All	Air Filter	33-2023
1996	7.5L	V8 F/I	All	Air Filter	33-2023	1992	5.8L	V8 F/I	(H)	Oil Filter	HP-3001	1987	5.8L	V8 4 BBL.	(H)	Oil Filter	HP-3001
1996	7.5L	V8 F/I	w/mass air	FIPK	57-2516	1992	5.8L	V8 F/I	All	Air Filter	33-2023	1987	5.8L	V8 4 BBL.	All	Air Filter	E-1570
1996	7.5L	V8 F/I	w/o mass air	Aircharger®	63-1014	1992	5.8L	V8 F/I	All	FIPK	57-2503	1987	6.9L	V8 DSL	(I)	Oil Filter	HP-4002
1995	4.9L	L6 F/I	w/mass air	Air Filter	33-2023	1992	7.3L	V8 DSL	(M)	Oil Filter	HP-4002	1987	6.9L	V8 DSL	All	Air Filter	E-1460
1995	4.9L	L6 F/I	w/mass air	FIPK	57-2510-1	1992	7.3L	V8 DSL	All	Air Filter	E-1460	1987	7.5L	V8 4 BBL.	(L) exc.	Oil Filter	HP-3001
1995	4.9L	L6 F/I	w/o mass air	Air Filter	33-2023	1992	7.5L	V8 F/I	(G)	Oil Filter	HP-3001	1987	7.5L	V8 4 BBL.	off-road apps		
1995	4.9L	L6 F/I	w/o mass air	FIPK	57-2503	1992	7.5L	V8 F/I	All	Air Filter	33-2023	1987	7.5L	V8 4 BBL.	All	Air Filter	E-1570
1995	5.0L	V8 F/I	(N)	Oil Filter	HP-3001	1992	7.5L	V8 F/I	All	FIPK	57-2503	1986	4.9L	L6 1 BBL.	(Y)	Oil Filter	HP-3001
1995	5.0L	V8 F/I	All	Air Filter	33-2023	1991	4.9L	L6 F/I	All	Air Filter	33-2023	1986	4.9L	L6 1 BBL.	All	Air Filter	E-1350
1995	5.0L	V8 F/I	w/mass air	FIPK	57-2510-1	1991	4.9L	L6 F/I	All	FIPK	57-2503	1986	5.0L	V8 F/I	(N)	Oil Filter	HP-3001
1995	5.0L	V8 F/I	w/o mass air	FIPK	57-2503	1991	4.9L	L6 F/I	exc.cart.type	Oil Filter	HP-3001	1986	5.0L	V8 F/I	All	Air Filter	33-2012
1995	5.8L	V8 F/I	(H,R)	Oil Filter	HP-2010	1991	5.0L	V8 F/I	(N)	Oil Filter	HP-3001	1986	5.0L	V8 F/I	All	Air Filter	E-1290
1995	5.8L	V8 F/I	All	Air Filter	33-2023	1991	5.0L	V8 F/I	All	Air Filter	33-2023	1986	5.8L	V8 2 BBL.	All	Air Filter	E-1290
1995	5.8L	V8 F/I	Lightning	FIPK	57-2517	1991	5.0L	V8 F/I	All	FIPK	57-2503	1986	5.8L	V8 4 BBL.	(H)	Oil Filter	HP-3001
1995	5.8L	V8 F/I	w/mass air	FIPK	57-2510-1	1991	5.0L	V8 F/I	All	FIPK	57-2503	1986	5.8L	V8 4 BBL.	All	Air Filter	E-1570
1995	5.8L	V8 F/I	w/o mass air, exc. L	FIPK	57-2503	1991	5.8L	V8 F/I	(H)	Oil Filter	HP-3001	1986	6.9L	V8 DSL	(1)	Oil Filter	HP-4002
1995	7.3L	V8 DSL	(F) Turbo	Oil Filter	HP-6001	1991	5.8L	V8 F/I	All	Air Filter	33-2023	1986	6.9L	V8 DSL	All	Air Filter	E-1460
1995	7.3L	V8 DSL	All	Air Filter	E-1946	1991	5.8L	V8 F/I	All	FIPK	57-2503	1986	7.5L	V8 4 BBL.	(L)	Oil Filter	HP-3001
1995	7.3L	V8 DSL	Turbo Diesel	Aircharger®	63-1038	1991	7.3L	V8 DSL	(M)	Oil Filter	HP-4002	1986	7.5L	V8 4 BBL.	All	Air Filter	E-1570
1995	7.5L	V8 F/I	(G) exc.	Oil Filter	HP-3001	1991	7.3L	V8 DSL	All	Air Filter	E-1460	1985	4.9L	L6 1 BBL.	(Y)	Oil Filter	HP-3001
			off-road apps			1991	7.5L	V8 F/I	(G)	Oil Filter	HP-3001	1985	4.9L	L6 1 BBL.	All	Air Filter	E-1350
1995	7.5L	V8 F/I	All	Air Filter	33-2023	1991	7.5L	V8 F/I	All	Air Filter	33-2023	1985	5.0L	V8 2 BBL.	(F)	Oil Filter	HP-3001
1995	7.5L	V8 F/I	All	FIPK	57-2503	1991	7.5L	V8 F/I	All	FIPK	57-2503	1985	5.0L	V8 2 BBL.	All	Air Filter	E-1290
1994	4.9L	L6 F/I	All	Air Filter	33-2023	1990	4.9L	L6 F/I	(Y)	Oil Filter	HP-3001	1985	5.0L	V8 F/I	(N)	Oil Filter	HP-3001
						1990	4.9L	L6 F/I	All	Air Filter	33-2023	1985	5.0L	V8 F/I	All		

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #			
1985	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1979	351	V8	2 BBL.	(N)	Oil Filter	HP-3001	1973	240	L6	1 BBL.	All	Oil Filter	HP-3001
1985	5.8L	V8	4 BBL.	(H)	Oil Filter	HP-3001	1979	351	V8	2 BBL.	All	Air Filter	E-1290	1973	300	L6	1 BBL.	All	Air Filter	E-1200
1985	5.8L	V8	4 BBL.	All	Air Filter	E-1570	1979	400	V8	2 BBL.	(S)	Oil Filter	HP-3001	1973	300	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001
1985	6.9L	V8	DSL	(1)	Oil Filter	HP-4002	1979	400	V8	2 BBL.	All	Air Filter	E-1290	1973	302	V8	2 BBL.	All	Air Filter	E-1290
1985	6.9L	V8	DSL	All	Air Filter	E-1460	1979	460	V8	4 BBL.	(J)	Oil Filter	HP-3001	1973	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001
1985	7.5L	V8	4 BBL.	(L)	Oil Filter	HP-3001	1979	460	V8	4 BBL.	All	Air Filter	E-1570	1973	360	V8	2 BBL.	All	Air Filter	E-1570
1985	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1978	300	L6	1 BBL.	(B,K)	Oil Filter	HP-3001	1973	360	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001
1984	4.9L	L6	1 BBL.	(Y)	Oil Filter	HP-3001	1978	300	L6	1 BBL.	(B,K)	Oil Filter	HP-3001	1973	390	V8	4 BBL.	All	Air Filter	E-1570
1984	4.9L	L6	1 BBL.	All	Air Filter	E-1350	1978	300	L6	1 BBL.	(B,K)	Oil Filter	HP-3001	1973	390	V8	4 BBL.	exc.cart.type	Oil Filter	HP-3001
1984	5.0L	V8	2 BBL.	(F)	Oil Filter	HP-3001	1978	300	L6	1 BBL.	All	Air Filter	E-1040	1973	455	V8	4 BBL.	All	Air Filter	E-1570
1984	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1978	300	L6	1 BBL.	CA. mod.	Air Filter	E-1040	1972	240	L6	1 BBL.	All	Air Filter	E-1200
1984	5.8L	V8	2 BBL.	(G)	Oil Filter	HP-3001	1978	300	L6	1 BBL.	& F-100 only	Air Filter	E-1200	1972	240	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001
1984	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1978	300	L6	1 BBL.	exc. CA	Air Filter	E-1200	1972	300	L6	1 BBL.	All	Air Filter	E-1200
1984	6.9L	V8	DSL	(1)	Oil Filter	HP-4002	1978	302	V8	2 BBL.	mod. & F-100	Air Filter	HP-3001	1972	300	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001
1984	6.9L	V8	DSL	All	Air Filter	E-1460	1978	302	V8	2 BBL.	(G)	Oil Filter	HP-3001	1972	302	V8	2 BBL.	All	Air Filter	E-1570
1984	7.5L	V8	4 BBL.	(L)	Oil Filter	HP-3001	1978	302	V8	2 BBL.	All	Air Filter	E-1290	1972	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001
1984	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1978	351	V8	2 BBL.	(H)	Oil Filter	HP-3001	1972	302	V8	2 BBL.	exc. F-100	Air Filter	E-1570
1983	3.8L	V6	2 BBL.	(3)	Oil Filter	HP-3001	1978	351	V8	2 BBL.	All	Air Filter	E-1290	1972	302	V8	2 BBL.	F-100 only	Air Filter	E-1290
1983	3.8L	V6	2 BBL.	All	Air Filter	E-1325	1978	400	V8	2 BBL.	(S)	Oil Filter	HP-3001	1972	360	V8	2 BBL.	All	Air Filter	E-1570
1983	4.9L	L6	1 BBL.	(Y)	Oil Filter	HP-3001	1978	400	V8	2 BBL.	All	Air Filter	E-1290	1972	360	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001
1983	4.9L	L6	1 BBL.	All	Air Filter	E-1350	1978	460	V8	4 BBL.	(J)	Oil Filter	HP-3001	1972	390	V8	4 BBL.	All	Air Filter	E-1570
1983	5.0L	V8	2 BBL.	(F)	Oil Filter	HP-3001	1978	460	V8	4 BBL.	All	Air Filter	E-1570	1972	390	V8	4 BBL.	exc.cart.type	Oil Filter	HP-3001
1983	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1977	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	1971	240	L6	1 BBL.	All	Air Filter	E-1200
1983	5.8L	V8	2 BBL.	(G)	Oil Filter	HP-3001	1977	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	1971	300	L6	1 BBL.	All	Air Filter	E-1200
1983	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1977	300	L6	1 BBL.	exc F-100	Air Filter	E-1200	1971	302	V8	2 BBL.	All	Air Filter	E-1570
1983	6.9L	V8	DSL	(1)	Oil Filter	HP-4002	1977	300	L6	1 BBL.	F-100 only	Air Filter	E-1040	1971	351	V8	2 BBL.	All	Air Filter	E-1570
1983	6.9L	V8	DSL	All	Air Filter	E-1460	1977	302	V8	2 BBL.	(G)	Oil Filter	HP-3001	1971	360	V8	2 BBL.	All	Air Filter	E-1570
1983	7.5L	V8	4 BBL.	(L)	Oil Filter	HP-3001	1977	302	V8	2 BBL.	All	Air Filter	E-1290	1971	390	V8	4 BBL.	All	Air Filter	E-1570
1983	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1977	351	V8	2 BBL.	(H)	Oil Filter	HP-3001	1970	240	L6	1 BBL.	All	Air Filter	E-1200
1982	3.8L	V6	2 BBL.	(3)	Oil Filter	HP-3001	1977	351	V8	2 BBL.	All	Air Filter	E-1290	1970	240	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001
1982	3.8L	V6	2 BBL.	All	Air Filter	E-1325	1977	400	V8	2 BBL.	(S)	Oil Filter	HP-3001	1970	300	L6	1 BBL.	All	Air Filter	E-1200
1982	4.2L	V8	2 BBL.	(D)	Oil Filter	HP-3001	1977	400	V8	2 BBL.	All	Air Filter	E-1290	1970	300	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001
1982	4.2L	V8	2 BBL.	All	Air Filter	E-1290	1977	460	V8	4 BBL.	(J)	Oil Filter	HP-3001	1970	302	V8	2 BBL.	All	Air Filter	E-1570
1982	4.9L	L6	1 BBL.	(9,E)	Oil Filter	HP-3001	1977	460	V8	4 BBL.	All	Air Filter	E-1570	1970	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001
1982	4.9L	L6	1 BBL.	All	Air Filter	E-1350	1976	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	1970	351	V8	2 BBL.	All	Air Filter	E-1570
1982	5.0L	V8	2 BBL.	(F)	Oil Filter	HP-3001	1976	300	L6	1 BBL.	All	Air Filter	E-1200	1970	360	V8	2 BBL.	All	Air Filter	E-1570
1982	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1976	302	V8	2 BBL.	(G)	Oil Filter	HP-3001	1970	360	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001
1982	5.8L	V8	2 BBL.	(W)	Oil Filter	HP-3001	1976	302	V8	2 BBL.	All	Air Filter	E-1290	1970	390	V8	4 BBL.	All	Air Filter	E-1570
1982	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1976	360	V8	2 BBL.	(Y)	Oil Filter	HP-3001	1970	390	V8	4 BBL.	exc.cart.type	Oil Filter	HP-3001
1982	6.6L	V8	2 BBL.	(Z)	Oil Filter	HP-3001	1976	360	V8	2 BBL.	All	Air Filter	E-1570	1970	428	V8	4 BBL.	GPD carb.	Air Filter	E-1560
1982	6.6L	V8	2 BBL.	All	Air Filter	E-1290	1976	390	V8	4 BBL.	(M)	Oil Filter	HP-3001	1970	428	V8	4 BBL.	Rochester carb.	Air Filter	E-1570
1981	4.2L	V8	2 BBL.	(D)	Oil Filter	HP-3001	1976	390	V8	4 BBL.	All	Air Filter	E-1570	1969	170	L6	1 BBL.	All	Air Filter	E-1040
1981	4.2L	V8	2 BBL.	All	Air Filter	E-1290	1976	400	V8	2 BBL.	All	Air Filter	E-1290	1969	200	L6	1 BBL.	All	Air Filter	E-1040
1981	4.9L	L6	1 BBL.	(E)	Oil Filter	HP-3001	1976	460	V8	4 BBL.	(J)	Oil Filter	HP-3001	1969	240	L6	1 BBL.	All	Air Filter	E-1040
1981	4.9L	L6	1 BBL.	All	Air Filter	E-1040	1976	460	V8	4 BBL.	All	Air Filter	E-1570	1969	240	L6	1 BBL.	exc.F-100	Air Filter	E-1030
1981	5.0L	V8	2 BBL.	(F)	Oil Filter	HP-3001	1975	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	1969	240	L6	1 BBL.	man. trans.	Air Filter	E-1030
1981	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1975	300	L6	1 BBL.	All	Air Filter	E-1200	1969	240	L6	1 BBL.	F-100	Air Filter	E-1200
1981	5.8L	V8	2 BBL.	(G)	Oil Filter	HP-3001	1975	302	V8	2 BBL.	(G)	Oil Filter	HP-3001	1969	240	L6	1 BBL.	w/man. trans.	Air Filter	E-1200
1981	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1975	302	V8	2 BBL.	All	Air Filter	E-1290	1969	351	V8	2 BBL.	All	Air Filter	E-1570
1981	6.6L	V8	2 BBL.	(Z)	Oil Filter	HP-3001	1975	360	V8	2 BBL.	(Y)	Oil Filter	HP-3001	1969	351	V8	2 BBL.	All	Oil Filter	HP-3001
1981	6.6L	V8	2 BBL.	All	Air Filter	E-1290	1975	360	V8	2 BBL.	All	Air Filter	E-1570	1969	351	V8	4 BBL.	All	Air Filter	E-1570
1980	300	L6	1 BBL.	(E)	Oil Filter	HP-3001	1975	390	V8	4 BBL.	(H)	Oil Filter	HP-3001	1969	351	V8	4 BBL.	All	Oil Filter	HP-3001
1980	300	L6	1 BBL.	All	Air Filter	E-1040	1975	390	V8	4 BBL.	All	Air Filter	E-1570	1969	360	V8	4 BBL.	All	Air Filter	E-1570
1980	302	V8	2 BBL.	(F)	Oil Filter	HP-3001	1975	400	V8	2 BBL.	All	Air Filter	E-1290	1969	360	V8	4 BBL.	exc.cart.type	Oil Filter	HP-3001
1980	302	V8	2 BBL.	All	Air Filter	E-1290	1975	460	V8	4 BBL.	(J)	Oil Filter	HP-3001	1969	360	V8	4 BBL.	All	Air Filter	E-1570
1980	351	V8	2 BBL.	(G)	Oil Filter	HP-3001	1975	460	V8	4 BBL.	All	Air Filter	E-1570	1969	390	V8	4 BBL.	All	Air Filter	E-1570
1980	351	V8	2 BBL.	All	Air Filter	E-1290	1974	240	L6	1 BBL.	All	Air Filter	E-1200	1969	390	V8	4 BBL.	exc.cart.type	Oil Filter	HP-3001
1980	400	V8	2 BBL.	(Z)	Oil Filter	HP-3001	1974	240	L6	1 BBL.	All	Oil Filter	HP-3001	1969	428	V8	4 BBL.	GPD carb.	Air Filter	E-1560
1980	400	V8	2 BBL.	All	Air Filter	E-1290	1974	300	L6	1 BBL.	All	Air Filter	E-1200	1969	428	V8	4 BBL.	Rochester carb.	Air Filter	E-1570
1980	460	V8	4 BBL.	(L)	Oil Filter	HP-3001	1974	300	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001	1968	170	L6	1 BBL.	All	Air Filter	E-1040
1980	460	V8	4 BBL.	All	Air Filter	E-1570	1974	302	V8	2 BBL.	All	Air Filter	E-1290	1968	240	L6	1 BBL.	All	Air Filter	E-1030
1979	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	1974	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001	1968	289	V8	2 BBL.	All	Air Filter	E-1570
1979	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	1974	360	V8	2 BBL.	All	Air Filter	E-1570	1968	360	V8	4 BBL.	All	Air Filter	E-1570
1979	300	L6	1 BBL.	CA. mod.	Air Filter	E-1040	1974	360	V8	2 BBL.	All	Oil Filter	HP-3001	1968	360	V8	4 BBL.	All	Oil Filter	HP-3001
				& F-100 only			1974	390	V8	4 BBL.	All	Air Filter	E-1570	1968	360	V8	4 BBL.	All	Air Filter	E-1570
1979	300	L6	1 BBL.	exc. CA	Air Filter	E-1200	1974	390	V8	4 BBL.	All	Oil Filter	HP-3001	1968	390	V8	2 BBL.	All	Air Filter	E-1570
				mod. & F-100			1974	460	V8	4 BBL.	All	Air Filter	E-1570	1967	200	L6	1 BBL.	All	Air Filter	E-1080
1979	302	V8																		

Automotive Applications

(Pickup Full Size cont.)

FORD

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #
1967	289 V8 2	BBL.	All	Air Filter	E-1040	1993	2.5L V6 F/I		All	Air Filter	33-2049	1973	400 V8 2	BBL.	All	Air Filter	E-1580
1966	200 L6 1	BBL.	All	Air Filter	E-1080	1993	2.5L V6 F/I		All	FIPK	57-2507	1973	400 V8 2	BBL.	All	Oil Filter	HP-3001
1966	200 L6 1	BBL.	All	Oil Filter	HP-3001	1992	2.2L L4 F/I		(C,L)	Oil Filter	HP-1006	1973	429 V8 4	BBL.	All	Air Filter	E-1580
1966	289 V8 2	BBL.	All	Air Filter	E-1040	1992	2.2L L4 F/I		All	Air Filter	33-2026	1973	429 V8 4	BBL.	All	Oil Filter	HP-3001
1965	200 L6 1	BBL.	All	Air Filter	E-1080	1992	3.0L V6 F/I		(U)	Oil Filter	HP-2009	1972	250 L6 1	BBL.	All	Air Filter	E-1350
1965	289 V8 2	BBL.	All	Air Filter	E-1040	1992	3.0L V6 F/I		All	Air Filter	33-2026	1972	250 L6 1	BBL.	All	Oil Filter	HP-3001
1964	200 L6 1	BBL.	All	Air Filter	E-1080	1991	2.2L L4 F/I		(C)	Oil Filter	HP-1006	1972	302 V8 2	BBL.	All	Air Filter	E-1300
1964	200 L6 1	BBL.	All	Oil Filter	HP-3001	1991	2.2L L4 F/I		All	Air Filter	33-2026	1972	302 V8 2	BBL.	exc.cart.type	Oil Filter	HP-3001
1964	260 V8 2	BBL.	All	Air Filter	E-1080	1991	3.0L V6 F/I		(U)	Oil Filter	HP-2009	1972	351 V8 2	BBL.	All	Air Filter	E-1300
1964	260 V8 2	BBL.	All	Oil Filter	HP-3001	1991	3.0L V6 F/I		All	Air Filter	33-2026	1972	351 V8 2	BBL.	All	Oil Filter	HP-3001
1964	289 V8 2	BBL.	All	Air Filter	E-1040	1990	2.2L L4 F/I		(C)	Oil Filter	HP-1006	1972	351 V8 4	BBL.	CJ w/	Oil Filter	HP-3001
1964	289 V8 2	BBL.	All	Oil Filter	HP-3001	1990	2.2L L4 F/I		Cruise Control	Air Filter	33-2024				Ram air		
1963	200 L6 1	BBL.	All	Air Filter	E-1080	1990	2.2L L4 F/I		exc. Cruise Control	Air Filter	33-2026	1972	351 V8 4	BBL.	w/Ram air	Air Filter	E-1560
1963	200 L6 1	BBL.	All	Oil Filter	HP-3001	1990	3.0L V6 F/I		(U)	Oil Filter	HP-2009	1972	351 V8 4	BBL.	w/o Ram air	Air Filter	E-1570
1963	289 V8 2	BBL.	All	Air Filter	E-1040	1990	3.0L V6 F/I		All	Air Filter	33-2026	1972	351 V8 4	BBL.	w/o Ram air	Oil Filter	HP-3001
1963	289 V8 2	BBL.	All	Oil Filter	HP-3001	1989	2.2L L4 F/I		(L)	Oil Filter	HP-1006	1972	400 V8 2	BBL.	All	Air Filter	E-1570
Pinto						1989	2.2L L4 F/I		All	Air Filter	33-2026	1972	429 V8 4	BBL.	All	Air Filter	E-1570
1980	140 L4 2	BBL.	All	Air Filter	E-1200	1989	2.2L L4 F/I		All	Air Filter	33-2026	1972	429 V8 4	BBL.	All	Oil Filter	HP-3001
1979	230 L4 2	BBL.	All	Air Filter	E-1200	Ranchero						1972	250 L6 1	BBL.	All	Air Filter	E-1350
1979	280 V6 2	BBL.	All	Air Filter	E-1280	1979	302 V8 2	BBL.	(F)	Oil Filter	HP-3001	1971	250 L6 1	BBL.	All	Oil Filter	HP-3001
1978	230 L4 2	BBL.	All	Air Filter	E-1200	1979	302 V8 2	BBL.	All	Air Filter	E-1290	1971	250 L6 1	BBL.	All	Air Filter	HP-3001
1978	280 V6 2	BBL.	All	Air Filter	E-1280	1979	351 V8 2	BBL.	(H)	Oil Filter	HP-3001	1971	302 V8 2	BBL.	All	Air Filter	E-1570
1977	230 L4 2	BBL.	All	Air Filter	E-1200	1979	351 V8 2	BBL.	All	Air Filter	E-1290	1971	302 V8 2	BBL.	exc.cart.type	Oil Filter	HP-3001
1977	280 V6 2	BBL.	All	Air Filter	E-1280	1978	302 V8 2	BBL.	(F)	Oil Filter	HP-3001	1971	351 V8 2	BBL.	All	Air Filter	E-1570
1976	230 L4 2	BBL.	All	Air Filter	E-1200	1978	302 V8 2	BBL.	All	Air Filter	E-1290	1971	351 V8 4	BBL.	All	Air Filter	E-1570
1976	280 V6 2	BBL.	All	Air Filter	E-1350	1978	351 V8 2	BBL.	(H)	Oil Filter	HP-3001	1971	429 V8 4	BBL.	GPD carb.	Air Filter	E-1560
1975	230 L4 2	BBL.	All	Air Filter	E-1200	1978	351 V8 2	BBL.	All	Air Filter	E-1290	1971	429 V8 4	BBL.	Rochester carb.	Air Filter	E-1570
1975	280 V6 2	BBL.	All	Air Filter	E-1350	1978	400 V8 2	BBL.	(S)	Oil Filter	HP-3001	1971	429 V8 4	BBL.	w/Ram air	Air Filter	E-1580
1974	200 L4 2	BBL.	All	Air Filter	E-1200	1978	400 V8 2	BBL.	All	Air Filter	E-1300	1971	429 V8 4	BBL.	w/Ram air	Oil Filter	HP-3001
1974	230 L4 2	BBL.	All	Air Filter	E-1200	1977	302 V8 2	BBL.	(F)	Oil Filter	HP-3001	1970	250 L6 1	BBL.	All	Air Filter	E-1350
1973	160 L4 1	BBL.	All	Air Filter	E-1050	1977	302 V8 2	BBL.	All	Air Filter	E-1290	1970	250 L6 1	BBL.	All	Oil Filter	HP-3001
1973	200 L4 2	BBL.	All	Air Filter	E-1200	1977	351 V8 2	BBL.	(H)	Oil Filter	HP-3001	1970	302 V8 2	BBL.	All	Air Filter	E-1570
1972	160 L4 1	BBL.	All	Air Filter	E-1050	1977	400 V8 2	BBL.	(S)	Oil Filter	HP-3001	1970	302 V8 2	BBL.	exc.cart.type	Oil Filter	HP-3001
1972	200 L4 1	BBL.	All	Air Filter	E-1210	1977	400 V8 2	BBL.	All	Air Filter	E-1300	1970	351 V8 2	BBL.	All	Oil Filter	HP-3001
1971	160 L4 1	BBL.	All	Air Filter	E-1050	1976	351 V8 2	BBL.	(H)	Oil Filter	HP-3001	1970	351 V8 2	BBL.	All	Oil Filter	HP-3001
1971	200 L4 1	BBL.	All	Air Filter	E-1210	1976	351 V8 2	BBL.	(W)	Air Filter	E-1300	1970	351 V8 2	BBL.	w/Ram air	Air Filter	E-1580
Police						1976	400 V8 2	BBL.	(S)	Oil Filter	HP-3001	1970	351 V8 2	BBL.	w/o Ram air		
1972	429 V8 4	BBL.	All	Air Filter	E-1570	1976	400 V8 2	BBL.	All	Air Filter	E-1300	1970	351 V8 2	BBL.	(W),(C)	Air Filter	E-1570
1971	429 V8 4	BBL.	w/GPD carb.	Air Filter	E-1560	1976	400 V8 2	BBL.	All	Air Filter	E-1300	1970	351 V8 4	BBL.	All	Oil Filter	HP-3001
1971	429 V8 4	BBL.	w/Roch carb.	Air Filter	E-1570	1976	460 V8 4	BBL.	(A)	Oil Filter	HP-3001	1970	351 V8 4	BBL.	All	Oil Filter	HP-3001
1970	428 V8 4	BBL.	All	Air Filter	E-1560	1976	460 V8 4	BBL.	All	Air Filter	E-1580	1970	351 V8 4	BBL.	All	Oil Filter	HP-3001
1969	428 V8 4	BBL.	All	Air Filter	E-1560	1975	302 V8 2	BBL.	All	Air Filter	E-1300	1970	351 V8 4	BBL.	w/Ram air	Air Filter	E-1580
1968	428 V8 4	BBL.	All	Air Filter	E-1560	1975	351 V8 2	BBL.	"M"	Air Filter	E-1580	1970	351 V8 4	BBL.	(W),(C)	Air Filter	E-1570
Probe						1975	351 V8 2	BBL.	"W"	Air Filter	E-1300	1970	351 V8 4	BBL.	w/o Ram air	Air Filter	E-1570
1997	2.0L L4 F/I		(A)	Oil Filter	HP-1006	1975	351 V8 2	BBL.	(H)	Oil Filter	HP-3001	1970	351 V8 4	BBL.	(W),(C)	Air Filter	E-1570
1997	2.0L L4 F/I		All	Air Filter	33-2049	1975	351 V8 2	BBL.	(H)	Oil Filter	HP-3001	1970	390 V8 2	BBL.	All	Air Filter	E-1570
1997	2.5L V6 F/I		(B)	Oil Filter	HP-1010	1975	400 V8 2	BBL.	(S)	Oil Filter	HP-3001	1970	390 V8 2	BBL.	All	Oil Filter	HP-3001
1997	2.5L V6 F/I		All	Air Filter	33-2049	1975	400 V8 2	BBL.	All	Air Filter	E-1580	1970	390 V8 4	BBL.	All	Air Filter	E-1560
1997	2.5L V6 F/I		All	FIPK	57-2507	1975	460 V8 4	BBL.	(A)	Oil Filter	HP-3001	1970	390 V8 4	BBL.	All	Air Filter	E-1560
1996	2.0L L4 F/I		(A)	Oil Filter	HP-1006	1975	460 V8 4	BBL.	All	Air Filter	E-1580	1970	390 V8 4	BBL.	All	Oil Filter	HP-3001
1996	2.0L L4 F/I		All	Air Filter	33-2049	1974	250 L6 1	BBL.	All	Air Filter	E-1350	1970	429 V8 4	BBL.	"CJ"	Air Filter	E-1580
1996	2.5L V6 F/I		(B)	Oil Filter	HP-1010	1974	250 L6 1	BBL.	All	Oil Filter	HP-3001	1970	429 V8 4	BBL.	w/ Ram air		
1996	2.5L V6 F/I		All	Air Filter	33-2049	1974	302 V8 2	BBL.	All	Air Filter	E-1300	1970	429 V8 4	BBL.	"CJ" w/o	Air Filter	E-1570
1996	2.5L V6 F/I		All	FIPK	57-2507	1974	302 V8 2	BBL.	exc.cart.type	Oil Filter	HP-3001	1970	429 V8 4	BBL.	Ram air		
1995	2.0L L4 F/I		(A)	Oil Filter	HP-1006	1974	351 V8 2	BBL.	All	Air Filter	E-1300	1970	429 V8 4	BBL.	"SCJ"	Air Filter	E-1580
1995	2.0L L4 F/I		All	Air Filter	33-2049	1974	351 V8 2	BBL.	All	Oil Filter	HP-3001	1970	429 V8 4	BBL.	All	Oil Filter	HP-3001
1995	2.5L V6 F/I		(B)	Oil Filter	HP-1010	1974	351 V8 4	BBL.	All	Air Filter	E-1580	1970	429 V8 4	BBL.	All	Oil Filter	HP-3001
1995	2.5L V6 F/I		All	Air Filter	33-2049	1974	400 V8 2	BBL.	All	Air Filter	E-1580	1970	429 V8 4	BBL.	All	Oil Filter	HP-3001
1995	2.5L V6 F/I		All	FIPK	57-2507	1974	400 V8 2	BBL.	All	Oil Filter	HP-3001	1969	250 L6 1	BBL.	All	Air Filter	E-1030
1994	2.0L L4 F/I		(A)	Oil Filter	HP-1006	1974	460 V8 4	BBL.	All	Air Filter	E-1580	1969	250 L6 1	BBL.	All	Oil Filter	HP-3001
1994	2.0L L4 F/I		16V DOHC	Air Filter	33-2676	1974	460 V8 4	BBL.	All	Oil Filter	HP-3001	1969	302 V8 2	BBL.	All	Air Filter	E-1570
1994	2.0L L4 F/I		All	Air Filter	33-2049	1973	250 L6 1	BBL.	All	Air Filter	E-1350	1969	302 V8 2	BBL.	exc.cart.type	Oil Filter	HP-3001
1994	2.5L V6 F/I		(B)	Oil Filter	HP-1010	1973	250 L6 1	BBL.	All	Oil Filter	HP-3001	1969	351 V8 2	BBL.	All	Air Filter	E-1570
1994	2.5L V6 F/I		24V DOHC	Air Filter	33-2676	1973	302 V8 2	BBL.	All	Air Filter	E-1300	1969	351 V8 2	BBL.	All	Oil Filter	HP-3001
1994	2.5L V6 F/I																

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #
1969	390 V8 4 BBL.	exc.cart.type		Oil Filter	HP-3001	1999	3.0L V6 F/I	(U,V)		Oil Filter	HP-2009	1991	4.0L V6 F/I	(X)		Oil Filter	HP-3001
1968	200 L6 1 BBL.	All		Air Filter	E-1030	1999	3.0L V6 F/I	All		Air Filter	33-2106-1	1991	4.0L V6 F/I	All		Air Filter	33-2024
1968	200 L6 1 BBL.	All		Oil Filter	HP-3001	1999	3.0L V6 F/I	All		Aircharger®	63-1034	1990	2.3L L4 F/I	(A)		Oil Filter	HP-3001
1968	302 V8 2 BBL.	All		Air Filter	E-1570	1999	4.0L V6 F/I	(X)		Oil Filter	HP-3001	1990	2.3L L4 F/I	All		Air Filter	33-2024
1968	302 V8 2 BBL.	exc.cart.type		Oil Filter	HP-3001	1999	4.0L V6 F/I	All		Air Filter	33-2106-1	1990	2.9L V6 F/I	(T)		Oil Filter	HP-3001
1968	390 V8 2 BBL.	All		Air Filter	E-1570	1999	4.0L V6 F/I	OHV		FIPK	57-2527	1990	2.9L V6 F/I	All		Air Filter	33-2024
1968	390 V8 4 BBL.	All		Air Filter	E-1570	1998	2.5L L4 F/I	(C)		Oil Filter	HP-2009	1990	4.0L V6 F/I	(X)		Oil Filter	HP-3001
1967	200 L6 1 BBL.	All		Air Filter	E-1080	1998	2.5L L4 F/I	All		Air Filter	33-2106-1	1990	4.0L V6 F/I	All		Air Filter	33-2024
1967	390 V8 2 BBL.	All		Air Filter	E-1090	1998	3.0L V6 F/I	(U)		Oil Filter	HP-2009	1989	2.3L L4 F/I	(A)		Oil Filter	HP-3001
1967	390 V8 4 BBL.	All		Air Filter	E-1090	1998	3.0L V6 F/I	All		Air Filter	33-2106-1	1989	2.3L L4 F/I	All		Air Filter	33-2024
1966	170 L6 1 BBL.	All		Air Filter	E-1080	1998	3.0L V6 F/I	All		Aircharger®	63-1034	1989	2.9L V6 F/I	(T)		Oil Filter	HP-3001
1966	170 L6 1 BBL.	All		Oil Filter	HP-3001	1998	4.0L V6 F/I	(X)		Oil Filter	HP-3001	1989	2.9L V6 F/I	All		Air Filter	33-2024
1966	200 L6 1 BBL.	All		Air Filter	E-1080	1998	4.0L V6 F/I	All		Air Filter	33-2106-1	1988	2.0L L4 2 BBL.	(C)		Oil Filter	HP-3001
1965	170 L6 1 BBL.	All		Air Filter	E-1080	1998	4.0L V6 F/I	OHV		FIPK	57-2527	1988	2.0L L4 2 BBL.	All		Air Filter	E-1088
1965	170 L6 1 BBL.	All		Oil Filter	HP-3001	1997	2.3L L4 F/I	(A)		Oil Filter	HP-3001	1988	2.3L L4 F/I	(A)		Oil Filter	HP-3001
1965	200 L6 1 BBL.	All		Air Filter	E-1080	1997	2.3L L4 F/I	All		Air Filter	E-0995	1988	2.9L V6 F/I	(T)		Oil Filter	HP-3001
1964	170 L6 1 BBL.	All		Air Filter	E-1080	1997	2.3L L4 F/I	All	Manual	Aircharger®	63-1049	1988	2.9L V6 F/I	All		Air Filter	33-2024
1964	170 L6 1 BBL.	All		Oil Filter	HP-3001				Trans only			1987	2.0L L4 2 BBL.	(C)		Oil Filter	HP-3001
1964	200 L6 1 BBL.	All		Air Filter	E-1080	1997	3.0L V6 F/I	(U)		Oil Filter	HP-2009	1987	2.0L L4 2 BBL.	All		Air Filter	E-1088
1964	200 L6 1 BBL.	All		Oil Filter	HP-3001	1997	3.0L V6 F/I	All		Air Filter	E-0995	1987	2.3L L4 F/I	(A)		Oil Filter	HP-3001
1964	223 L6 1 BBL.	All		Air Filter	E-1080	1997	4.0L V6 F/I	(E,X)		Oil Filter	HP-3001	1987	2.9L V6 F/I	(T)		Oil Filter	HP-3001
1964	223 L6 1 BBL.	All		Oil Filter	HP-3001	1997	4.0L V6 F/I	All		Air Filter	E-0995	1986	2.0L L4 2 BBL.	All		Air Filter	E-1088
1963	170 L6 1 BBL.	All		Air Filter	E-1080	1997	4.0L V6 F/I	All		FIPK	57-2513-1	1986	2.3L L4 F/I	(A)		Oil Filter	HP-3001
1963	170 L6 1 BBL.	All		Oil Filter	HP-3001	1997	4.0L V6 F/I	OHV, w/		FIPK	57-2527	1986	2.9L V6 F/I	(T)		Oil Filter	HP-3001
1963	200 L6 1 BBL.	All		Air Filter	E-1080			FA-1658 panel filter				1985	2.0L L4 2 BBL.	All		Air Filter	E-1088
1963	200 L6 1 BBL.	All		Oil Filter	HP-3001	1996	2.3L L4 F/I	(A)		Oil Filter	HP-3001	1985	2.3L L4 F/I	(A,B)		Oil Filter	HP-3001
1963	223 L6 1 BBL.	All		Air Filter	E-1080	1996	2.3L L4 F/I	All		Air Filter	E-0995	1985	2.3L L4 F/I	All		Air Filter	33-2002
1963	223 L6 1 BBL.	All		Oil Filter	HP-3001	1996	2.3L L4 F/I	Manual		Aircharger®	63-1049	1985	2.8L V6 2 BBL.	(S)		Oil Filter	HP-3001
1962	170 L6 1 BBL.	All		Air Filter	E-1080			Trans only				1985	2.8L V6 2 BBL.	All		Air Filter	E-1280
1962	170 L6 1 BBL.	All		Oil Filter	HP-3001	1996	3.0L V6 F/I	(U)		Oil Filter	HP-2009	1984	2.0L L4 2 BBL.	All		Air Filter	E-1088
1962	223 L6 1 BBL.	All		Air Filter	E-1080	1996	3.0L V6 F/I	All		Air Filter	E-0995	1984	2.2L L4 DSL	(P) Full			
1962	223 L6 1 BBL.	All		Oil Filter	HP-3001	1996	4.0L V6 F/I	(X)		Oil Filter	HP-3001			flow filter		Oil Filter	HP-2007
1961	170 L6 1 BBL.	All		Air Filter	E-1080	1996	4.0L V6 F/I	All		Air Filter	E-0995	1984	2.2L L4 DSL	All		Air Filter	E-0990
1961	170 L6 1 BBL.	All		Oil Filter	HP-3001	1996	4.0L V6 F/I	All		FIPK	57-2513-1	1984	2.3L L4 1 BBL.	(A)		Oil Filter	HP-3001
1961	223 L6 1 BBL.	All		Air Filter	E-1080	1996	4.0L V6 F/I	All		Oil Filter	HP-3001	1984	2.3L L4 1 BBL.	All		Air Filter	E-1088
1961	223 L6 1 BBL.	All		Oil Filter	HP-3001	1995	2.3L L4 F/I	(A)		Oil Filter	HP-3001	1984	2.8L V6 2 BBL.	(S)		Oil Filter	HP-3001
						1995	2.3L L4 F/I	All		Air Filter	E-0995	1984	2.8L V6 2 BBL.	All		Air Filter	E-1280
						1995	2.3L L4 F/I	Manual		Aircharger®	63-1049	1984	2.8L V6 2 BBL.	All		Air Filter	E-1280
								Trans only				1983	2.2L L4 DSL	(P) Full			
						1995	3.0L V6 F/I	(U)		Oil Filter	HP-2009			flow filter		Oil Filter	HP-2007
						1995	3.0L V6 F/I	All		Air Filter	33-2024	1983	2.2L L4 DSL	All		Air Filter	E-0990
						1995	4.0L V6 F/I	(X)		Oil Filter	HP-3001	1983	2.3L L4 1 BBL.	(A)		Oil Filter	HP-3001
						1995	4.0L V6 F/I	All		Air Filter	E-0995	1983	2.3L L4 1 BBL.	All		Air Filter	E-1088
						1995	4.0L V6 F/I	All		FIPK	57-2513-1	1983	2.8L V6 2 BBL.	(S)		Oil Filter	HP-3001
						1994	2.3L L4 F/I	(A)		Oil Filter	HP-3001	1983	2.8L V6 2 BBL.	All		Air Filter	E-1280
						1994	2.3L L4 F/I	All		Air Filter	33-2024	1982	2.3L L4 2 BBL.	All		Air Filter	E-1088
						1994	3.0L V6 F/I	(U)		Oil Filter	HP-2009						
						1994	3.0L V6 F/I	All		Air Filter	33-2024						
						1994	4.0L V6 F/I	(X)		Oil Filter	HP-3001						
						1994	4.0L V6 F/I	All		Air Filter	33-2024						
						1994	4.0L V6 F/I	All		Air Filter	33-2024						
						1994	4.0L V6 F/I	SOHC		FIPK	57-2529-1						
						2001	2.3L L4 F/I	(D)		Oil Filter	HP-2009						
						2001	2.5L L4 F/I	(C)		Oil Filter	HP-2009						
						2001	2.5L L4 F/I	All		Air Filter	33-2106-1						
						2001	3.0L V6 F/I	(U,V)		Oil Filter	HP-2009						
						2001	3.0L V6 F/I	All		Air Filter	33-2106-1						
						2001	3.0L V6 F/I	All		Aircharger®	63-1034						
						2001	4.0L V6 F/I	(E)		Oil Filter	HP-2010						
						2001	4.0L V6 F/I	(X)		Oil Filter	HP-3001						
						2001	4.0L V6 F/I	All		Air Filter	33-2106-1						
						2001	4.0L V6 F/I	SOHC		FIPK	57-2529-1						
						2000	2.5L L4 F/I	(C)		Oil Filter	HP-2009						
						2000	2.5L L4 F/I	All		Air Filter	33-2106-1						
						2000	3.0L V6 F/I	(U,V)		Oil Filter	HP-2009						
						2000	3.0L V6 F/I	All		Air Filter	33-2106-1						
						2000	3.0L V6 F/I	All		Aircharger®	63-1034						
						2000	4.0L V6 F/I	(X)		Oil Filter	HP-3001						
						2000	4.0L V6 F/I	All		Air Filter	33-2106-1						
						2000	4.0L V6 F/I	OHV		FIPK	57-2527						
						1999	2.5L L4 F/I	(C)		Oil Filter	HP-2009						
						1999	2.5L L4 F/I	All		Air Filter	33-2106-1						

Automotive Applications

(Taurus cont.)

FORD

YRS.	ENG.DISPL. INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL. INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL. INTAKE	COMMENTS	PRODUCT	PART #
		(U) 12 valve			1987	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1991	3.8L V6 F/I	(4,R)	Oil Filter	HP-2009
1997	3.0L V6 F/I	(S) 24 valve	Oil Filter	HP-2010	1987	3.0L V6 F/I	All	Air Filter	33-2024	1991	3.8L V6 F/I	All	Air Filter	33-2033
1997	3.0L V6 F/I	All	Air Filter	33-2107	1986	2.5L L4 F/I	(D) A.T.	Oil Filter	HP-2004	1991	3.8L V6 F/I	Non SC	FIPK	57-2505-1
1997	3.4L V8 F/I	(N) SHO	Oil Filter	HP-2009	1986	2.5L L4 F/I	(D) M.T.	Oil Filter	HP-3001	1991	5.0L V8 F/I	(T)	Oil Filter	HP-3001
1997	3.4L V8 F/I	SHO	Air Filter	33-2107	1986	2.5L L4 F/I	All	Air Filter	33-2024	1991	5.0L V8 F/I	All	Air Filter	33-2033
1996	3.0L V6 F/I	(1,U) flex fuel	Oil Filter	HP-2009	1986	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1991	5.0L V8 F/I	All	FIPK	57-2505-1
1996	3.0L V6 F/I	(S) DOHC	Oil Filter	HP-2010	1986	3.0L V6 F/I	All	Air Filter	33-2024	1990	3.8L V6 F/I	(4,R)	Oil Filter	HP-3001
1996	3.0L V6 F/I	All	Air Filter	33-2107	Tempo									
1996	3.4L V8 F/I	(N) DOHC	Oil Filter	HP-2009	1994	2.3L L4 F/I	(X)	Oil Filter	HP-2004	1989	3.8L V6 F/I	(4,R)	Oil Filter	HP-2009
1996	3.4L V8 F/I	SHO	Air Filter	33-2107	1994	2.3L L4 F/I	All	Air Filter	33-2107	1989	3.8L V6 F/I	All	Air Filter	33-2033
1995	3.0L V6 F/I	All	Air Filter	33-2024	1994	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1988	2.3L L4 F/I	(T) Turbo	Oil Filter	HP-2004
1995	3.0L V6 F/I	SHO	Air Filter	33-2040	1993	2.3L L4 F/I	(X)	Oil Filter	HP-2004	1988	2.3L L4 F/I	Turbo	Air Filter	E-1931
1995	3.2L V6 F/I	(P) SHO	Oil Filter	HP-2009	1993	2.3L L4 F/I	All	Air Filter	33-2107	1988	3.8L V6 F/I	(4)	Oil Filter	HP-2009
1995	3.2L V6 F/I	SHO	Air Filter	33-2040	1993	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1988	3.8L V6 F/I	All	Air Filter	33-2015
1995	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1992	2.3L L4 F/I	(X)	Oil Filter	HP-2004	1988	5.0L V8 F/I	(F)	Oil Filter	HP-3001
1995	3.8L V6 F/I	All	Air Filter	33-2024	1992	2.3L L4 F/I	All	Air Filter	33-2107	1988	5.0L V8 F/I	All	Air Filter	33-2015
1994	3.0L V6 F/I	All	Air Filter	33-2024	1992	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1987	2.3L L4 F/I	(W) Turbo	Oil Filter	HP-2004
1994	3.0L V6 F/I	SHO	Air Filter	33-2040	1991	2.3L L4 F/I	(S,X)	Oil Filter	HP-3001	1987	2.3L L4 F/I	Turbo	Air Filter	E-1931
1994	3.2L V6 F/I	(P) SHO	Oil Filter	HP-2009	1991	2.3L L4 F/I	All	Air Filter	33-2044	1987	3.8L V6 F/I	(3)	Oil Filter	HP-3001
1994	3.2L V6 F/I	SHO	Air Filter	33-2040	1990	2.3L L4 F/I	(S,X)	Oil Filter	HP-3001	1987	3.8L V6 F/I	All	Air Filter	E-1325
1994	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1990	2.3L L4 F/I	All	Air Filter	33-2044	1987	5.0L V8 F/I	(F)	Oil Filter	HP-3001
1994	3.8L V6 F/I	All	Air Filter	33-2024	1989	2.3L L4 F/I	(S,X)	Oil Filter	HP-3001	1987	5.0L V8 F/I	All	Air Filter	33-2015
1993	3.0L V6 F/I	(1,U)	Oil Filter	HP-2009	1989	2.3L L4 F/I	All	Air Filter	33-2044	1986	2.3L L4 F/I	(W) Turbo	Oil Filter	HP-2004
1993	3.0L V6 F/I	(Y)	Oil Filter	HP-2009	1988	2.3L L4 F/I	(S,X)	Oil Filter	HP-3001	1986	2.3L L4 F/I	Turbo	Air Filter	E-1931
1993	3.0L V6 F/I	All	Air Filter	33-2024	1988	2.3L L4 F/I	All	Air Filter	33-2044	1986	3.8L V6 F/I	(3)	Oil Filter	HP-3001
1993	3.0L V6 F/I	SHO	Air Filter	33-2040	1987	2.3L L4 F/I	(S,X)	Oil Filter	HP-3001	1986	3.8L V6 F/I	All	Air Filter	E-1325
1993	3.2L V6 F/I	(P)	Oil Filter	HP-2009	1987	2.3L L4 F/I	All	Air Filter	33-2044	1986	5.0L V8 F/I	(F)	Oil Filter	HP-3001
1993	3.2L V6 F/I	SHO	Air Filter	33-2040	1986	2.3L L4 F/I	(S,X)	Oil Filter	HP-3001	1986	5.0L V8 F/I	All	Air Filter	33-2015
1993	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1986	2.3L L4 F/I	All	Air Filter	33-2044	1985	2.3L L4 F/I	(W) Turbo	Oil Filter	HP-2004
1993	3.8L V6 F/I	All	Air Filter	33-2024	1985	2.3L L4 F/I	(S,X)	Oil Filter	HP-3001	1985	2.3L L4 F/I	Turbo	Air Filter	E-1931
1992	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1985	2.3L L4 F/I	All	Air Filter	33-2044	1985	3.8L V6 F/I	(3)	Oil Filter	HP-3001
1992	3.0L V6 F/I	(Y)	Oil Filter	HP-2009	1984	2.3L L4 1 BBL.	(R)	Oil Filter	HP-3001	1985	3.8L V6 F/I	All	Air Filter	E-1325
1992	3.0L V6 F/I	All	Air Filter	33-2024	1984	2.3L L4 1 BBL.	All	Air Filter	33-2044	1985	5.0L V8 F/I	(F)	Oil Filter	HP-3001
1992	3.0L V6 F/I	SHO	Air Filter	33-2040	Thunderbird									
1992	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1997	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1985	5.0L V8 F/I	All	Air Filter	E-1290
1992	3.8L V6 F/I	All	Air Filter	33-2024	1997	3.8L V6 F/I	All	Air Filter	33-2033	1984	2.3L L4 F/I	(W) Turbo	Oil Filter	HP-2004
1991	2.5L L4 F/I	(N)	Oil Filter	HP-2004	1997	3.8L V6 F/I	All	FIPK	57-2505-1	1984	2.3L L4 F/I	Turbo	Air Filter	E-1931
1991	2.5L L4 F/I	All	Air Filter	33-2024	1997	4.6L V8 F/I	(W)	Oil Filter	HP-2010	1984	3.8L V6 F/I	(3)	Oil Filter	HP-3001
1991	3.0L V6 F/I	(U,Y)	Oil Filter	HP-2009	1997	4.6L V8 F/I	All	Air Filter	33-2033	1984	3.8L V6 F/I	All	Air Filter	E-1325
1991	3.0L V6 F/I	All	Air Filter	33-2024	1997	4.6L V8 F/I	All	Air Filter	33-2033	1984	5.0L V8 F/I	(F)	Oil Filter	HP-3001
1991	3.0L V6 F/I	SHO	Air Filter	33-2040	1996	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1984	5.0L V8 F/I	All	Air Filter	E-1290
1991	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1996	3.8L V6 F/I	All	Air Filter	33-2033	1983	2.3L L4 F/I	(W) Turbo	Oil Filter	HP-2004
1991	3.8L V6 F/I	All	Air Filter	33-2024	1996	3.8L V6 F/I	All	FIPK	57-2505-1	1983	2.3L L4 F/I	Turbo	Air Filter	E-1931
1990	2.5L L4 F/I	(D)	Oil Filter	HP-2004	1996	4.6L V8 F/I	(W)	Oil Filter	HP-2010	1983	3.8L V6 2 BBL.	(3)	Oil Filter	HP-3001
1990	2.5L L4 F/I	All	Air Filter	33-2024	1996	4.6L V8 F/I	All	Air Filter	33-2033	1983	3.8L V6 2 BBL.	All	Air Filter	E-1325
1990	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1996	4.6L V8 F/I	All	FIPK	57-2505-1	1983	5.0L V8 F/I	(F)	Oil Filter	HP-3001
1990	3.0L V6 F/I	(Y)	Oil Filter	HP-2009	1995	4.6L V8 F/I	All	FIPK	57-2505-1	1983	5.0L V8 F/I	All	Air Filter	E-1290
1990	3.0L V6 F/I	All	Air Filter	33-2024	1995	3.8L V6 F/I	(W)	Oil Filter	HP-2010	1982	3.3L L6 1 BBL.	(B)	Oil Filter	HP-3001
1990	3.0L V6 F/I	SHO	Air Filter	33-2040	1995	3.8L V6 F/I	All	Air Filter	33-2033	1982	3.3L L6 1 BBL.	All	Air Filter	E-1350
1990	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1995	3.8L V6 F/I	Non SC	FIPK	57-2505-1	1982	3.8L V6 2 BBL.	(3)	Oil Filter	HP-3001
1990	3.8L V6 F/I	All	Air Filter	33-2024	1995	4.6L V8 F/I	All	Air Filter	33-2033	1982	3.8L V6 2 BBL.	All	Air Filter	E-1325
1989	2.5L L4 F/I	(D)	Oil Filter	HP-2004	1995	4.6L V8 F/I	All	FIPK	57-2505-1	1982	4.2L V8 2 BBL.	(D)	Oil Filter	HP-3001
1989	2.5L L4 F/I	All	Air Filter	33-2024	1994	3.8L V6 F/I	(4,R)	Oil Filter	HP-2009	1982	4.2L V8 2 BBL.	All	Air Filter	E-1180
1989	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1994	3.8L V6 F/I	All	Air Filter	33-2033	1981	3.3L L6 1 BBL.	(B)	Oil Filter	HP-3001
1989	3.0L V6 F/I	(Y) SHO	Oil Filter	HP-2009	1994	3.8L V6 F/I	Non SC	FIPK	57-2505-1	1981	3.3L L6 1 BBL.	All	Air Filter	E-1350
1989	3.0L V6 F/I	All	Air Filter	33-2024	1994	4.6L V8 F/I	(W)	Oil Filter	HP-2010	1981	4.2L V8 2 BBL.	(D)	Oil Filter	HP-3001
1989	3.0L V6 F/I	SHO	Air Filter	33-2040	1994	4.6L V8 F/I	All	Air Filter	33-2033	1981	4.2L V8 2 BBL.	All	Air Filter	E-1180
1989	3.8L V6 F/I	(4)	Air Filter	33-2024	1994	4.6L V8 F/I	All	FIPK	57-2505-1	1981	5.0L V8 2 BBL.	(F)	Oil Filter	HP-3001
1989	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1993	3.8L V6 F/I	(4,R)	Oil Filter	HP-2009	1981	5.0L V8 2 BBL.	All	Air Filter	E-1180
1988	2.5L L4 F/I	(D) A.T.	Oil Filter	HP-2004	1993	3.8L V6 F/I	All	Air Filter	33-2033	1980	200 L6 1 BBL.	(B)	Oil Filter	HP-3001
1988	2.5L L4 F/I	(D) M.T.	Oil Filter	HP-3001	1993	3.8L V6 F/I	Non SC	FIPK	57-2505-1	1980	200 L6 1 BBL.	All	Air Filter	E-1350
1988	2.5L L4 F/I	All	Air Filter	33-2024	1993	5.0L V8 F/I	(T)	Oil Filter	HP-3001	1980	255 V8 2 BBL.	(D)	Oil Filter	HP-3001
1988	3.0L V6 F/I	(U)	Oil Filter	HP-2009	1993	5.0L V8 F/I	All	Air Filter	33-2033	1980	255 V8 2 BBL.	All	Air Filter	E-1180
1988	3.0L V6 F/I	All	Air Filter	33-2024	1992	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1980	302 V8 2 BBL.	(F)	Oil Filter	HP-3001
1988	3.8L V6 F/I	(4)	Oil Filter	HP-2009	1992	3.8L V6 F/I	All	Air Filter	33-2033	1980	302 V8 2 BBL.	All	Air Filter	E-1180
1988	3.8L V6 F/I	All	Air Filter	33-2024	1992	3.8L V6 F/I	Non SC	FIPK	57-2505-1	1979	302 V8 2 BBL.	(F)	Oil Filter	HP-3001
1987	2.5L L4 F/I	(D) A.T.	Oil Filter	HP-2004	1992	5.0L V8 F/I	(T)	Oil Filter	HP-3001	1979	302 V8 2 BBL.	All	Air Filter	E-1180
1987	2.5L L4 F/I	(D) M.T.	Oil Filter	HP-3001	1992	5.0L V8 F/I	All	Air Filter	33-2033	1979	351 V8 2 BBL.	(H)	Oil Filter	HP-3001
1987	2.5L L4 F/I	All	Air Filter	33-2024	1992	5.0L V8 F/I	All	FIPK	57-2505-1	1979	351 V8 2 BBL.	All	Air Filter	E-1290
					1992	5.0L V8 F/I	All	FIPK	57-2505-1	1978	302 V8 2 BBL.	(F)	Oil Filter	HP-3001

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #
1978	302 V8 2 BBL.	All		Air Filter	E-1290	2001	5.4L V8 F/I	(L,M,Z)		Oil Filter	HP-2010	1994	5.0L V8 F/I	All		Air Filter	33-2023
1978	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	2001	5.4L V8 F/I	All		Air Filter	E-0945	1994	5.8L V8 F/I	(H)		Oil Filter	HP-3001
1978	351 V8 2 BBL.	All		Air Filter	E-1290	2001	6.8L V10 F/I	(S)		Oil Filter	HP-2010	1994	5.8L V8 F/I	All		Air Filter	33-2023
1978	400 V8 2 BBL.	(S)		Oil Filter	HP-3001	2001	6.8L V10 F/I	All		Air Filter	E-0945	1994	7.5L V8 F/I	(G) exc.		Oil Filter	HP-3001
1978	400 V8 2 BBL.	All		Air Filter	E-1290	2001	7.3L V8 DSL	(F)		Oil Filter	HP-6001	off-road apps					
1978	460 V8 4 BBL.	exc.Police		Air Filter	E-1580	2001	7.3L V8 DSL	All Qty.2		Air Filter	33-2127*	1994	7.5L V8 F/I	All		Air Filter	33-2023
1978	460 V8 4 BBL.	Police only		Air Filter	E-1570	2000	4.2L V6 F/I	(2)		Oil Filter	HP-2009	1993	4.9L L6 F/I	(Y)		Oil Filter	HP-3001
1977	302 V8 2 BBL.	(F)		Oil Filter	HP-3001	2000	4.2L V6 F/I	All		Air Filter	E-0945	1993	4.9L L6 F/I	All		Air Filter	33-2023
1977	302 V8 2 BBL.	All		Air Filter	E-1180	2000	4.6L V8 F/I	(W)		Oil Filter	HP-2010	1993	5.0L V8 F/I	(N)		Oil Filter	HP-3001
1977	351 V8 2 BBL.	(H)		Oil Filter	HP-3001	2000	4.6L V8 F/I	All		Air Filter	E-0945	1993	5.0L V8 F/I	All		Air Filter	33-2023
1977	351 V8 2 BBL.	All		Air Filter	E-1290	2000	5.4L V8 F/I	(L,M,Z)		Oil Filter	HP-2010	1993	5.8L V8 F/I	(H)		Oil Filter	HP-3001
1977	400 V8 2 BBL.	(S)		Oil Filter	HP-3001	2000	5.4L V8 F/I	All		Air Filter	E-0945	1993	5.8L V8 F/I	All		Air Filter	33-2023
1977	400 V8 2 BBL.	All		Air Filter	E-1290	2000	6.8L V10 F/I	(S)		Oil Filter	HP-2010	1993	7.3L V8 DSL	(M)		Oil Filter	HP-4002
1977	400 V8 4 BBL.	(R)		Oil Filter	HP-3001	2000	6.8L V10 F/I	All		Air Filter	E-0945	1993	7.3L V8 DSL	All		Air Filter	E-1461
1977	400 V8 4 BBL.	All		Air Filter	E-1290	2000	7.3L V8 DSL	(F)		Oil Filter	HP-6001	1993	7.5L V8 F/I	(G)		Oil Filter	HP-3001
1976	460 V8 4 BBL.	(A)		Oil Filter	HP-3001	2000	7.3L V8 DSL	All Qty.2		Air Filter	33-2127*	1993	7.5L V8 F/I	All		Air Filter	33-2023
1976	460 V8 4 BBL.	All		Air Filter	E-1580	1999	4.2L V6 F/I	All		Air Filter	E-0945	1992	4.9L L6 F/I	(Y)		Oil Filter	HP-3001
1975	460 V8 4 BBL.	(A)		Oil Filter	HP-3001	1999	4.6L V8 F/I	Econoline		Air Filter	E-0945	1992	4.9L L6 F/I	All		Air Filter	33-2023
1975	460 V8 4 BBL.	All		Air Filter	E-1580	1999	5.4L V8 F/I	(L)		Oil Filter	HP-2010	1992	5.0L V8 F/I	(N)		Oil Filter	HP-3001
1974	460 V8 4 BBL.	(A)		Oil Filter	HP-3001	1999	5.4L V8 F/I	All		Air Filter	E-0945	1992	5.0L V8 F/I	All		Air Filter	33-2023
1974	460 V8 4 BBL.	All		Air Filter	E-1580	1999	7.3L V8 DSL	All Qty.2		Air Filter	33-2127*	1992	5.8L V8 F/I	(H)		Oil Filter	HP-3001
1973	400 V8 4 BBL.	Police only		Air Filter	E-1570	1998	4.2L V6 F/I	(2)		Oil Filter	HP-2009	1992	5.8L V8 F/I	All		Air Filter	33-2023
1973	429 V8 4 BBL.	exc.Police		Air Filter	E-1580	1998	4.2L V6 F/I	All		Air Filter	E-0945	1992	7.3L V8 DSL	(M)		Oil Filter	HP-4002
1973	429 V8 4 BBL.	Police only		Air Filter	E-1570	1998	4.6L V8 F/I	(6)		Oil Filter	HP-2010	1992	7.3L V8 DSL	All		Air Filter	E-1461
1973	460 V8 4 BBL.	exc.Police		Air Filter	E-1580	1998	4.6L V8 F/I	All		Air Filter	E-0945	1992	7.5L V8 F/I	(G)		Oil Filter	HP-3001
1973	460 V8 4 BBL.	Police only		Air Filter	E-1570	1998	5.4L V8 F/I	(L)		Oil Filter	HP-2010	1992	7.5L V8 F/I	All		Air Filter	33-2023
1972	400 V8 2 BBL.	All		Air Filter	E-1570	1998	5.4L V8 F/I	All		Air Filter	E-0945	1991	4.9L L6 F/I	(Y)		Oil Filter	HP-3001
1972	429 V8 2 BBL.	All		Air Filter	E-1570	1998	6.8L V10 F/I	(S)		Oil Filter	HP-2010	1991	4.9L L6 F/I	All		Air Filter	33-2023
1972	429 V8 4 BBL.	All		Air Filter	E-1570	1998	6.8L V10 F/I	All		Air Filter	E-0945	1991	5.0L V8 F/I	(N)		Oil Filter	HP-3001
1972	429 V8 4 BBL.	All		Oil Filter	HP-3001	1998	7.3L V8 DSL	(F) Turbo		Oil Filter	HP-6001	1991	5.0L V8 F/I	All		Air Filter	33-2023
1971	429 V8 4 BBL.	All		Air Filter	E-1570	1998	7.3L V8 DSL	All Qty.2		Air Filter	33-2127*	1991	5.8L V8 F/I	(H)		Oil Filter	HP-3001
1971	429 V8 4 BBL.	All		Oil Filter	HP-3001	1997	4.2L V6 F/I	(2)		Oil Filter	HP-2009	1991	5.8L V8 F/I	All		Air Filter	33-2023
1970	429 V8 4 BBL.	All		Air Filter	E-1570	1997	4.2L V6 F/I	All		Air Filter	E-0945	1991	7.3L V8 DSL	(M)		Oil Filter	HP-4002
1970	429 V8 4 BBL.	All		Oil Filter	HP-3001	1997	4.6L V8 F/I	(6)		Oil Filter	HP-2010	1991	7.3L V8 DSL	All		Air Filter	E-1460
1969	429 V8 4 BBL.	All		Air Filter	E-1570	1997	4.6L V8 F/I	All		Air Filter	E-0945	1991	7.5L V8 F/I	(G)		Oil Filter	HP-3001
1969	429 V8 4 BBL.	All		Oil Filter	HP-3001	1997	5.4L V8 F/I	(L)		Oil Filter	HP-2010	1991	7.5L V8 F/I	All		Air Filter	33-2023
1968	390 V8 4 BBL.	All		Air Filter	E-1560	1997	5.4L V8 F/I	All		Air Filter	E-0945	1990	4.9L L6 F/I	(Y)		Oil Filter	HP-3001
1968	390 V8 4 BBL.	All		Oil Filter	HP-3001	1997	6.8L V10 F/I	(S)		Oil Filter	HP-2010	1990	4.9L L6 F/I	All		Air Filter	33-2023
1968	429 V8 4 BBL.	All		Air Filter	E-1570	1997	6.8L V10 F/I	All		Air Filter	E-0945	1990	5.0L V8 F/I	(N)		Oil Filter	HP-3001
1968	429 V8 4 BBL.	All		Oil Filter	HP-3001	1997	7.3L V8 DSL	(F) Turbo		Oil Filter	HP-6001	1990	5.0L V8 F/I	All		Air Filter	33-2023
1963	406 V8 3x2BBL.	All		Air Filter	E-1960	1997	7.3L V8 DSL	Turbo Qty.2		Air Filter	33-2127*	1990	5.8L V8 F/I	(H)		Oil Filter	HP-3001
1963	406 V8 3x2BBL.	All		Oil Filter	HP-3001	1997	7.5L V8 F/I	All		Air Filter	33-2023	1990	5.8L V8 F/I	All		Air Filter	33-2023
1962	406 V8 3x2BBL.	All		Air Filter	E-1960	1996	4.9L L6 F/I	(Y) Ovr &		Oil Filter	HP-3001	1990	7.3L V8 DSL	(G)		Oil Filter	HP-3001
1962	406 V8 3x2BBL.	All		Oil Filter	HP-3001	undr 8500 GVW					1990	7.3L V8 DSL	All		Air Filter	E-1460	
Van						1996	4.9L L6 F/I	All		Air Filter	33-2023	1990	7.5L V8 F/I	(M)		Oil Filter	HP-4002
2003	4.2L V6 F/I	Econoline,(2)		Oil Filter	HP-2009	1996	5.0L V8 F/I	(N)		Oil Filter	HP-3001	1990	7.5L V8 F/I	All		Air Filter	33-2023
2003	4.6L V8 F/I	Econoline,(W)		Oil Filter	HP-2010	1996	5.0L V8 F/I	All		Air Filter	33-2023	1989	4.9L L6 F/I	(Y)		Oil Filter	HP-3001
2003	5.4L V8 F/I	Econoline,(L)		Oil Filter	HP-2010	1996	5.8L V8 F/I	(H)		Oil Filter	HP-3001	1989	4.9L L6 F/I	All		Air Filter	33-2023
2003	5.4L V8 F/I	Econoline, (M) CNG		Oil Filter	HP-2010	1996	5.8L V8 F/I	All		Air Filter	33-2023	1989	5.0L V8 F/I	(N)		Oil Filter	HP-3001
2003	5.4L V8 F/I	Econoline, (Z) Bi-Fuel		Oil Filter	HP-2010	1996	5.8L V8 F/I	w/oil cooler		Oil Filter	HP-2010	1989	5.0L V8 F/I	All		Air Filter	33-2023
2003	6.8L V10 F/I	Econoline, (F) Turbo		Oil Filter	HP-2010	1996	7.3L V8 DSL	(F) Turbo		Oil Filter	HP-6001	1989	5.8L V8 F/I	(H)		Oil Filter	HP-3001
2003	7.3L V8 DSL	Econoline, (F) Turbo		Oil Filter	HP-2010	1996	7.3L V8 DSL	Turbo Qty.2		Air Filter	33-2127*	1989	5.8L V8 F/I	All		Air Filter	33-2023
2002	4.2L V6 F/I	All		Air Filter	E-0945	1996	7.5L V8 F/I	(G)		Oil Filter	HP-3001	1989	7.3L V8 DSL	(M)		Oil Filter	HP-4002
2002	4.6L V8 F/I	(W)		Oil Filter	HP-2010	1996	7.5L V8 F/I	All		Air Filter	33-2099	1989	7.3L V8 DSL	All		Air Filter	E-1460
2002	4.6L V8 F/I	All		Air Filter	E-0945	1995	4.9L L6 F/I	All		Air Filter	33-2023	1989	7.5L V8 F/I	(G) exc.		Oil Filter	HP-3001
2002	5.4L V8 F/I	All		Air Filter	E-0945	1995	5.0L V8 F/I	(N)		Oil Filter	HP-3001	off-road apps					
2002	5.4L V8 F/I	Econoline, (L), (M), (Z)		Oil Filter	HP-2010	1995	5.0L V8 F/I	All		Air Filter	33-2023	1989	7.5L V8 F/I	All		Air Filter	33-2023
2002	6.8L V10 F/I	All		Air Filter	E-0945	1995	5.8L V8 F/I	(H)		Oil Filter	HP-3001	1988	4.9L L6 F/I	(Y)		Oil Filter	HP-3001
2002	6.8L V10 F/I	Econoline,(S)		Oil Filter	HP-2010	1995	5.8L V8 F/I	All		Air Filter	33-2023	1988	4.9L L6 F/I	All		Air Filter	33-2023
2002	7.3L V8 DSL	All Qty.2		Air Filter	33-2127*	1995	5.8L V8 F/I	All		Air Filter	33-2023	1988	5.0L V8 F/I	(N)		Oil Filter	HP-3001
2002	7.3L V8 F/I	Econoline,(F)		Oil Filter	HP-6001	1995	7.3L V8 DSL	(F) Turbo		Oil Filter	HP-6001	1988	5.0L V8 F/I	All		Air Filter	33-2023
2001	4.2L V6 F/I	(2)		Oil Filter	HP-2009	1995	7.3L V8 DSL	Turbo Qty.2		Air Filter	33-2127*	1988	5.8L V8 F/I	(H)		Oil Filter	HP-3001
2001	4.2L V6 F/I	All		Air Filter	E-0945	1995	7.5L V8 F/I	(G) exc.		Oil Filter	HP-3001	1988	5.8L V8 F/I	All		Air Filter	33-2023
2001	4.6L V8 F/I	(W)		Oil Filter	HP-2010	off-road apps					1988	5.8L V8 F/I	All		Air Filter	33-2023	
2001	4.6L V8 F/I	All		Air Filter	E-0945	1994	4.9L L6 F/I	(Y) Ovr &		Oil Filter	HP-3001	1988	7.3L V8 DSL	All		Air Filter	E-1460
2001	4.6L V8 F/I	All		Air Filter	E-0945	undr 8500 GVW					1988	7.5L V8 F/I	(G) exc.		Oil Filter	HP-3001	
2001	4.6L V8 F/I	All		Air Filter	E-0945	1994	4.9L L6 F/I	All		Air Filter	33-2023	off-road apps					
2001	4.6L V8 F/I	All		Air Filter	E-0945	1994	5.0L V8 F/I	(N)		Oil Filter	HP-3001	1988	7.5L V8 F/I	All		Air Filter	33-2023
2001	4.6L V8 F/I	All		Air Filter	E-0945	1994	5.0L V8 F/I	(N)		Oil Filter	HP-3001	1987	4.9L L6 F/I	All		Air Filter	33-2023

* 2 filters needed

Automotive Applications

(Van cont.)

FORD

YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #	YRS.	ENG.DISPL.	INTAKE	COMMENTS	PRODUCT	PART #			
1987	5.0L	V8	F/I	All	Air Filter	33-2023	1980	302	V8	2 BBL.	All	Air Filter	E-1290	1968	240	L6	1 BBL.	All	Air Filter	E-1040
1987	5.8L	V8	4 BBL.	All	Air Filter	E-1570	1980	351	V8	2 BBL.	(G)	Oil Filter	HP-3001	1968	240	L6	1 BBL.	All	Oil Filter	HP-3001
1987	5.8L	V8	F/I	All	Air Filter	33-2023	1980	351	V8	2 BBL.	All	Air Filter	E-1290	1968	302	V8	2 BBL.	All	Air Filter	E-1040
1987	6.9L	V8	DSL	All	Air Filter	E-1460	1980	400	V8	2 BBL.	(Z)	Oil Filter	HP-3001	1968	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001
1987	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1980	400	V8	2 BBL.	All	Air Filter	E-1290	1967	170	L6	1 BBL.	All	Air Filter	E-1080
1987	7.5L	V8	F/I	All	Air Filter	33-2023	1980	460	V8	4 BBL.	(L)	Oil Filter	HP-3001	1967	170	L6	1 BBL.	All	Oil Filter	HP-3001
1986	4.9L	L6	1 BBL.	(Y)	Oil Filter	HP-3001	1980	460	V8	4 BBL.	All	Air Filter	E-1570	1967	300	L6	1 BBL.	All	Air Filter	E-1080
1986	4.9L	L6	1 BBL.	All	Air Filter	E-1040	1979	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	1966	170	L6	1 BBL.	All	Air Filter	E-1080
1986	5.0L	V8	F/I	(N)	Oil Filter	HP-3001	1979	300	L6	1 BBL.	All	Air Filter	E-1040	1966	170	L6	1 BBL.	All	Oil Filter	HP-3001
1986	5.0L	V8	F/I	All	Air Filter	33-2012	1979	302	V8	2 BBL.	(G)	Oil Filter	HP-3001	1965	200	L6	1 BBL.	All	Air Filter	E-1080
1986	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1979	302	V8	2 BBL.	All	Air Filter	E-1290	1965	200	L6	1 BBL.	All	Oil Filter	HP-3001
1986	5.8L	V8	4 BBL.	(H)	Oil Filter	HP-3001	1979	351	V8	2 BBL.	(H)	Oil Filter	HP-3001	1964	200	L6	1 BBL.	All	Air Filter	E-1080
1986	5.8L	V8	4 BBL.	All	Air Filter	E-1570	1979	351	V8	2 BBL.	All	Air Filter	E-1290	1964	200	L6	1 BBL.	All	Oil Filter	HP-3001
1986	6.9L	V8	DSL	(1)	Oil Filter	HP-4002	1979	460	V8	4 BBL.	(A)	Oil Filter	HP-3001	1963	200	L6	1 BBL.	All	Air Filter	E-1080
1986	6.9L	V8	DSL	All	Air Filter	E-1460	1979	460	V8	4 BBL.	All	Air Filter	E-1570	1963	200	L6	1 BBL.	All	Oil Filter	HP-3001
1986	7.5L	V8	4 BBL.	(L)	Oil Filter	HP-3001	1978	300	L6	1 BBL.	All	Air Filter	E-1040	Windstar						
1986	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1978	351	V8	2 BBL.	All	Air Filter	E-1290	2003	4.0L	V6	F/I	(4)	Oil Filter	HP-2009
1985	4.9L	L6	1 BBL.	(Y)	Oil Filter	HP-3001	1978	460	V8	4 BBL.	All	Air Filter	E-1570	2002	3.0L	V6	F/I	All	Air Filter	E-0995
1985	4.9L	L6	1 BBL.	All	Air Filter	E-1040	1977	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	2002	3.8L	V6	F/I	(4)	Oil Filter	HP-2009
1985	5.0L	V8	2 BBL.	(F)	Oil Filter	HP-3001	1977	300	L6	1 BBL.	All	Air Filter	E-1040	2002	3.8L	V6	F/I	All	Air Filter	E-0995
1985	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1977	351	V8	2 BBL.	(H)	Oil Filter	HP-3001	2001	3.0L	V6	F/I	(U)	Oil Filter	HP-2009
1985	5.8L	V8	2 BBL.	(G)	Oil Filter	HP-3001	1977	351	V8	2 BBL.	All	Air Filter	E-1290	2001	3.0L	V6	F/I	All	Air Filter	E-0995
1985	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1977	460	V8	4 BBL.	(A)	Oil Filter	HP-3001	2001	3.8L	V6	F/I	(4)	Oil Filter	HP-2009
1985	5.8L	V8	4 BBL.	(H)	Oil Filter	HP-3001	1977	460	V8	4 BBL.	All	Air Filter	E-1580	2001	3.8L	V6	F/I	All	Air Filter	E-0995
1985	5.8L	V8	4 BBL.	All	Air Filter	E-1570	1976	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	2000	3.0L	V6	F/I	(U)	Oil Filter	HP-2009
1985	5.8L	V8	4 BBL.	All	Air Filter	E-1570	1976	300	L6	1 BBL.	All	Air Filter	E-1040	2000	3.0L	V6	F/I	All	Air Filter	E-0995
1985	6.9L	V8	DSL	(1)	Oil Filter	HP-4002	1976	351	V8	2 BBL.	(H)	Oil Filter	HP-3001	2000	3.8L	V6	F/I	(4)	Oil Filter	HP-2009
1985	6.9L	V8	DSL	All	Air Filter	E-1460	1976	351	V8	2 BBL.	All	Air Filter	E-1290	2000	3.8L	V6	F/I	All	Air Filter	E-0995
1985	7.5L	V8	4 BBL.	(L)	Oil Filter	HP-3001	1976	460	V8	4 BBL.	(A)	Oil Filter	HP-3001	1999	3.0L	V6	F/I	(U)	Oil Filter	HP-2009
1985	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1976	460	V8	4 BBL.	All	Air Filter	E-1570	1999	3.0L	V6	F/I	All	Air Filter	E-0995
1984	4.9L	L6	1 BBL.	(Y)	Oil Filter	HP-3001	1976	460	V8	4 BBL.	All	Air Filter	E-1570	1999	3.0L	V6	F/I	All	Air Filter	E-0995
1984	4.9L	L6	1 BBL.	All	Air Filter	E-1040	1975	300	L6	1 BBL.	(B)	Oil Filter	HP-3001	1999	3.8L	V6	F/I	(4)	Oil Filter	HP-2009
1984	5.0L	V8	2 BBL.	(F)	Oil Filter	HP-3001	1975	300	L6	1 BBL.	All	Air Filter	E-1040	1999	3.8L	V6	F/I	All	Air Filter	E-0995
1984	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1975	302	V8	2 BBL.	(G)	Oil Filter	HP-3001	1998	3.0L	V6	F/I	(U)	Oil Filter	HP-2009
1984	5.8L	V8	2 BBL.	(G)	Oil Filter	HP-3001	1975	302	V8	2 BBL.	All	Air Filter	E-1300	1998	3.8L	V6	F/I	(4)	Oil Filter	HP-2009
1984	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1975	351	V8	2 BBL.	(H)	Oil Filter	HP-3001	1998	3.8L	V6	F/I	All	Air Filter	E-0995
1984	5.8L	V8	4 BBL.	(H)	Oil Filter	HP-3001	1975	351	V8	2 BBL.	All	Air Filter	E-1290	1997	3.0L	V6	F/I	(U)	Oil Filter	HP-2009
1984	5.8L	V8	4 BBL.	All	Air Filter	E-1570	1975	460	V8	4 BBL.	(A)	Oil Filter	HP-3001	1997	3.0L	V6	F/I	All	Air Filter	33-2024
1984	6.9L	V8	DSL	(1)	Oil Filter	HP-4002	1975	460	V8	4 BBL.	All	Air Filter	E-1570	1997	3.8L	V6	F/I	(4)	Oil Filter	HP-2009
1984	6.9L	V8	DSL	All	Air Filter	E-1460	1974	240	L6	1 BBL.	All	Air Filter	E-1200	1997	3.8L	V6	F/I	All	Air Filter	E-0995
1984	7.5L	V8	4 BBL.	(L)	Oil Filter	HP-3001	1974	240	L6	1 BBL.	All	Oil Filter	HP-3001	1996	3.0L	V6	F/I	(U)	Oil Filter	HP-2009
1984	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1974	300	L6	1 BBL.	All	Air Filter	E-1040	1996	3.0L	V6	F/I	All	Air Filter	33-2024
1983	4.9L	L6	1 BBL.	(Y)	Oil Filter	HP-3001	1974	300	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001	1996	3.8L	V6	F/I	(4)	Oil Filter	HP-2009
1983	4.9L	L6	1 BBL.	All	Air Filter	E-1040	1974	302	V8	2 BBL.	All	Air Filter	E-1300	1996	3.8L	V6	F/I	All	Air Filter	E-0995
1983	5.0L	V8	2 BBL.	(F)	Oil Filter	HP-3001	1974	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001	1995	3.0L	V6	F/I	(U)	Oil Filter	HP-2009
1983	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1973	240	L6	1 BBL.	All	Air Filter	E-1200	1995	3.0L	V6	F/I	All	Air Filter	33-2024
1983	5.8L	V8	2 BBL.	(G)	Oil Filter	HP-3001	1973	240	L6	1 BBL.	All	Oil Filter	HP-3001	1995	3.8L	V6	F/I	(4)	Oil Filter	HP-2009
1983	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1973	300	L6	1 BBL.	All	Air Filter	E-1040	ZX2						
1983	5.8L	V8	4 BBL.	All	Air Filter	E-1570	1973	300	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001	2003	2.0L	L4	F/I	DOHC	Air Filter	E-0995
1983	6.9L	V8	DSL	(1)	Oil Filter	HP-4002	1973	302	V8	2 BBL.	All	Air Filter	E-1300	2002	2.0L	L4	F/I	DOHC	Air Filter	E-0995
1983	6.9L	V8	DSL	All	Air Filter	E-1460	1973	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001	GEO						
1983	7.5L	V8	4 BBL.	(L)	Oil Filter	HP-3001	1972	240	L6	1 BBL.	All	Air Filter	E-1040	Metro						
1983	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1972	240	L6	1 BBL.	All	Oil Filter	HP-3001	1998	1.0L	L4	F/I	All	Air Filter	E-9209
1982	4.9L	L6	1 BBL.	All	Air Filter	E-1040	1972	302	V8	2 BBL.	All	Air Filter	E-1040	1997	1.0L	L3	F/I	(6)	Oil Filter	HP-1002
1982	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1972	302	V8	2 BBL.	All	Oil Filter	HP-3001	1997	1.0L	L3	F/I	All	Air Filter	E-9209
1982	5.8L	V8	2 BBL.	All	Air Filter	E-1290	1971	240	L6	1 BBL.	All	Air Filter	E-1040	1997	1.0L	L3	F/I	(9)	Oil Filter	HP-1002
1982	5.8L	V8	4 BBL.	All	Air Filter	E-1570	1971	240	L6	1 BBL.	exc.cart.type	Oil Filter	HP-3001	1997	1.3L	L4	F/I	(9)	Oil Filter	HP-1002
1982	6.6L	V8	2 BBL.	All	Air Filter	E-1290	1971	302	V8	2 BBL.	All	Air Filter	E-1040	1997	1.3L	L4	F/I	All	Air Filter	E-9209
1982	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1971	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001	1996	1.0L	L3	F/I	(6)	Oil Filter	HP-1002
1981	4.9L	L6	1 BBL.	(E)	Oil Filter	HP-3001	1970	170	L6	1 BBL.	All	Air Filter	E-1040	1996	1.0L	L3	F/I	All	Air Filter	E-9209
1981	4.9L	L6	1 BBL.	All	Air Filter	E-1040	1970	170	L6	1 BBL.	All	Oil Filter	HP-3001	1996	1.3L	L4	F/I	(9)	Oil Filter	HP-1002
1981	5.0L	V8	2 BBL.	(F)	Oil Filter	HP-3001	1970	240	L6	1 BBL.	All	Air Filter	E-1040	1996	1.3L	L4	F/I	All	Air Filter	E-9209
1981	5.0L	V8	2 BBL.	All	Air Filter	E-1290	1970	240	L6	1 BBL.	All	Oil Filter	HP-3001	1995	1.0L	L3	F/I	(6)	Oil Filter	HP-1002
1981	6.6L	V8	2 BBL.	(Z)	Oil Filter	HP-3001	1970	302	V8	2 BBL.	All	Air Filter	E-1040	1995	1.0L	L3	F/I	All	Air Filter	E-9209
1981	6.6L	V8	2 BBL.	All	Air Filter	E-1290	1970	302	V8	2 BBL.	exc.cart.type	Oil Filter	HP-3001	1995	1.3L	L4	F/I	(9)	Oil Filter	HP-1002
1981	7.5L	V8	4 BBL.	(L)	Oil Filter	HP-3001	1969	240	L6	1 BBL.	All	Air Filter	E-1040	1995	1.3L	L4	F/I	All	Air Filter	E-9209
1981	7.5L	V8	4 BBL.	All	Air Filter	E-1570	1969	240	L6	1 BBL.	All	Oil Filter	HP-3001	1994	1.0L	L3	F/I	(6)	Oil Filter	HP-1002
1980	300	L6	1 BBL.	(E)	Oil Filter	HP-3001	1969	302	V8	2 BBL.	All	Air Filter	E-1040	1994	1.0L	L3	F/I	All	Air Filter	E-9209
1980	300	L6	1 BBL.	All	Air Filter	E-1040	1969	302	V8	2 BBL.										